

Atlas Copco MINETRUCK

MT2000

Spare Parts Catalogue

Use Atlas Copco genuine parts only.
Any damage or malfunction caused by the
use of unauthorized parts is not covered by
warranty or product liability.

This publication refers only to the mentioned
product.

When ordering spare parts, please state part
number (not the ref no) and the quantity.

Använd alltid Atlas Copco originaldelar.
Skador och driftstörningar orsakade av ej
godkända reservdelar täcks ej av garanti
och produktsäkerhetsåtaganden.

Denna publikation gäller endast för
nämnda produkt.

Vid beställning av reservdelar, var god ange
detaljnummer (ej ref nr) samt antal.

© Copyright 2006, Atlas Copco Rock Drills AB, Sweden

Any unauthorized use or copying of the contents or any part thereof is prohibited.
This applies in particular to trademarks, model denominations, part numbers and drawings.

Obehörigt utnyttjande eller kopiering av innehållet eller del därav är förbjudet.
Detta gäller speciellt varumärken, modellbeteckningar, reservdelnummer och ritningar.


Table of Content / Innehållsförteckning

1. MAIN BODY / HUVUDKROPP	5
2. POWER UNIT / KRAFTENHET	61
3. POWERTRAIN / DRIVLINA	127
4. OPERATORS AREA / MANÖVEROMRÅDE	231
5. STEERING SYSTEM / STYRSYSTEM	265
6. DUMP SYSTEM / TIPP SYSTEM	289
7. BRAKE SYSTEM / BROMSSYSTEM	305
8. LUBRICATION SET / SMÖRJUTRUSTNING	329
9. SIGN SET / SKYLTSATS	347
10.CROSS REFERENCE LIST	355

MAIN BODY / HUVUDKROPP
LIST OF CONTENTS

Part no Detaljnr	Description	Benämning	See page Se sida	Remarks Anmärkning
–	MAIN BODY	HUVUDKROPP	7	
5590 0001 77	– POWERFRAME	– MOTORRAM	9	
–	– – POWERFRAME	– – MOTORRAM	11	
5573 6649 00	– – – AXLE SUPPORT	– – – AXELSTÖD	13	AXLE HANGER WELDMENT-RT-406
5575 7002 82	– – GRILL	– – GRILL	15	
–	– – PROTECTION ROOF	– – SKYDDSTAK	17	
–	– – COVER	– – PLÅTHUV	21	HOOD INST-LOW CANOPY
5554 5348 00	– – – LOCK DEVICE	– – – LÅSANORDNING	25	LATCH ASSY-RUBBER
5574 5814 00	– – FUEL TANK	– – BRÄNSLETANK	27	FUEL TANK
–	– – – FUEL TANK	– – – BRÄNSLETANK	29	TANK ASSEMBLY-FUEL
5574 5815 00	– – HYDR.OIL TANK	– – HYDRAULOLJETANK	32	
–	– – – HYDR.OIL TANK	– – – HYDRAULOLJETANK	35	
5573 5998 00	– – – – HYDRAUL. FILTER	– – – – HYDRAULFILTER	37	
5535 4557 00	– – – – – FILTER	– – – – – FILTER	39	FILTER ASSY-HYDRAULIC SUCTION
5574 5794 00	– – – CAP	– – – HUV	41	HYD CAP ASSY
5535 2776 00	– – – VALVE	– – – VENTIL	43	RELIEF VALVE
5554 5348 00	– – – LOCK DEVICE	– – – LÅSANORDNING	25	LATCH ASSY-RUBBER
5590 0001 03	– CHASSIS	– CHASSIE	45	
5573 6415 00	– – CHASSIS	– – CHASSIE	47	
5573 6418 61	– – LOCKING	– – LÅSNING	49	
5590 0001 76	– DUMP BOX	– FLAK	51	9.2 CU.M
5572 4970 00	– – DUMP BOX	– – FLAK	53	9.2 CU.M
5571 7188 00	– TAILGATE	– BAKLEM	55	
5571 4891 00	– SWIVEL	– SVIVEL	57	
5573 6418 00	– SWIVEL LOCK	– MIDJELÅS	59	


MAIN BODY / HUVUDKROPP



MAIN BODY / HUVUDKROPP


Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5590 0001 77	1	POWERFRAME	MOTORRAM		
	5590 0001 03	1	CHASSIS	CHASSIE	Page 45	
	5590 0001 76	1	DUMP BOX	FLAK	Page 51	9.2 CU.M
	5571 7188 00	1	TAILGATE	BAKLEM	Page 55	
	5571 4891 00	1	SWIVEL	SVIVEL	Page 57	
	5573 6418 00	1	SWIVEL LOCK	MIDJELÅS	Page 59	

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1101	—	1	POWERFRAME	MOTORRAM	Page 11	
1102	5575 7002 82	1	GRILL	GRILL	Page 15	
1103	—	1	PROTECTION ROOF	SKYDDSTAK	Page 17	
2401	—	1	COVER	PLÅTHUV	Page 21	HOOD INST-LOW CANOPY
3102	5574 5814 00	1	FUEL TANK	BRÄNSLETANK	Page 27	FEUL TANK
3105	5574 5815 00	1	HYDR.OIL TANK	HYDRAULOLJETANK	Page 32	




5574 2894 00

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
37	5573 6649 00	1	AXLE SUPPORT	AXELSTÖD	Page 13	AXLE HANGER WELDMENT-RT-406
39	5574 0415 00	1	PLATE	PLÅT		FENDER FILL PLATE
40	—	1	MOUNT	FÄSTE		
58	5541 4412 00	4	HINGE	GÅNGJÄRN		HINGE-BARREL, 4', GREASABLE
63	5573 6769 00	1	FOOT PLATE	FOTPLATTA		FOOT REST
80	0144 4000 95	2	HEXAGON SCREW	SEKKANTSSKRUV		UNC 3/4 - 51 33 H 11,9 28
81	5559 9237 00	2	WASHER	PLÅTBRICKA		3/4 HT X 1.5 OD
82	—	1	FRONT PLATE	FRONTPLÅT		
83	—	2	SPACER	DISTANS		
84	5536 4553 00	22	FLANGE SCREW	FLÄNSSKRUV		CPSCR-FLG W 3/8 NC X 3/4
85	5559 9232 00	27	WASHER	PLÅTBRICKA		3/8 HT
86	0144 3366 03	4	SCREW, HEX HEAD	SKRUV, SEKKANT		UNC 1/2 X 45 - 8.8 FZB
87	5559 9234 00	25	WASHER	PLÅTBRICKA		1/2 HT
88	5530 7551 00	12	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1/2 NC N
89	5112 2467 47	12	SCREW	SKRUV		1C-624
90	5530 7116 00	12	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
93	0144 3288 03	3	SCREW, HEX HEAD	SKRUV, SEKKANT		UNC 3/8 X 32 - 8.8 FZB
94	0144 3362 03	8	SCREW, HEX HEAD	SKRUV, SEKKANT		UNC 1/2 X 25 - 8.8 FZB
97	5533 6841 00	1	KNOB	KNOPP		KNOB
98	0144 3362 03	1	SCREW, HEX HEAD	SKRUV, SEKKANT		UNC 1/2 X 25 - 8.8 FZB



5573 6649 00

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
4	5556 7224 00	2	CAP	HUV		
5	5530 8144 00	8	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 1 NC X 8 G8
6	5559 9239 00	8	WASHER	PLÅTBRICKA		




GRILL / GRILL


5575 7002 82

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5575 7000 60	1	GRILL	GRILL		
2	5530 7880 00	6	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/4 NC X 2-1/2
3	5559 9237 00	12	WASHER	PLÅTBRICKA		3/4 HT X 1.5 OD
4	5530 7356 00	6	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/4 NC N
5	5573 6500 00	1	EAR	ÖRA		
6	5573 6547 00	2	EAR	ÖRA		
7	5573 6548 00	2	EAR	ÖRA		
8	5574 1479 00	4	STIFFENER	FÖRSTYVNING		
9	5540 7490 00	14	BOLT	BULT		
10	5540 1128 00	18	WASHER	PLÅTBRICKA		WASHER-FLAT M20 HT PLTD
11	0291 1128 43	4	LOCK NUT	LÅSMUTTER		M 20 2,5 1A 22,8 16,9 - 3
12	5571 3299 00	2	LIFT EAR	LYFTÖRA		

PROTECTION ROOF / SKYDDSTAK



VIEW A-A




5574 9958 00 ed.00

PROTECTION ROOF / SKYDDSTAK

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	—	1	CANOPY	HUV		
2	5530 9235 00	8	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 10144220000
3	5530 7241 00	8	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1 NC N
4	5559 9239 00	16	WASHER	PLÅTBRICKA		

Fig. 1 of 3




5575 7008 79 1/3 ed.01

COVER / PLĀTHUV

Fig. 2 of 3



HOOD INST-LOW CANOPY



5575 7008 79 2/3 ed.01

COVER / PLÅTHUV

Fig. 3 of 3



COVER / PLÅTHUV


(Sheet 1 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5574 3121 00	1	COVER	PLÅTHUV		
2	—	1	COVER	PLÅTHUV		
3	5573 6470 00	1	WELDMENT	WELDMENT		
4	5574 7924 00	1	BRACKET	KONSOL		
5	5574 3109 00	1	COVER	PLÅTHUV		
6	5574 0468 00	1	COVER	PLÅTHUV		
7	5574 6599 00	2	BAR	STÅNG		
8	5574 7896 00	1	COVER	PLÅTHUV		
9	5573 6474 00	1	SUPPORT	STÖD		
10	5573 6475 00	1	SUPPORT	STÖD		
11	5573 6476 00	1	SUPPORT	STÖD		
12	5573 6477 00	1	SUPPORT	STÖD		
13	—	1	SUPPORT	STÖD		
14	5580 0012 50	2.13M	SEAL	TÄTNING		
15	5575 7007 38	2	STAY	STAG		
16	5541 4412 00	4	HINGE	GÅNGJÄRN		HINGE-BARREL, 4', GREASABLE
18	—	7	HINGE	GÅNGJÄRN		
19	0144 3368 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 57 - 8.8 FZB
20	5559 9234 00	10	WASHER	PLÅTBRICKA		1/2 HT
21	5530 7551 00	5	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1/2 NC N
22	0144 3366 03	3	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 45 - 8.8 FZB
23	0144 3284 03	3	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 16 - 8.8 FZB
24	5559 9232 00	4	WASHER	PLÅTBRICKA		3/8 HT
25	5530 7116 00	1	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
26	5571 4082 00	2	STOP	STOPP		
27	5554 5348 00	7	LOCK DEVICE	LÅSANORDNING	Page 25	LATCH ASSY-RUBBER
28	0144 3203 03	11	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/4 X 13 - 8.8 FZB
29	5559 9230 00	4	WASHER	PLÅTBRICKA		1/4 HT
31	5112 2467 47	2	SCREW	SKRUV		1C-624
32	—	1	PLATE	PLÅT		
33	5541 3641 00	11	NUT	MUTTER		NUT-CAGED 5/16 NC
34	0144 3245 03	11	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 5/16 X 16 - 8.8 FZB

COVER / PLÅTHUV



(Sheet 2 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
35	5559 9231 00	11	WASHER	PLÅTBRICKA		5/16 HT
36	0144 3286 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 22 - 8.8 FZB
37	5559 9232 00	10	WASHER	PLÅTBRICKA		3/8 HT
38	0144 3288 03	3	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 32 - 8.8 FZB
39	5530 7116 00	4	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
40	5541 2108 00	8	SHOULDER SCREW	ANSATSSKRUV		SHLDR BOLT-1/2DX1.25L-3/8
41	5500 6139 00	8	WASHER	PLÅTBRICKA		WASHER-FLAT 1/2 HT 1-3/8
42	5530 9141 00	12	WASHER	PLÅTBRICKA		WASHER-FLAT 10.5X40X1.5
43	5540 8302 00	8	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC SS
45	0144 3206 03	9	HEXAGON SCREW	SEKANTSSKRUV		UNC 1/4 - 19 12,8 H 4 11,
46	5530 7055 00	11	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1/4 NC NE
47	0144 3211 03	2	HEXAGON SCREW	SEKANTSSKRUV		UNC 1/4 - 38 12,8 19 4 11
48	5530 7032 00	10	LOCK WASHER	LÅSBRICKA		WASHER-LOCK 1/4 SPLIT TYP
59	5575 7007 77	3	HOLDER IRON	FÄSTJÄRN		
60	0147 1364 03	16	SCREW, HEX HEAD	SKRUV, SEXKANT		M 10 X 35 - 8.8 FZB
61	0291 1128 20	16	LOCK NUT	LÅSMUTTER		M 10 - 8 FZB / ISO 7040
62	0301 2344 00	32	PLAIN WASHER	RUNDBRICKA		10,5 / 20 X 2 -HB 200 FZB 10,5 / 20 X 2 -HB 200 FZB
63	—	3	PLATE	PLATTA		



1261 5000 32

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5533 7708 00	1	LATCH	REGEL		RUBBER LATCH
2	5533 5318 00	1	BRACKET	KONSOL		BRACKET-ANCHOR
3	5533 5391 00	1	HOOD SUPPORT	HUVSTÖD		HOOD BRACKET-STEM DOWN
4	0147 1253 03	1	SCREW, HEX HEAD	SKRUV, SEXKANT		M 6 X 45 - 8.8 FZB
5	0291 1128 15	1	LOCK NUT	LÅSMUTTER		M 6 - 8 FZB / ISO 7040




B0023945

FUEL TANK / BRÄNSLETANK

5574 5814 00

FEUL TANK

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	—	1	FUEL TANK	BRÄNSLETANK	Page 29	TANK ASSEMBLY-FUEL
2	5537 5554 00	1	CAP	HUV		CAP-FILLER (W/SHORT PINS)
3	5575 7005 91	1	STRAINER	SIL		
4	5534 5551 00	2	GAUGE	MÄTINSTRUMENT		SIGHT GAUGE




TANK CAPACITY :	
TOTAL TANK CAP.	=99.0 GAL. (375 LITER)
UPPER SIGHT GAGE	=74.0 GAL. (280 LITER)
LOWER SIGHT GAGE	=25.5 GAL. (97 LITER)

FUEL TANK / BRÄNSLETANK
TANK ASSEMBLY-FUEL


Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
18	5550 0667 00	1	ACCESS COVER	INSPEKT.LUCKA		
19	5556 0139 00	1	COVER PLATE	TÄCKPLÅT		
20	5533 2754 00	2	O-RING	O-RING		O-RING
21	5112 2803 18	20	SCREW	SKRUV		
22	5559 9232 00	20	WASHER	PLÅTBRICKA		3/8 HT
23	5530 7895 00	1	PLUG	PROPP		PLUG-2SQ.HD.
24	5530 7894 00	1	PLUG	PROPP		PLUG-SQ HD 1 1/2 NPT BLK
25	5503 7225 00	1	PLUG	PROPP		PLUG-HEX (O-RING)

Fig. 1 of 2



B0023946

Fig. 2 of 2




Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	—	1	HYDR.OIL TANK	HYDRAULOLJETANK	Page 35	
2	5533 2736 00	1	O-RING	O-RING		O-RING (VITON 48-SPFL)
3	5530 8977 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 1-1/2
4	5559 9232 00	4	WASHER	PLÅTBRICKA		3/8 HT
6	5573 6004 00	1	SUCTION PIPE	SUGRÖR		
7	5530 5040 00	2	SCREW	SKRUV		
8	5530 7029 00	2	LOCK WASHER	LÅSBRICKA		WASHER-LOCK 3/8 SPLIT TYP
9	5573 6006 00	1	BRACKET	KONSOL		
21	5534 5551 00	2	GAUGE	MÄTINSTRUMENT		SIGHT GAUGE
22	5503 7225 00	1	PLUG	PROPP		PLUG-HEX (O-RING)
23	5574 5794 00	1	CAP	HUV	Page 41	HYD CAP ASSY
24	5540 0839 00	1	STRAINER	SIL		STRAINER-TANK FILL
25	5534 0154 00	1	O-RING	O-RING		O-RING
26	5535 2776 00	1	VALVE	VENTIL	Page 43	RELIEF VALVE
27	5530 7892 00	1	PLUG	PLUGG		
28	5554 5348 00	1	LOCK DEVICE	LÅSANORDNING	Page 25	LATCH ASSY-RUBBER
29	0144 3203 03	3	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/4 X 13 - 8.8 FZB
30	5559 9230 00	3	WASHER	PLÅTBRICKA		1/4 HT
31	5112 3116 49	1	SCREW	SKRUV		
32	5530 8111 00	1	HEXAGON NUT	SEXXNT MUTTER		NUT-HEX 3/8 NC G8
33	5530 7116 00	1	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
34	5559 9232 00	4	WASHER	PLÅTBRICKA		3/8 HT
35	5500 9687 00	2	PLUG	PROPP		PLUG-HEX (O-RING)
36	3176 0577 00	2	PLUG	PROPP		

HYDR.OIL TANK / HYDRAULOLJETANK


5574 5815 00

HYDR.OIL TANK / HYDRAULOLJETANK




HYDR.OIL TANK / HYDRAULOLJETANK

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
5	—	1	TOP PLATE	TOPPLÅT		
7	0607 1100 22	1	SOCKET	HYLSA		B2 ST NPT 2 - -
8	5573 5998 00	1	HYDRAUL. FILTER	HYDRAULFILTER	Page 37	
9	5535 5146 00	2	FLANGE	FLÄNS		WELD FLANGE-3/8NPT
13	5535 0467 00	2	FLANGE	FLÄNS		
15	—	1	FLANGE	FLÄNS		
16	—	1	PLATE	PLÅT		
18	5112 2803 18	10	SCREW	SKRUV		
19	5559 9232 00	10	WASHER	PLÅTBRICKA		3/8 HT
20	5561 4110 00	1	FLANGE	FLÄNS		
21	5550 0667 00	1	ACCESS COVER	INSPEKT.LUCKA		
22	5533 2754 00	1	O-RING	O-RING		O-RING
23	—	1	WELDING FLANGE	SVETSFLÄNS		
24	5573 6003 00	1	DOOR	DÖRR		
25	5571 4082 00	1	STOP	STOPP		
26	5540 1754 00	2	WELDED HINGE	SVETSGÅNGJÄRN		
29	5574 0915 00	2	WASHER	BRICKA		




HYDRAUL. FILTER / HYDRAULFILTER**5573 5998 00**

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5535 4557 00	1	FILTER	FILTER	Page 39	FILTER ASSY-HYDRAULIC SUCTION




5535 4557 00 - 003

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
2	5535 4829 00	1	HEAD	HUVUD		INCLUDES ITEMS 3 TO 10
3	5536 6470 00	1	NUT	MUTTER		INCLUDES ITEM 4
4	5535 3361 00	1	O-RING	O-RING		
5	5535 3362 00	1	WINDOW	FÖNSTER		INCLUDES ITEM 6
6	5535 3363 00	1	KIT	SATS		WINDOW ASSEMBLY KIT
7	5535 3378 00	1	O-RING	O-RING		
8	5535 3379 00	1	PLUG	PROPP		INCLUDES ITEM 9
9	5535 3380 00	1	O-RING	O-RING		
10	5534 1706 00	1	DRAIN VALVE	DRÄNERINGSVENT.		DRAIN COCK (1/4)
11	5535 4830 00	1	VALVE	VENTIL		INCLUDES ITEMS 12 TO 19
12	5535 3383 00	1	SEAL	TÄTNING		
13	5535 3384 00	1	SPRING	FJÄDER		NOT ILLUSTRATED
14	5535 3385 00	2	BOLT	BULT		
15	5535 3386 00	2	MAGNET	MAGNET		
16	5535 4832 00	1	TUBE	RÖR		NOT ILLUSTRATED
17	5535 3388 00	1	BODY	RAM		
18	5535 3389 00	1	BRACKET	KONSOL		
19	5535 3390 00	1	O-RING	O-RING		
20	5535 2716 00	1	ELEMENT	ELEMENT		
21	5537 3232 00	1	BODY	RAM		



5574 5794 00

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5574 5497 00	1	CAP	HUV		HYD CAP MACHINING
2	5112 2467 47	1	SCREW	SKRUV		1C-624
3	0663 9050 01	1	O-RING	O-RING		9,25X 1,78 90 SHORE
4	5559 9232 00	2	WASHER	PLÅTBRICKA		3/8 HT
5	5555 2581 00	1	CHAIN	KEDJA		CHAIN-2/0 17' OR 20 LINKS
6	5531 0128 00	2	LOCK NUT	LÅSMUTTER		NUT-OVALOK 3/8 NC GR.C
7	5534 0154 00	1	O-RING	O-RING		O-RING




VALVE / VENTIL

5535 2776 00


RELIEF VALVE

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5534 8485 00	1	REPAIR KIT	RENOVERINGSSATS		INCLUDES 2 O-RINGS, 1 INTERNAL LOCK RING, 1 40 MICRON FILTER ELEMENT.




CHASSIS / CHASSIE**5590 0001 03**

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1601	5573 6415 00	1	CHASSIS	CHASSIE	Page 47	
3002	5573 6418 61	1	LOCKING	LÅSNING	Page 49	



5573 6415 00 ed.10


Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
9	5112 2803 18	8	SCREW	SKRUV		
10	5574 4976 00	2	TIE PLATE	SKARVPLÅT		
11	5574 4973 00	2	TIE PLATE	SKARVPLÅT		
12	5557 9156 00	2	BEARING	LAGER		
21	5533 2883 00	2	BUSHING	BUSSNING		BUSHING-BALL
23	5502 9911 00	4	INSERT	INSATS		
26	5558 3051 00	2	COVER	KÅPA		
27	5559 3542 00	1	SUPPORT	STÖD		
28	5571 3525 00	2	INSERT	INSATS		
41	5112 2392 40	8	LOCK WASHER	LÅSBRICKA		
42	5530 5257 00	1	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/4 NC X 3-1/4
43	5530 7030 00	1	LOCK WASHER	LÅSBRICKA		WASHER-LOCK 3/4 SPLIT TYP
44	5530 7356 00	1	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/4 NC N
45	5530 5145 00	2	GREASE NIPPLE	FETTNIPPEL		GREASE FITTING-1/8(STRAIG
57	5530 8576 00	12	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 1 NC X 3-1/4 G8
58	5530 7241 00	12	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1 NC N
59	5559 9239 00	24	WASHER	PLÅTBRICKA		
60	5572 0397 00	2	LOCKING PIN	SPÄRR PINNE		



5573 6418 00

LOCKING / LÅSNING**5573 6418 61**


Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5573 6587 00	0	LOCK	LÅS		
3	5571 6896 00	1	PIN	TAPP		
5	5572 0554 00	1	PIN	TAPP		
6	5535 2806 00	2	PIN	PINNE		PIN-Q/R 1/4 DIA X 3 LNG



DUMP BOX / FLAK**5590 0001 76**

9.2 CU.M


Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1605	5572 4970 00	1	DUMP BOX	FLAK	Page 53	9.2 CU.M



DUMP BOX / FLAK**5572 4970 00**

9.2 CU.M


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5573 6780 00	1	DUMP BOX	FLAK		
2	—	1	MOD. KIT	MOD.KIT		MODIFICATION
3	5530 5145 00	2	GREASE NIPPLE	FETTNIPPEL		GREASE FITTING-1/8(STRAIG
4	5530 6004 00	2	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 1/2 NC X 6 G5
5	5112 2465 26	2	LOCK WASHER	LÅSBRICKA		
6	5530 7551 00	2	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1/2 NC N
7	5564 7229 00	2	PIN	TAPP		




TAILGATE / BAKLEM

5571 7188 00

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
9	5573 2450 00	2	PIN	TAPP		
11	5559 9242 00	2	WASHER	PLÅTBRICKA		
12	5530 7112 00	2	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1- 1/2 NC
13	5530 5145 00	2	GREASE NIPPLE	FETTNIPPEL		GREASE FITTING-1/8(STRAIG
14	5540 8719 00	4	CLEVIS	KLYKA		DOUBLE CLEVIS
15	5571 7446 00	2	CHAIN	KÄTTING		




5571 4891 00 ed.02



SWIVEL / SVIVEL

5571 4891 00

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5530 0742 00	1	REPAIR SET	REPARATIONSSATS		REF 1, 5, 20, 22-26
1	5540 5631 00	2	BEARING	LAGER		
2	5571 3526 00	2	RETAINER	FASTHÅLLARE		
4	5571 4949 00	1	RETAINER	FASTHÅLLARE		
5	5571 3529 00	2	PIN	TAPP		
6	5571 4948 00	1	RETAINER	FASTHÅLLARE		
11	5540 5642 00	16	CAPSCREW	HUVUDSKRUV		CPSCR-12PT 1/2 NC X 2-1/2
12	5559 9236 00	24	WASHER	PLÅTBRICKA		
13	5530 6137 00	16	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 5/8 NC X 2 G8
14	5530 8072 00	8	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 5/8 NC X 1-3/4
20	5540 6744 00	4	O-RING	O-RING		O-RING
22	5571 3531 00	2	SHIM	SHIMS		
23	5571 3532 00	2	SHIM	SHIMS		
24	5571 3533 00	2	SHIM	SHIMS		
25	5571 3534 00	2	SHIM	SHIMS		
26	5571 4500 00	4	SHIM	SHIMS		
27	5530 5271 00	10	SET SCREW	STOPPSKRUV		SETSCR-ALN HD 3/4NC X 3/4
30	5531 0603 00	1	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 1 NC X 1 G8
31	5559 9239 00	1	WASHER	PLÅTBRICKA		



5573 6418 00

SWIVEL LOCK / MIDJELÅS
5573 6418 00

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5573 6587 00	1	LOCK	LÅS		
3	5571 6896 00	1	PIN	TAPP		
5	5572 0554 00	1	PIN	TAPP		
6	5535 2806 00	2	PIN	PINNE		PIN-Q/R 1/4 DIA X 3 LNG

POWER UNIT / KRAFTENHET
LIST OF CONTENTS


Part no Detaljnr	Description	Benämning	See page Se sida	Remarks Anmärkning
–	POWER UNIT	KRAFTENHET	63	
5575 5393 00	– DIESEL ENG.SET	– DIESELMOTORSATS	66	TIER 2
5575 5392 00	– – DIESEL ENGINE	– – DIESELMOTOR	69	
5574 3107 00	– AIR INLET	– LUFTINTAG	71	AIR INTAKE INST. STG-16
5574 4997 00	– – AIR CLEANING	– – LUFTRENING	73	
5540 0700 00	– – – AIR CLEANING	– – – LUFTRENING	75	
5575 7003 38	– EXHAUST SYSTEM	– AVGASSYSTEM	78	EXH INST-PURIF/SILEN, HI EXIT
5541 0324 00	– – PURIFIER	– – KATALYSATOR	81	
5541 6097 00	– – SILENCER	– – LJUDDÄMPARE	83	
5575 5837 00	– FUEL SYSTEM	– BRÄNSLESYSTEM	86	FUEL SYSTEM
5508 1914 00	– – HOSE LIST	– – SLANGLISTA	89	HOSE LIST
5575 4880 00	– – RADIATOR	– – KYLARE	91	FUEL COOLER FAN MODIFICATION
5541 3447 00	– – – COOLER	– – – KYLARE	93	FUEL COOLER
5540 5602 00	– – SEPARATOR	– – FILTER	95	
5575 5268 00	– COOLING SYSTEM	– KYLSYSTEM	97	
5508 1940 00	– – HOSE SET	– – SLANGSATS	101	
5541 4764 00	– – TRANSMISSION	– – TRANSMISSION	103	
5573 5595 00	– RADIATOR	– KYLARE	105	
5573 6480 00	– – RADIATOR	– – KYLARE	107	
–	– HYDR. SYSTEM	– HYDRAULSYSTEM	110	PLMG-HYD OIL FILL PUMP
5536 8661 00	– – FILTER	– – FILTER	113	
5574 9945 00	– FIRE SUPPR.SYST	– ELDBEKÄMPN.SYST	117	ANSUL
5536 2608 00	– – ANSUL SYSTEM	– – ANSUL SYSTEM	121	EXTINGUISHER & BRKT LTA101-30
5573 2468 00	– – SWITCH	– – OMKOPPLARE	123	SWITCH-PRES ASSY, 60 PSI DECRE
5573 8399 00	– FIRE EXTINGUIS.	– ELDSLÄCKARE	125	FIRE EXTING 10LB S50



POWER UNIT / KRAFTENHET

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5575 5393 00	1	DIESEL ENG.SET	DIESELMOTORSATS	Page 66	TIER 2
	5574 3107 00	1	AIR INLET	LUFTINTAG	Page 71	AIR INTAKE INST. STG-16
	5575 7003 38	1	EXHAUST SYSTEM	AVGASSYSTEM	Page 78	EXH INST-PURIF/SILEN, HI EXIT
	5575 5837 00	1	FUEL SYSTEM	BRÄNSLESYSTEM	Page 86	FUEL SYSTEM
	5575 5268 00	1	COOLING SYSTEM	KYLSYSTEM	Page 97	
	5573 5595 00	1	RADIATOR	KYLARE	Page 105	
	—	1	HYDR. SYSTEM	HYDRAULSYSTEM	Page 110	PLMG-HYD OIL FILL PUMP
	5574 9945 00	1	FIRE SUPPR.SYST	ELDBEKÄMPN.SYST	Page 117	ANSUL
	5573 8399 00	1	FIRE EXTINGUIS.	ELDSLÄCKARE	Page 125	FIRE EXTING 10LB S50

Fig. 1 of 2



SERIES 50.






Fig. 2 of 2




Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5575 5392 00	1	DIESEL ENGINE	DIESELMOTOR	Page 69	
2	5573 9713 00	2	ATTACHMENT	FÄSTE		
3	5573 6044 00	1	MOUNT	FÄSTE		
4	5541 0241 00	12	MOUNT	FÄSTE		
5	5572 5259 00	6	WASHER	BRICKA		
6	5530 8072 00	12	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 5/8 NC X 1-3/4
7	5559 9236 00	12	WASHER	PLÅTBRICKA		
8	5531 0831 00	6	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 1 NC X 6 G8
9	5559 9239 00	12	WASHER	PLÅTBRICKA		
10	5530 7241 00	6	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1 NC N
11	5530 8458 00	2	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/4 NC X 2-3/4
12	5559 9237 00	4	WASHER	PLÅTBRICKA		3/4 HT X 1.5 OD
13	5530 7356 00	2	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/4 NC N
14	5590 0001 54	1	ATTACHM. PLATE	FÄSTPLÅT		
15	0147 1326 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		M 8 X 30 - 8.8 FZB
16	0301 2335 00	4	PLAIN WASHER	RUNDBRICKA		8,4 / 16 X 1,6 -HB200 FZB
17	0291 1128 18	2	LOCK NUT	LÅSMUTTER		M 8 - 8 FZB / ISO 7040
18	5541 2171 00	1	FILLER COVER	PÅFYLLN.LOCK		FILLER CAP 1NPT THREADED
19	5574 8419 00	1	WELDMENT			
20	0268 4138 20	1	HEXAGON NUT	6-KANTMUTTER		UN 1 11/16 12 10,5 B 50 ?
21	0570 7017 08	1	NIPPLE	NIPPEL		B2 28 32 UN 42,86 1 11/16
22	5501 1848 00	1	NIPPLE	NIPPEL		E2 -----
101	5575 7008 09	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY




DIESEL ENGINE / DIESELMOTOR

5575 5392 00

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5575 7001 46	1	DIESEL ENGINE	DIESELMOTOR		
2	5541 3648 00	1	FAN	FLÄKT		
3	5574 1478 00	1	SPACER	DISTANS		
4	5540 8783 00	6	CAPSCREW	HUVUDSKRUV		CPSCR-12PT 3/8 NF X 2-1/4
5	5559 9232 00	6	WASHER	PLÅTBRICKA		3/8 HT
6	5535 0931 00	3	V-BELT	KILREM		
7	5573 6038 00	1	MOUNT	FÄSTE		
8	5573 6041 00	1	WELDMENT	WELDMENT		
9	5540 1125 00	1	WASHER	PLÅTBRICKA		WASHER-FLAT M10 HT PLTD
10	5541 0493 00	1	SCREW, HEX HEAD	SKRUV, SEXKANT		A M14 120 34 8,8 21 10.9
11	0333 2174 22	1	SPRING WASHER	FJÄDERBRICKA		A 14,2 M14 - 24,1 3 - -
12	5541 0457 00	2	SCREW, HEX HEAD	SKRUV, SEXKANT		A M10 120 26 6,4 16 10.9
13	5540 1125 00	2	WASHER	PLÅTBRICKA		WASHER-FLAT M10 HT PLTD
15	5541 0472 00	2	SHIELD	SKÖLD		
17	5531 0059 00	1	GREASE NIPPLE	FETTNIPPEL		GREASE FITTING-1/8X 90 LO
19	5535 5007 00	1	CLAMP	KLAMMA		
20	5534 5330 00	1	CLAMP	KLAMMA		CLAMP-HOSE (1.25 ID)
21	0570 7025 27	1	NIPPLE	NIPPEL		E 18-20 UN 1 3/16-12
22	0570 7009 04	1	NIPPLE	NIPPEL		A1 18-20 UN 1 3/16-12
23	0570 7000 10	1	CAP	HUV		B1 18-20 1 3/16-12
24	5570 4133 00	1	COUPLE	KOPPEL		
25	5570 4134 00	1	ADAPTER	ADAPTER		
26	5540 6719 00	1	GASKET	PACKNING		
27	5540 1110 00	5	CAPSCREW	HUVUDSKRUV		CPSCR-SKT M12 X 50 G8.8
28	5540 1141 00	1	RING	RING		SNAP RING-3/4ID
29	5580 0009 93	0.60M	HOSE	SLANG		
30	5575 5313 00	1	HOSE	SLANG		




Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5574 4997 00	1	AIR CLEANING	LUFTRENING	Page 73	
2	5574 3108 00	1	BRACKET	KONSOL		
3	5574 3110 00	1	PLATE	PLÅT		
4	0144 3288 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 32 - 8.8 FZB
5	5559 9232 00	14	WASHER	PLÅTBRICKA		3/8 HT
6	5530 7116 00	12	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
7	0144 3287 03	3	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 25 - 8.8 FZB
8	5574 3112 00	1	AIR INLET	LUFTINTAG		
9	5536 2785 00	4	CLAMP	KLAMMA		
10	5535 2447 00	1	RUBBER	GUMMI		
11	5535 5074 00	1	CAP	HUV		
12	5535 2442 00	1	FITTING	FÖRSKRUVNING		
13	5537 1136 00	1	CLAMP	KLAMMA		
14	5574 5277 00	1	INLET PORT	INSUGNINGSRÖR		
15	5534 6929 00	1	HOSE ASSEMBLY	SLANGLEDNING		346929
16	5535 0482 00	1	MOUNT	FÄSTE		
17	5535 3228 00	1	INDICATOR	INDIKATOR		INDICATOR-RESTRICTION (20')
18	5574 7652 00	1	HOSE	SLANG		
19	5536 2786 00	3	CLAMP	KLAMMA		
20	0144 3290 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 38 - 8.8 FZB
21	0144 3291 03	3	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 45 - 8.8 FZB
22	5574 3125 00	1	COVER	PLÅTHUV		
23	5112 2467 48	1	PLUG	PROPP		CLARK 40K-02
24	5500 4940 00	1	PIPE CONNECTION	RÖRANSLUTNING		CONNECTOR (PIPE/PIPE)



AIR CLEANING / LUFTRENING**5574 4997 00**

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5540 0700 00	1	AIR CLEANING	LUFTRENING	Page 75	
2	5535 2573 00	1	CAP	HUV		
3	5535 5426 00	1	VALVE	VENTIL		




AIR CLEANING / LUFTRENING

5540 0700 00


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5535 4889 00	1	COVER	KÅPA		
2	5534 6368 00	1	NUT	MUTTER		
4	5540 1085 00	1	NUT	MUTTER		
5	5534 6367 00	1	GASKET	PACKNING		
6	5536 2760 00	1	ELEMENT	ELEMENT		
7	5540 1086 00	1	ELEMENT	ELEMENT		
8	–	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
9	5535 4890 00	1	CLAMP	KLAMMA		
10	–	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
11	5532 8803 00	2	O-RING	O-RING		
12	5532 8743 00	1	CLAMP	KLAMMA		
13	5540 1089 00	1	CUP	YTTERRING		

Fig. 1 of 2



5575 7003 38

Fig. 2 of 2



5575 7003 38


(Sheet 1 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5573 5766 00	1	TUBE	RÖR		
2	5574 6442 00	1	PIPE	RÖR		
3	5541 0324 00	1	PURIFIER	KATALYSATOR	Page 81	
4	5541 6097 00	1	SILENCER	LJUDDÄMPARE	Page 83	
5	5541 3404 00	1	TOP PART	ÖVERDEL		
6	5540 2102 00	1	CLAMP	KLAMMA		
7	5535 0503 00	3	CLAMP	KLAMMA		
8	5501 8497 00	1	TUBE	RÖR		
9	5574 0971 00	2	BRACKET	KONSOL		
10	5537 5835 00	5	CLAMP	KLAMMA		
11	5531 0686 00	2	FLANGE NUT	FLÄNSMUTTER		NUT-FLG 3/8 NC (WIDE) G5
12	5559 9232 00	8	WASHER	PLÅTBRICKA		3/8 HT
13	5112 2467 47	2	SCREW	SKRUV		1C-624
14	0144 3288 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 32 - 8.8 FZB
15	5530 7116 00	2	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
16	5530 8687 00	2	PLUG	PROPP		PLUG-1/8NPT HEX HD.(BRASS
19	5590 0001 50	1	EXHAUST COVER	LJUDDÄMPARSKYDD		
20	5573 6512 00	1	MOUNT	FÄSTE		
21	5573 6510 00	2	MOUNT	FÄSTE		
23	5590 0001 45	1	EXHAUST COVER	LJUDDÄMPARSKYDD		
24	5590 0001 53	1	ATTACHM. PLATE	FÄSTPLÅT		
25	5573 8092 00	2	MOUNT	FÄSTE		
26	5574 8352 00	1	GUARD	SKYDD		
27	5574 8351 00	1	TUBE	RÖR		
28	5535 9158 00	6	FLANGE SCREW	FLÄNSSKRUV		CPSCR-FLG W 5/16NC X 3/4
30	5541 3641 00	6	NUT	MUTTER		NUT-CAGED 5/16 NC
31	5541 3641 00	6	NUT	MUTTER		NUT-CAGED 5/16 NC
32	5537 3877 00	2	CLAMP	KLAMMER		
33	5537 3878 00	2	GASKET	PACKNING		
34	5541 4666 00	1	EXHAUST	AVGASSYSTEM		
35	5531 0673 00	6	FLANGE SCREW	FLÄNSSKRUV		CPSCR-FLG W 5/16NC X 1 G5
36	0147 1363 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		M 10 X 30 - 8.8 FZB

EXHAUST SYSTEM / AVGASSYSTEM**5575 7003 38**


(Sheet 2 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
37	0301 2344 00	11	PLAIN WASHER	RUNDBRICKA		10,5 / 20 X 2 -HB 200 FZB 10,5 / 20 X 2 -HB 200 FZB
38	0291 1128 20	5	LOCK NUT	LÅSMUTTER		M 10 - 8 FZB / ISO 7040
39	0147 1364 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		M 10 X 35 - 8.8 FZB
44	5575 7008 49	1	PLATE	PLÅT		



PURIFIER / KATALYSATOR**5541 0324 00**


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5537 8163 00	1	BODY	RAM		
2	5537 5547 00	1	CONE	KONA		
2	5537 5548 00	1	CONE	KONA		
3	5537 3877 00	1	CLAMP	KLAMMER		
4	5537 3878 00	1	GASKET	PACKNING		
5	5537 3879 00	1	PLUG	PROPP		
6	5541 7087 00	1	NUT	MUTTER		
7	5537 8114 00	1	BOLT	BULT		



SILENCER / LJUDDÄMPARE**5541 6097 00**


Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5537 3877 00	2	CLAMP	KLAMMER		
2	5537 3878 00	2	GASKET	PACKNING		

Fig. 1 of 2



5575 5837 00 1/2 ed 05

Fig. 2 of 2




(Sheet 1 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5508 1914 00	1	HOSE LIST	SLANGLISTA	Page 89	HOSE LIST
1	5575 4880 00	1	RADIATOR	KYLARE	Page 91	FUEL COOLER FAN MODIFICATION
3	0570 7025 22	1	NIPPLE	NIPPEL		E 14-16 UNS 1 -14
4	5507 1571 00	1	NIPPLE	NIPPEL		ELBOW-45 (ORS/PIPE)
5	3455 0400 02	1	PLUG	PLUGG		F 10 NPTF 1/4 - 14,2 18,8
6	5500 7577 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/PIPE)
7	5500 7884 00	2	PLUG	PROPP		PLUG-INV (O-RING)
8	5505 1112 00	1	NIPPLE	NIPPEL		ELBOW-90 (PIPE/PIPE)
9	0570 7041 27	1	ELBOW NIPPLE	VINKELNIPPEL		B2 12 - UNF 20,64 13/16 1
11	0570 7025 11	1	NIPPLE	NIPPEL		B1 14-16 UNS 1 -14
12	0570 7041 25	1	NIPPLE	NIPPEL		E 8-10 UNF 11/16-16
13	3176 7868 07	1	PLUG	PROPP		
14	5500 7577 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/PIPE)
20	5500 7577 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/PIPE)
21	5533 6438 00	1	VALVE	VENTIL		VALVE-ON/OFF, INLINE, BAL
27	5530 7116 00	4	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
29	5540 5602 00	1	SEPARATOR	FILTER	Page 95	
30	5580 0009 37	0.80M	HOSE	SLANG		
31	5500 7285 00	1	NIPPLE	NIPPEL		ELBOW-90 (PIPE/PIPE)
32	5500 5092 00	1	BUSHING	BUSSNING		BUSHING (O-RING/PIPE)
33	3176 7868 06	2	PLUG	PROPP		3/4-16 UNF, TYPE A,STEEL
35	5500 7577 00	2	NIPPLE	NIPPEL		ELBOW-90 (ORS/PIPE)
36	5501 1837 00	1	NIPPLE	NIPPEL		ELBOW-45 (ORS/O-RING)
37	5500 7883 00	1	PLUG	PROPP		PLUG-INV (O-RING)
38	3455 0400 04	2	PLUG	PROPP		F 15 NPTF 1/2 - 19 24,4 2
39	5573 6804 00	1	GUARD	SKYDD		
40	5536 3858 00	1	CLAMP	KLAMMA		
41	5559 9232 00	24	WASHER	PLÅTBRICKA		3/8 HT
42	5530 7116 00	8	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
43	0144 3287 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 25 - 8.8 FZB
46	0144 3290 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 38 - 8.8 FZB
47	5541 0429 00	4	RUBBER DAMPER	GUMMIDÄMPARE		

FUEL SYSTEM / BRÄNSLESYSTEM**5575 5837 00**

(Sheet 2 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
48	5580 0012 50	0.91M	SEAL	TÄTNING		
49	5534 7657 00	4	WASHER	PLÅTBRICKA		
53	0144 3291 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 45 - 8.8 FZB
55	5542 1111 00	1	FILTER GAUGE	FILTERHÅLLARE		
56	5540 8625 00	1	FUEL FILTER	BRÄNSLEFILTER		COMPLETE FUEL FILTER
57	5575 7003 62	1	MOUNT	FÄSTE		
58	0147 1369 03	1	SCREW, HEX HEAD	SKRUV, SEXKANT		M 10 X 60 - 8.8 FZB M 10 X 60 - 8.8 FZB
59	0147 1367 03	1	SCREW, HEX HEAD	SKRUV, SEXKANT		M 10 X 50 - 8.8 FZB
60	0147 1362 03	1	SCREW, HEX HEAD	SKRUV, SEXKANT		M 10 X 25 - 8.8 FZB M 10 X 25 - 8.8 FZB
61	0301 2344 00	3	PLAIN WASHER	RUNDBRICKA		10,5 / 20 X 2 -HB 200 FZB 10,5 / 20 X 2 -HB 200 FZB
62	3176 0577 00	1	PLUG	PROPP		




HOSE LIST / SLANGLISTA

5508 1914 00

HOSE LIST

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
101	0574 2253 16	1	HOSE ASSEMBLY	SLANGLEDNING		16 4826 I-I 105 UNS 1-14
102	5507 1607 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
103	5506 3063 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
104	5575 7003 59	1	HOSE ASSEMBLY	SLANGLEDNING		MT2000
105	5575 7003 60	1	HOSE ASSEMBLY	SLANGLEDNING		1C00093HGG1070A
106	5507 6422 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY




5575 4880 00

RADIATOR / KYLARE

5575 4880 00

FUEL COOLER FAN MODIFICATION

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5541 3447 00	1	COOLER	KYLARE	Page 93	FUEL COOLER
2	5541 0272 00	1	CONNECTOR	KONTAKTDON		CONN. PLUG 2-SOCKET DT SERIES
3	5541 0273 00	1	CONNECTOR LOCK	KONTAKTLÅS		CONN. LOCK 2-SOCKET DT SERIES
4	5541 0368 00	1	BOOT	BOOT		
5	5540 8598 00	2	CABLE LUG	KABELSKO		TERM-SOCK
6	5540 9511 00	2	CABLE TIES	BUNTBAND		CABLE TIE




COOLER / KYLARE

5541 3447 00

FUEL COOLER


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5541 4694 00	1	COOLER	KYLARE		
2	5541 4695 00	4	NUT	MUTTER		
3	5541 4698 00	4	WASHER	BRICKA		
4	5541 4699 00	1	FAN	FLÄKT		
5	5541 4700 00	1	FAN	FLÄKT		
6	5541 4701 00	3	SPACER	DISTANS		
7	5541 4702 00	3	CAPSCREW	HUVUDSKRUV		
8	5541 4703 00	1	MOTOR	MOTOR		
9	5541 4704 00	4	CAPSCREW	HUVUDSKRUV		
10	5541 4705 00	4	WASHER	BRICKA		



SEPARATOR / FILTER

5540 5602 00

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
0	5540 6118 00	1	SEAL KIT	TÄTNINGSSATS		
1	5540 6478 00	1	SEAL KIT	TÄTNINGSSATS		
2	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
3	5540 6117 00	1	ELEMENT	ELEMENT		
4	5540 6479 00	1	COLLECTOR	UPPSAMLARE		



5575 5268 00 ed.02

COOLING SYSTEM / KYLSYSTEM

5575 5268 00


(Sheet 1 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
0	5508 1940 00	1	HOSE SET	SLANGSATS	Page 101	
1	5573 6223 00	1	TUBE	RÖR		
2	5573 6224 00	1	TUBE	RÖR		
3	5573 6225 00	1	TUBE	RÖR		
4	5573 6226 00	1	TUBE	RÖR		
5	5575 5931 00	1	TUBE	RÖR		
6	5573 6228 00	1	TUBE	RÖR		
7	5571 5246 00	1	HOSE	SLANG		
8	5580 0009 37	1.60M	HOSE	SLANG		
9	5536 3858 00	1	CLAMP	KLAMMA		
10	5570 9641 00	3	HOSE	SLANG		
11	5540 8178 00	3	CLAMP	KLAMMA		CLAMP-TBOLT 2.625 - 3.12
12	5571 0790 00	2	HOSE	SLANG		
13	5535 8426 00	2	CLAMP	KLAMMA		CLAMP-TBOLT 3.00 - 3.25
14	5540 0995 00	2	HOSE	SLANG		
15	5540 0996 00	8	CLAMP	KLAMMA		
16	5573 5467 00	2	HOSE	SLANG		
17	5561 6328 00	1	HOSE	SLANG		
18	5575 4091 00	1	HOSE	SLANG		
20	5500 2167 00	4	NIPPLE	NIPPEL		ELBOW-90 (ORS/PIPE)
21	3176 6540 00	1	NIPPLE	NIPPEL		UN 1 5/16 - NPTF 1
22	3176 1672 00	1	NIPPLE	NIPPEL		UN 1 5/16 - NPTF 1
23	5506 2845 00	1	PIPE CONNECTION	RÖRANSLUTNING		CONNECTOR (ORS/PIPE)
24	5500 7580 00	1	NIPPLE	NIPPEL		ELBOW-45 (ORS/O-RING)
25	3176 0577 00	2	PLUG	PROPP		
30	5541 4764 00	1	TRANSMISSION	TRANSMISSION	Page 103	
32	5573 6481 00	1	TANK	TANK		
33	0144 3288 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 32 - 8.8 FZB
34	5559 9232 00	16	WASHER	PLÅTBRICKA		3/8 HT
35	5530 7116 00	8	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
37	5530 5056 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 2-1/4
38	5574 4802 00	2	SPACER	DISTANS		

COOLING SYSTEM / KYLSYSTEM
5575 5268 00

(Sheet 2 of 2)


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
39	5534 5551 00	1	GAUGE	MÄTINSTRUMENT		SIGHT GAUGE
41	5501 1810 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/ORS) BULKHE
42	0570 7000 09	1	CAP	HUV		B1 8-10 11/16-16
43	0570 7025 21	1	NIPPLE	NIPPEL		E 8-10 UNF 11/16-16
44	5112 2467 48	2	PLUG	PROPP		CLARK 40K-02
45	0347 6100 21	16	HOSE CLIP	SLANGKLÄMMA		B 70 92 15,8 - - - -
46	0147 1358 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		M 10 X 14 - 8.8 FZB
47	0301 2344 00	2	PLAIN WASHER	RUNDBRICKA		10,5 / 20 X 2 -HB 200 FZB 10,5 / 20 X 2 -HB 200 FZB
48	5590 0003 61	1	ATTACHMENT	FÄSTE		



HOSE SET / SLANGSATS


5508 1940 00

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
101	5501 4248 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
102	5507 4234 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
103	5504 6603 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
104	5503 9644 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
105	5501 4417 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY



TRANSMISSION / TRANSMISSION**5541 4764 00**


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5541 5364 00	1	TUBE	RÖR		
2	5541 5365 00	2	CROSS	KORS		
3	5541 5366 00	2	GASKET	PACKNING		
4	5541 5367 00	2	CROSS	KORS		
5	5541 5368 00	8	WASHER	BRICKA		
6	5541 5369 00	8	WASHER	BRICKA		



RADIATOR / KYLARE

5573 5595 00

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5573 6480 00	1	RADIATOR	KYLARE	Page 107	
3	5572 5387 00	1	MOUNT	FÄSTE		
4	5572 5385 00	1	MOUNT	FÄSTE		
5	5572 2780 00	1	BUSHING	BUSSNING		
6	5530 8517 00	3	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 5/8 NC X 1-1/2
7	5530 7033 00	3	LOCK WASHER	LÅSBRICKA		WASHER-LOCK 5/8 SPLIT TYP
8	5559 9236 00	3	WASHER	PLÅTBRICKA		
9	5530 8472 00	1	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 1 NC X 2-1/2 G8
10	5559 9239 00	1	WASHER	PLÅTBRICKA		
11	0144 3362 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 25 - 8.8 FZB
13	5530 6119 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 1/2 NC X 1-3/4
14	5530 7551 00	4	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1/2 NC N
19	5559 9234 00	12	WASHER	PLÅTBRICKA		1/2 HT
27	5572 2781 00	1	INSERT	INSATS		
28	5573 6487 00	1	RUBBERMOULDING	GUMMILIST		
29	5573 6488 00	1	RUBBERMOULDING	GUMMILIST		
30	0144 3207 03	15	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/4 X 22 - 8.8 FZB
31	5559 9230 00	15	WASHER	PLÅTBRICKA		1/4 HT
32	5530 7055 00	15	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1/4 NC NE
33	5574 1048 00	1	RUBBERMOULDING	GUMMILIST		




RADIATOR / KYLARE

5573 6480 00


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5541 4713 00	1	SEAL	TÄTNING		
2	5541 4706 00	2	SUPPORT	STÖD		
3	5541 4707 00	93	TUBE	RÖR		
3	5541 4971 00	93	GROMMET	GENOMFÖRING		
3	5541 4972 00	93	GROMMET	GENOMFÖRING		
4	5541 4708 00	123	TUBE	RÖR		
5	5541 4709 00	1	SHROUD	SKÖLD		
6	5541 4710 00	1	FAN	FLÄKT		
7	5541 4711 00	8	FLANGE SCREW	FLÄNSSKRUV		
8	5541 4711 00	8	FLANGE SCREW	FLÄNSSKRUV		
9	5541 4712 00	1	GUARD	SKYDD		

Fig. 1 of 2




5590 0026 85_1/2

Fig. 2 of 2




HYDR. SYSTEM / HYDRAULSYSTEM

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	3176 7467 01	1	PUMP	PUMP	Page 113	
2	5536 8661 00	1	FILTER	FILTER		
3	5590 0025 94	1	MOUNT	FÄSTE		
4	0147 1365 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		M 10 X 40 - 8.8 FZB
5	0291 1128 20	4	LOCK NUT	LÅSMUTTER		M 10 - 8 FZB / ISO 7040
6	0301 2344 00	8	PLAIN WASHER	RUNDBRICKA		10,5 / 20 X 2 -HB 200 FZB 10,5 / 20 X 2 -HB 200 FZB
7	0144 3206 03	2	HEXAGON SCREW	SEKKANTSSKRUV		UNC 1/4 - 19 12,8 H 4 11,
8	5559 9230 00	2	WASHER	PLÅTBRICKA		1/4 HT
9	0147 1364 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		M 10 X 35 - 8.8 FZB
10	5501 1727 00	1	CAP	HUV		COUPLER-DUST CAP
11	5501 1722 00	1	QUICK COUPLING	SNABBKOPPLING		FD45-1002-08-10
12	5500 2165 00	1	PIPE CONNECTION	RÖRANSLUTNING		CONNECTOR (ORS/PIPE)
13	5590 0025 93	1	PIPE CONNECTION	RÖRANSLUTNING		
14	5500 2176 00	1	NIPPLE	NIPPEL		ELBOW-45 (ORS/O-RING)
15	5590 0025 78	2	ADAPTER	ÖVERGÅNG		
16	5500 2155 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/O-RING)
17	0570 7009 02	1	NIPPLE	NIPPEL		A1 12 UNF 13/16-16
18	5501 1816 00	1	PIPE CONNECTION	RÖRANSLUTNING		CONNECTOR (ORS/PIPE)
19	5500 4911 00	1	BUSHING	BUSSNING		BUSHING (PIPE/PIPE)
20	5505 6286 00	1	BUSHING	BUSSNING		
21	5540 6126 00	1	VALVE	VENTIL		VALVE-CHECK
22	5507 7567 00	1	WAGNER PART	WAGNER ARTIKEL		
23	0570 7000 16	1	PLUG	PLUGG		C 18-20 UN 1 3/16-12
24	3176 3681 00	2	STRAP	BAGAGEBAND		
25	0570 7025 51	1	STRAIGHT NIPPLE	RAK NIPPEL		E - - UN 1 3/16-12 NPTF 1
26	5501 1725 00	1	QUICK COUPLING	SNABBKOPPLING		COUPLER-QUICK DISCONNECT
27	5501 1731 00	1	COUPLE	KOPPEL		COUPLER-DUST PLUG
101	5501 4370 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
102	5505 8456 00	1	HOSE ASSEMBLY	SLANGLEDNING		1C00134HHH0180A
103	5501 4447 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
104	5507 8168 00	1	HOSE ASSEMBLY	SLANGLEDNING		1C03669KKK0900A



Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
2	5534 2799 00	1	ELEMENT	ELEMENT		
4	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
5	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.

Fig. 1 of 3



5574 9945 00 1/5 ed.05

Fig. 2 of 3






Fig. 3 of 3




5574 9945 00 4/4 ed.05

(Sheet 1 of 2)


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	0570 5090 01	5	NIPPLE	NIPPEL		UNF 7/16 - NPTF 1/4
2	5500 4968 00	1	NIPPLE	NIPPEL		ELBOW-90 (PIPE/PIPE)
3	5500 5125 00	1	TEE	T-RÖR		TEE-BRNCH (PIPE/PIPE/PIPE)
4	3177 3063 00	1	NIPPLE	NIPPEL		UNF 7/16 - NPTF 1/4
5	3176 6573 00	1	NIPPLE	NIPPEL		UN 1 1/16 - NPTF 3/4
6	3176 1949 00	1	NIPPLE	NIPPEL		UNF 3/4 - NPTF 1/2
7	3176 2786 00	4	NIPPLE	NIPPEL		UNF 3/4 - NPTF 1/2
8	5500 4972 00	2	NIPPLE	NIPPEL		ELBOW-90 (PIPE/PIPE)
9	5537 1906 00	4	NOZZLE	MUNSTYCKE		
11	5537 8455 00	1	TEE	T-RÖR		
12	5536 2809 00	2	U-BOLT	U-BULT		U-BOLT W/NUTS
14	5112 2392 41	8	SCREW	SKRUV		
15	5530 7027 00	8	LOCK WASHER	LÅSBRICKA		WASHER-LOCK 5/16 SPLIT TY
17	5501 5349 00	1	NIPPLE	NIPPEL		ELBOW-45 (PIPE/PIPE)
18	3176 6573 00	1	NIPPLE	NIPPEL		UN 1 1/16 - NPTF 3/4
19	5500 4638 00	3	NIPPLE	NIPPEL		ELBOW-45 (PIPE/JIC)
20	5536 2608 00	1	ANSUL SYSTEM	ANSUL SYSTEM	Page 121	EXTINGUISHER & BRKT LTA101-30
21	5572 5294 00	2	LABEL	DEKAL		LABEL ISO-FIRE SUPPR INSTR
22	5537 0013 00	2	BRACKET	KONSOL		
23	5537 0095 00	2	TRIGGER	UTLÖSARE		REMOTE ACTUATOR
24	5541 9856 00	2	CARTRIDGE	PATRON		
25	5537 0239 00	2	VALVE	VENTIL		CHECK VALVE
26	5533 2168 00	1	VALVE	VENTIL		RELIEF VALVE
27	0144 3284 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 16 - 8.8 FZB
29	5112 2392 40	4	LOCK WASHER	LÅSBRICKA		
30	0144 3287 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 25 - 8.8 FZB
31	5559 9232 00	10	WASHER	PLÅTBRICKA		3/8 HT
32	5574 5717 00	1	COVER	KÅPA		
33	5530 7116 00	7	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
34	0144 3248 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 5/16 X 25 - 8.8 FZB
35	5530 7552 00	4	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 5/16NC N
36	5559 9231 00	8	WASHER	PLÅTBRICKA		5/16 HT

(Sheet 2 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
38	5530 8645 00	3	SCREW, HEX HEAD	SKRUV, SEXKANT	Page 123	CPSCR-HEX 3/8 NC X 1-1/4
39	5573 2468 00	1	SWITCH	OMKOPPLARE		SWITCH-PRES ASSY, 60 PSI DECRE
42	5500 4988 00	1	TEE	T-RÖR		TEE-RUN (PIPE/PIPE/PIPE)
43	3217 9316 25	2	SEAL	PLOMB		
51	5500 7904 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
52	5501 3136 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
53	5500 8625 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
54	5541 6638 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
55	5500 8186 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
56	5507 3138 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
57	5501 3260 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
58	5500 8186 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY



Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5540 8347 00	1	FIRE EXTINGUIS.	ELDSLÄCKARE		INCLUDES ITEMS 1 AND 2.
2	3217 9316 42	1	ATTACHMENT	FÄSTE		LT-A-101-30
3	5535 8979 00	1	CARTRIDGE	PATRON		CARTRIDGE-EXTINGUISH LTA10130
4	5535 8980 00	1	CARTRIDGE	PATRON		BRACKET-CARTRIDGE LTA101-30
5	5541 3127 00	1	ACTUATOR	VRIDMOTOR		ACTUATOR ASSEMBLY




5573 2468 00 - 004

SWITCH / OMKOPPLARE

5573 2468 00

SWITCH-PRES ASSY, 60 PSI DECRE

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5541 9492 00	1	PRESSURE SWITCH	TRYCKVAKT		PRESSURE SWITCH 60 PSI FS
2	5541 0286 00	1	CONNECTOR	KONTAKTDON		CONN. RECEPT. 3 PIN DT SERIES
3	5541 0288 00	1	CONNECTOR LOCK	KONTAKTLÅS		CONN. LOCK 3 PIN DT SERIES
4	5540 4555 00	3	CABLE LUG	KABELSKO		TERM-PIN
5	5541 0369 00	1	BOOT	BOOT		BOOT-DT 3-POS RECEPT. DEUTSCH



FIRE EXTINGUIS. / ELDSLÄCKARE

5573 8399 00

FIRE EXTING 10LB S50

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5537 1198 00	1	FIRE EXTINGUIS.	ELDSLÄCKARE		
2	5537 1199 00	1	MOUNT	FÄSTE		
3	0144 3248 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 5/16 X 25 - 8.8 FZB
4	5559 9231 00	8	WASHER	PLÅTBRICKA		5/16 HT
6	5530 7552 00	4	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 5/16NC N
7	5558 9017 00	4	SPACER	DISTANS		

POWERTRAIN / DRIVLINA
LIST OF CONTENTS


Part no Detaljnr	Description	Benämning	See page Se sida	Remarks Anmärkning
–	POWERTRAIN	DRIVLINA	131	
5574 4803 00	– FRONT AXLE	– FRAMAXEL	133	
5571 5542 00	-- AXLE	-- HJULAXEL	135	
5571 3537 00	--- SHAFT	--- AXEL	137	
5541 4490 00	---- CARRIER	---- BÄRARE	141	DIFF & CARRIER
5574 4996 00	– REAR AXLE	– BAKAXEL	145	
5571 5542 00	-- AXLE	-- HJULAXEL	135	
5571 3537 00	--- SHAFT	--- AXEL	137	
5541 4490 00	---- CARRIER	---- BÄRARE	141	DIFF & CARRIER
5574 0335 00	– DRIVELINE	– DRIVLINA	148	
5574 0443 00	-- DRIVELINE	-- DRIVLINA	151	TRANS-CONV DRIVELINE
5575 7003 78	-- DRIVELINE	-- DRIVLINA	153	MIDSHIP
5575 7003 77	-- DRIVELINE	-- DRIVLINA	155	CHASSIS DRIVE LINE
5574 0382 00	-- DRIVELINE	-- DRIVLINA	157	REAR DRIVE LINE
5559 9987 00	-- DRIVELINE	-- DRIVLINA	159	TRANSM. - ENGINE AXLE
5574 0446 00	-- COVER	-- KÅPA	161	COVER ASSY- D'LINE 18.00/457
5574 4772 00	– HYDR. SYSTEM	– HYDRAULSYSTEM	165	TRANSM./CONVERTER
5540 8945 00	-- FILTER	-- FILTER	169	FILTER-SPIN ON HYD
5574 7219 00	– HYDR. SYSTEM	– HYDRAULSYSTEM	172	PLMG-ELECTRIC SHIFT SYS, DDEC
5537 8911 00	-- VALVE	-- VENTIL	175	
5112 2467 45	--- SOLENOID VALVE	--- MAGNETVENTIL	177	
5540 0829 00	--- VALVE	--- VENTIL	179	LOCK-UP & MODULATOR
5537 8630 00	-- SOLENOID	-- MAGNETSPOLE	181	
5565 1702 00	-- ACCUMULATOR	-- ACKUMULATOR	183	
5540 7348 00	-- CHECK VALVE	-- BACKVENTIL	185	CHECK VALVE W/FIXED ORIFICE
5573 5599 00	– TRANSMISSION	– TRANSMISSION	187	TRANS INST-SERIES 50
5573 6541 00	-- TRANSMISSION	-- TRANSMISSION	189	MOD-CLARK 5000 SERIES TRANS

Part no Detaljnr	Description	Benämning	See page Se sida	Remarks Anmärkning
5570 5608 00	--- TRANSMISSION	--- TRANSMISSION	191	TRANSMISSION SPEC- 5421-184
5541 7531 00	---- CONTROL	---- REGLAGE	199	
5570 5608 73	---- CASE	---- HÖLJE	203	
5570 5608 74	---- TRANSM.SPEC	---- TRANSM.SPEC	205	
5540 0035 00	----- HUB	----- NAV	207	FWD, REV, 3RD, 4TH CLUTCH GRP.
5570 5608 75	---- TRANSM.SPEC	---- TRANSM.SPEC	209	
5537 3610 00	---- VALVE	---- VENTIL	211	CONTROL VALVE
5573 5600 00	- CONVERTER	- OMVANDLARE	215	
5573 6031 00	-- CONVERTER	-- OMVANDLARE	217	
5533 4107 00	--- PISTON	--- KOLV	223	16.00-25
5590 0001 42	- SET OF WHEELS	- HJULSATS	225	
5590 0001 38	-- WHEEL COMPL.	-- HJUL KOMPL.	227	
5571 3470 00	--- RIM	--- FÄLG	229	



POWERTRAIN / DRIVLINA

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5574 4803 00	1	FRONT AXLE	FRAMAXEL	Page 133	
	5574 4996 00	1	REAR AXLE	BAKAXEL	Page 145	
	5574 0335 00	1	DRIVELINE	DRIVLINA	Page 148	
	5574 4772 00	1	HYDR. SYSTEM	HYDRAULSYSTEM	Page 165	TRANSM./CONVERTER
	5574 7219 00	1	HYDR. SYSTEM	HYDRAULSYSTEM	Page 172	PLMG-ELECTRIC SHIFT SYS, DDEC
	5573 5599 00	1	TRANSMISSION	TRANSMISSION	Page 187	TRANS INST-SERIES 50
	5573 5600 00	1	CONVERTER	OMVANDLARE	Page 215	
	5590 0001 42	1	SET OF WHEELS	HJULSATS	Page 225	16.00-25




5574 4803 00 ed.00

FRONT AXLE / FRAMAXEL


5574 4803 00

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5571 5542 00	1	AXLE	HJULAXEL	Page 135	
2	5574 4766 00	1	PENDULUMHOUSING	PENDELINBYGGNAD		
3	5563 6449 00	2	PLATE	PLÅT		
6	5556 9699 00	2	COVER	KÅPA		
7	5530 9821 00	8	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 1-1/4 NC X 14 G
8	5530 9234 00	8	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 1 NC X 2-1/4 G8
9	5531 0199 00	8	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 1 G8
10	5531 0800 00	8	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1- 1/4 NC
11	5559 9239 00	8	WASHER	PLÅTBRICKA		
12	5112 2392 40	8	LOCK WASHER	LÅSBRICKA		
14	5559 9241 00	16	WASHER	PLÅTBRICKA		



AXLE / HJULAXEL**5571 5542 00**

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5571 3537 00	1	SHAFT	AXEL	Page 137	
2	5537 8776 00	1	FLANGE	FLÄNS		



SHAFT / AXEL

5571 3537 00

(Sheet 1 of 3)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
210	5540 6265 00	1	HOUSING	HUS		
310	5540 7522 00	2	PLUG	PROPP		
330	–	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
410	5540 5894 00	1	BREATHER	VENTILATION		
510	5540 7523 00	1	AXLE SHAFT	AXLE SHAFT		
520	5540 7524 00	1	AXLE SHAFT	AXLE SHAFT		
610	5541 7604 00	2	BRAKE UNIT	BROMSENHET		
710	5540 9283 00	1	HOUSING	HUS		
810	5541 5377 00	1	CAP	HUV		
910	5540 5897 00	7	PLUG	PROPP		
930	–	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
1010	5540 5895 00	2	PLUG	PROPP		
1030	5537 8847 00	1	O-RING	O-RING		
1110	5537 8847 00	4	O-RING	O-RING		
1210	5540 7522 00	1	PLUG	PROPP		
1230	–	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
1310	5541 1136 00	1	COVER	KÅPA		
1320	5540 0577 00	1	O-RING	O-RING		O-RING
1330	5540 0586 00	1	O-RING	O-RING		
1340	5540 0587 00	44	SPRING	FJÄDER		
1350	5540 0589 00	18	BOLT	BULT		
1360	5540 0595 00	18	WASHER	BRICKA		
1370	5540 4756 00	3	SPRING	FJÄDER		
1380	5537 8853 00	1	BREATHER	VENTILATION		
1390	5537 8854 00	1	CAP	HUV		
1400	5540 0591 00	1	PISTON	KOLV		
1510	5541 5378 00	1	CAP	HUV		
1610	5540 9912 00	4	PLATE	PLÅT		
1620	5540 9913 00	5	STATOR	STATOR		
1630	5540 5898 00	1	COVER	KÅPA		
1640	5540 0588 00	18	BOLT	BULT		
1650	5540 0595 00	18	WASHER	BRICKA		

SHAFT / AXEL

5571 3537 00


(Sheet 2 of 3)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1810	5541 4490 00	1	CARRIER	BÄRARE	Page 141	DIFF & CARRIER
3090	5542 0224 00	2	KIT	SATS		
3610	5540 3824 00	12	BOLT	BULT		
3620	5540 3825 00	2	BOLT	BULT		
3630	0333 2174 34	16	SPRING WASHER	FJÄDERBRICKA		A 14,2 M14 - 24,1 2,25 2,
3640	5537 8780 00	2	PIN	TAPP		
3650	5540 5913 00	2	BOLT	BULT		
3660	5540 5914 00	2	NUT	MUTTER		NUT
3710	5541 7731 00	2	HUB	NAV		
3720	5540 1014 00	16	BOLT	BULT		BOLT
3730	5540 8710 00	2	SEAL RING	TÄTN.RING		
3810	5541 3414 00	2	SEAL KIT	TÄTNINGSSATS		
3910	5540 2674 00	2	SPINDLE	SPINDEL		
3920	5540 0018 00	40	BOLT	BULT		
3930	5540 0628 00	4	DOWEL PIN	DUBBPINNE		
3940	5540 9278 00	2	CROSS	KORS		
3950	5540 5905 00	2	NUT	MUTTER		
3960	5540 5902 00	2	PLATE	PLÅT		
3970	5540 5903 00	4	BOLT	BULT		
4010	5540 9598 00	2	WASHER	BRICKA		
4020	5540 3821 00	2	SHAFT	AXEL		
4210	5540 9389 00	2	KIT	SATS		
4310	5540 5908 00	1	PLATE	PLÅT		
4320	5540 2676 00	3	PLANET GEAR	PLANETVÄXEL		
4330	5540 2677 00	6	BEARING	LAGER		
4340	5540 1010 00	6	WASHER	BRICKA		
4350	5540 5909 00	3	PLATE	PLÅT		
4360	5540 1013 00	3	SET SCREW	STOPPSKRUV		
4410	5540 7522 00	1	PLUG	PROPP		
4610	5540 7531 00	2	O-RING	O-RING		
4620	5541 7613 00	46	STUD	PINNBULT		
4630	5540 8367 00	2	THRUST WASHER	AXIALBRICKA		

SHAFT / AXEL**5571 3537 00**

(Sheet 3 of 3)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
4710	5540 2679 00	2	GEAR RING	KUGGKRANS		
4720	5540 2680 00	2	GEAR	VÄXEL		
4730	5540 5901 00	2	GEAR RING	KUGGKRANS		
4740	5540 0025 00	2	RETAINING RING	SPÄRRYTTARE		
4750	5540 2681 00	2	BEARING	LAGER		
4765	5541 5698 00	2	BEARING	LAGER		
4810	5541 7614 00	2	COVER	KÅPA		
4820	5540 1016 00	16	BOLT	BULT		
4830	5540 7531 00	2	O-RING	O-RING		



5541 4490 00


(Sheet 1 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1910	5540 5912 00	1	CARRIER	BÄRARE		
1920	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
1930	—	2	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
1940	5537 8786 00	4	CAP	HUV		
2010	5540 3833 00	1	BEARING	LAGER		
2020	5540 3832 00	1	LOCK RING	LÅSRING		
2030	5540 2661 00	2	BEARING	LAGER		
2040	5540 3831 00	4	LOCK PLATE	LÅSPLATTA		
2050	5540 4130 00	2	ADJUSTING NUT	JUSTERMUTTER		
2060	5537 8781 00	2	LOCK	LÅS		
2070	5537 8782 00	2	PLATE	PLÅT		
2080	0147 1362 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		M 10 X 25 - 8.8 FZB M 10 X 25 - 8.8 FZB
2110	5540 2662 00	1	GEAR	VÄXEL		
2120	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
2130	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
2210	5540 3826 00	12	BOLT	BULT		
2220	5540 3834 00	1	RETAINER	FASTHÅLLARE		
2310	5540 2663 00	1	SHIMS SET	SHIMSSATS		
2410	5540 2688 00	1	BEARING	LAGER		
2420	5540 0573 00	1	BEARING	LAGER		
2430	5537 8791 00	1	OIL SEPARAT.	OLJEAVSKILJARE		
2440	5540 2664 00	1	DUST COVER	DAMMSKYDDSKÅPA		
2450	5540 3836 00	1	SEAL	TÄTNING		
2460	5540 2666 00	1	COLLAR	KRAGE		
2470	5537 8735 00	8	BOLT	BULT		
	5542 0224 00	1	KIT	SATS		
2480	0333 2174 34	8	SPRING WASHER	FJÄDERBRICKA		A 14,2 M14 - 24,1 2,25 2,
2510	5540 2667 00	1	FLANGE	FLÄNS		
2520	5537 8794 00	1	NUT	MUTTER		
2530	5537 8795 00	1	WASHER	BRICKA		
2540	5537 8137 00	1	DETAILS	DETALJER		

CARRIER / BÄRARE**5541 4490 00**

(Sheet 2 of 2)


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
2610	5540 3835 00	1	KIT	SATS		
2910	5540 3827 00	1	CASE	KAPSEL		
2920	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
3010	5540 3828 00	8	BOLT	BULT		
3020	5540 3844 00	12	NUT	MUTTER		
3030	5540 3843 00	4	BOLT	BULT		
3040	—	2	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
3050	—	2	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
3060	—	4	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
3070	—	4	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
3080	—	2	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.



REAR AXLE / BAKAXEL
5574 4996 00


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5571 5542 00	1	AXLE	HJULAXEL	Page 135	
2	5530 9821 00	8	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 1-1/4 NC X 14 G
3	5531 0800 00	8	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1- 1/4 NC
4	5559 9241 00	16	WASHER	PLÅTBRICKA		

Fig. 1 of 2



5574 0335 00 bl 1/4 ed.03


Fig. 2 of 2




Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5574 0443 00	1	DRIVELINE	DRIVLINA	Page 151	TRANS-CONV DRIVELINE
2	5575 7003 78	1	DRIVELINE	DRIVLINA	Page 153	MIDSHIP
3	5575 7003 77	1	DRIVELINE	DRIVLINA	Page 155	CHASSIS DRIVE LINE
4	5574 0382 00	1	DRIVELINE	DRIVLINA	Page 157	REAR DRIVE LINE
5	5559 9987 00	1	DRIVELINE	DRIVLINA	Page 159	TRANSM. - ENGINE AXLE
6	5573 6743 00	1	SPACER	DISTANS		
13	5574 0448 00	1	MOUNT	FÄSTE		
14	5565 7678 00	1	GUARD	SKYDD		
15	0144 3367 03	10	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 51 - 8.8 FZB
16	5530 7551 00	10	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1/2 NC N
17	5559 9234 00	20	WASHER	PLÅTBRICKA		1/2 HT
19	5573 6746 00	1	WRAPPER	SVEP		
21	5574 0446 00	1	COVER	KÅPA	Page 161	COVER ASSY- D'LINE 18.00/457
25	5530 9109 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 5/8 NC X 3-1/2
26	5530 7057 00	6	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 5/8 NC N
27	5559 9236 00	12	WASHER	PLÅTBRICKA		
28	5530 8490 00	2	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 5/8 NC X 3 G8
31	5553 8252 00	1	GUARD	SKYDD		
32	5572 5271 00	1	GUARD	SKYDD		
33	5553 8109 00	1	MOUNT	FÄSTE		
35	5559 9234 00	2	WASHER	PLÅTBRICKA		1/2 HT
38	0144 3290 03	3	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 38 - 8.8 FZB
39	5559 9232 00	3	WASHER	PLÅTBRICKA		3/8 HT
40	0144 3370 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 64 - 8.8 FZB
41	5530 7116 00	3	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N




Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5574 0444 00	1	DRIVELINE	DRIVLINA		
2	5535 4734 00	1	YOKE	BYGEL		
3	5535 7209 00	2	BEARING	LAGER		




Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5573 6732 00	1	DRIVE LINE	KARDAN		
2	5535 4734 00	1	YOKE	BYGEL		
3	5535 7209 00	1	BEARING	LAGER		
4	5535 7209 00	1	BEARING	LAGER		




Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5573 6735 00	1	DRIVE LINE	KARDAN		CHASSIS DRIVELINE
2	5533 5001 00	1	YOKE	BYGEL		
3	5553 6763 00	2	CASTLE NUT	KRONMUTTER		
4	5541 3282 00	2	WASHER	PLÅTBRICKA		WASHER-FLAT 1-1/2 HT X 2.
5	5535 0528 00	1	FLANGE	FLÄNS		BEARING-FLANGE
6	5535 5619 00	1	BEARING	LAGER		
7	5575 7003 69	1	YOKE	OK		



Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5574 0383 00	1	DRIVE LINE	KARDAN		
2	5535 4734 00	1	YOKE	BYGEL		
3	5535 7209 00	1	BEARING	LAGER		
4	5535 7210 00	1	BEARING	LAGER		



Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5535 7209 00	1	BEARING	LAGER		
2	5535 7209 00	1	BEARING	LAGER		
3	5536 1070 00	1	YOKE	BYGEL		
4	5507 8909 00	1	OBSOLETE	UTGÅTT		



COVER / KÅPA

5574 0446 00

COVER ASSY- D'LINE 18.00/457

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5574 0447 00	1	COVER	KÅPA		
2	5573 6750 00	1	MOUNT	FÄSTE		
3	5573 6751 00	1	MOUNT	FÄSTE		
6	5573 6753 00	1	STRAP	SPÄNNBAND		
7	5541 3641 00	8	NUT	MUTTER		NUT-CAGED 5/16 NC
9	0144 3248 03	8	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 5/16 X 25 - 8.8 FZB
12	0144 3285 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 19 - 8.8 FZB
13	0301 2344 00	2	PLAIN WASHER	RUNDBRICKA		10,5 / 20 X 2 -HB 200 FZB 10,5 / 20 X 2 -HB 200 FZB

Fig. 1 of 3






Fig. 2 of 3



ONLY FOR HYDRAULIC SHIFT.

5574 4772 00 2/3 ed.08

Fig. 3 of 3





5574 4772 00 2/3 ed.08

(Sheet 1 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5500 7884 00	4	PLUG	PROPP		PLUG-INV (O-RING)
2	0570 7041 25	1	NIPPLE	NIPPEL		E 8-10 UNF 11/16-16
3	3176 7868 06	1	PLUG	PROPP		3/4-16 UNF, TYPE A, STEEL
4	0570 7000 07	1	NIPPLE	NIPPEL		B1 28-32 UN 1 11/16-12
6	5500 2158 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/O-RING)
7	5501 1759 00	2	CONNECTOR	KONTAKTDON		CONNECTOR (ORS/O-RING)
8	5501 1827 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/PIPE)
10	5501 1842 00	1	NIPPLE	NIPPEL		ELBOW-45 (ORS/O-RING)
11	5574 4768 00	1	TUBE	RÖR		
12	5573 6026 00	1	TUBE	RÖR		
13	5574 4800 00	1	TUBE	RÖR		
14	5573 6028 00	1	TUBE	RÖR		
15	5574 4769 00	1	BRACKET	KONSOL		
16	5574 4770 00	1	BRACKET	KONSOL		
17	5537 2976 00	2	CLAMP	KLAMMA		CLAMP-PIPE 1-1/2 (MAIN)
18	0144 3297 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 76 - 8.8 FZB
19	0144 3287 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 25 - 8.8 FZB
20	0144 3292 03	9	HEXAGON SCREW	SEXKANTSSKRUV		UNC 3/8 - 51 16,5 25 6 14
21	0144 3288 03	8	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 32 - 8.8 FZB
22	5530 6084 00	8	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 7/16NC X 1-1/2
23	0144 3365 03	28	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 38 - 8.8 FZB
24	5112 2392 40	14	LOCK WASHER	LÅSBRICKA		
25	5112 2466 39	16	LOCK WASHER	LÅSBRICKA		CAPSCREW - ADJUSTING NUT LOCK
26	5112 2465 26	32	LOCK WASHER	LÅSBRICKA		
43	5564 1385 00	1	MOUNT	FÄSTE		
45	5563 1862 00	1	MOUNT	FÄSTE		
46	5541 2570 00	1	CLAMP	KLAMMA		
49	5563 5240 00	1	MOUNT	FÄSTE		
27	5533 2727 00	1	O-RING	O-RING		O-RING (VITON 16-SPFL)
28	5533 2728 00	4	O-RING	O-RING		O-RING (VITON 20-SPFL)
29	5533 2729 00	6	O-RING	O-RING		O-RING (VITON 24-SPFL)
30	5533 2731 00	2	O-RING	O-RING		O-RING (VITON 32-SPFL)

(Sheet 2 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
31	0638 0521 00	2	FLANGE HALF	FLÄNSHALVA		25 X 45,24 SAE 1 PR.345
32	0638 0527 00	6	FLANGE HALF	FLÄNSHALVA		32 X 51,59 SAE 1 1/4 P276
33	3176 7922 00	12	FLANGE HALF	FLÄNSHALVA		38 61,09
34	0638 0545 00	4	FLANGE HALF	FLÄNSHALVA		51 72,24
35	5574 4799 00	1	TUBE	RÖR		
36	5573 8436 00	1	TUBE	RÖR		
37	5540 8499 00	1	KIT	SATS		BREATHING KIT
38	0144 3363 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 32 - 8.8 FZB
39	9125 6871 00	2	O-RING	O-RING		29,87X 1,78 90 SH
40	5500 2148 00	1	TEE	T-RÖR		TEE-RUN (ORS/O-RING)
41	5540 8945 00	1	FILTER	FILTER	Page 169	FILTER-SPIN ON HYD
42	5564 0889 00	2	JUNCTION BLOCK	KOPPLINGSBLOCK		
44	5530 9466 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 7/16NC X 2-1/2
47	0570 7041 24	2	ELBOW NIPPLE	VINKELNIPPEL		E 6 UNF 9/16-18
48	5501 1813 00	2	PIPE CONNECTION	RÖRANSLUTNING		CONNECTOR (ORS/PIPE)
50	5541 5727 00	2	PLATE	PLÅT		
51	5541 5743 00	2	INSERT	INSATS		
52	5541 5731 00	2	PLATE	PLÅT		
53	-	1	MOUNT	FÄSTE		
54	5530 6043 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 3-1/2
55	5112 2467 47	2	SCREW	SKRUV		1C-624
56	5559 9232 00	8	WASHER	PLÅTBRICKA		3/8 HT
57	5530 7116 00	2	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
58	5535 1313 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		
103	5507 3069 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
104	5507 3855 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
105	5575 7013 60	1	HOSE ASSEMBLY	SLANGLEDNING		1C00114NNN0180A
106	5507 2381 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
107	5507 3856 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
110	5507 2091 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
112	5507 5010 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
113	5507 5011 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY



1250 0151 61

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5537 4630 00	1	PLUG	PROPP		
2	5540 9073 00	1	FILTER HOLDER	FILTERFÄSTE		
3	5537 4631 00	2	FILTER ELEMENT	FILTERELEMENT		

Fig. 1 of 2





Fig. 2 of 2



5574 7219 00 2/2 ED.06

(Sheet 1 of 2)


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5574 8203 00	1	BRACKET	KONSOL		
2	0570 7025 21	1	NIPPLE	NIPPEL		E 8-10 UNF 11/16-16
3	5541 3641 00	3	NUT	MUTTER		NUT-CAGED 5/16 NC
4	0570 7041 16	4	ELBOW NIPPLE	VINKELNIPPEL		B1 8 10 UNF 17,46 11/16 1
5	0570 7041 24	5	ELBOW NIPPLE	VINKELNIPPEL		E 6 UNF 9/16-18
6	5571 4619 00	1	BUSHING	BUSSNING		
7	0570 7025 08	2	NIPPLE	NIPPEL		B1 8-10 UNF 11/16-16
9	5500 7577 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/PIPE)
10	5500 2161 00	1	TEE	T-RÖR		TEE-BRNCH (ORS/PIPE)
11	5537 8911 00	1	VALVE	VENTIL	Page 175	
12	5500 9305 00	1	CONNECTOR	KONTAKTDON		CONNECTOR (O-RING/JIC-FEM
13	5559 9231 00	3	WASHER	PLÅTBRICKA		5/16 HT
14	5503 1907 00	1	MANIFOLD	ANSLUTN.BLOCK		
15	5537 8630 00	5	SOLENOID	MAGNETSPOLE	Page 181	
17	5559 3684 00	1	MOUNT	FÄSTE		
18	0144 4001 95	4	HEXAGON SCREW	SEKKANTSSKRUV		UNC 7/16 - 51 18,3 28 7,1
19	5530 9645 00	4	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 7/16NC N
20	5565 1702 00	1	ACCUMULATOR	ACKUMULATOR	Page 183	
21	5530 7531 00	2	SCREW, HEX HEAD	SKRUV, SEKKANT		CPSCR-HEX 3/8 NC X 4 G5
22	5559 9232 00	7	WASHER	PLÅTBRICKA		3/8 HT
23	5540 7348 00	1	CHECK VALVE	BACKVENTIL	Page 185	CHECK VALVE W/FIXED ORIFICE
24	0144 3285 03	5	SCREW, HEX HEAD	SKRUV, SEKKANT		UNC 3/8 X 19 - 8.8 FZB
25	5537 6169 00	1	PLUG	PROPP		
26	3176 7868 03	11	PLUG	PROPP		7/16-20 UNF-2A
27	5501 1780 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/O-RING)
28	5500 7884 00	1	PLUG	PROPP		PLUG-INV (O-RING)
29	5500 4867 00	1	NIPPLE	NIPPEL		ELBOW-90 (O-RING/JIC)
31	3176 6570 00	1	NIPPLE	NIPPEL		UNF 3/4 - UNF 3/4
32	5501 1779 00	5	NIPPLE	NIPPEL		ELBOW-90 (ORS/O-RING)
33	0570 7041 26	1	ELBOW NIPPLE	VINKELNIPPEL		B1 6 - UNF 14,29 9/16 18
34	0144 3249 03	3	SCREW, HEX HEAD	SKRUV, SEKKANT		UNC 5/16 X 32 - 8.8 FZB
35	0570 7009 18	1	NIPPLE	NIPPEL		B2 8-10 UNF 11/16-16

HYDR. SYSTEM / HYDRAULSYSTEM

5574 7219 00

(Sheet 2 of 2)


Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
36	5501 6032 00	1	PIPE CONNECTION	RÖRANSLUTNING		CONNECTOR (PIPE/JIC-FEMAL
37	5540 2083 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		A M12 55 30 7,5 18 10.9 -
38	0291 1128 22	4	LOCK NUT	LÅSMUTTER		M 12 - 8 FZB / ISO 7040
39	5530 8108 00	8	WASHER	PLÅTBRICKA		WASHER-FLAT M12 HT PLTD
101	5507 7714 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
102	5501 4241 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
103	5505 8533 00	1	HOSE ASSEMBLY	SLANGLEDNING		1C00107EEE0590A
104	5504 9797 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
105	5501 4245 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
106	5504 9797 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
107	5501 4259 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
108	5500 8999 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
109	5500 9065 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
110	5501 4411 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
111	5500 9037 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
112	5501 4234 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY



VALVE / VENTIL


5537 8911 00

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5536 5349 00	1	PLUG	PLUGG		
2	5112 2467 60	1	O-RING	O-RING		
3	5540 0825 00	1	SPRING	FJÄDER		
4	5540 0826 00	1	SPOOL	SLID		
5	5536 5349 00	1	PLUG	PLUGG		
6	5112 2467 60	1	O-RING	O-RING		
7	5537 0522 00	1	SPRING	FJÄDER		
8	5540 4796 00	1	SPOOL	SLID		
9	5540 0722 00	1	PIN	TAPP		
10	5533 0091 00	1	BALL	KULA		
11	–	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
12	5112 2803 05	1	PLUG	PLUGG		
13	5112 2392 40	4	LOCK WASHER	LÅSBRICKA		
14	5540 0828 00	4	SCREW	HÅLSKRUV		
15	5112 2467 45	1	SOLENOID VALVE	MAGNETVENTIL	Page 177	
16	–	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
17	5537 0987 00	1	SPRING	FJÄDER		
18	5537 0986 00	1	SPRING	FJÄDER		
19	5112 2467 60	1	O-RING	O-RING		
20	5536 5349 00	1	PLUG	PLUGG		
21	5112 2803 05	1	PLUG	PLUGG		
22	5540 7841 00	1	GASKET	PACKNING		
23	5112 2803 05	1	PLUG	PLUGG		
24	5540 0829 00	1	VALVE	VENTIL	Page 179	LOCK-UP & MODULATOR
25	5540 0830 00	1	PLATE	PLÅT		




SOLENOID VALVE / MAGNETVENTIL**5112 2467 45**

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
17	5112 2467 42	1	O-RING	O-RING		
18	5112 2467 43	1	O-RING	O-RING		
19	5112 2467 44	1	O-RING	O-RING		
21	5112 3190 27	1	COIL	SPOLE		




Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5536 5349 00	1	PLUG	PLUGG		
2	5112 2467 60	1	O-RING	O-RING		
3	5540 0825 00	1	SPRING	FJÄDER		
4	5540 0826 00	1	SPOOL	SLID		
5	5536 5349 00	1	PLUG	PLUGG		
6	5112 2467 60	1	O-RING	O-RING		
7	5537 0522 00	1	SPRING	FJÄDER		
8	5540 4796 00	1	SPOOL	SLID		
9	5540 0722 00	1	PIN	TAPP		
10	5533 0091 00	1	BALL	KULA		
11	–	1	NOT DEL. SEP.	LEV. EJ SEP.		HOUSING
12	5112 2803 05	1	PLUG	PLUGG		
16	–	1	NOT DEL. SEP.	LEV. EJ SEP.		SPOOL
17	5537 0987 00	1	SPRING	FJÄDER		
18	5537 0986 00	1	SPRING	FJÄDER		
19	5112 2467 60	1	O-RING	O-RING		
20	5536 5349 00	1	PLUG	PLUGG		
21	5112 2803 05	1	PLUG	PLUGG		
23	5112 2803 05	1	PLUG	PLUGG		



SOLENOID / MAGNETSPOLE





5537 8630 00

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
0	5537 5898 00	1	SEAL KIT	TÄTNINGSSATS		
1	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
2	5540 3892 00	1	COIL	SPOLE		



ACCUMULATOR / ACKUMULATOR
5565 1702 00


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5557 2371 00	1	WEARING RING	SLITRING		
2	5541 1308 00	1	PACKING	TÄTNING		
3	5565 1705 00	1	PISTON	KOLV		
4	5537 2070 00	1	SPRING	FJÄDER		
5	5565 1703 00	1	BARREL	HYLSA		
6	5533 2733 00	1	O-RING	O-RING		O-RING (VITON 40-SPFL)
7	5565 1707 00	1	CAP	HUV		
8	5537 5194 00	1	RING	RING		SNAP RING




CHECK VALVE / BACKVENTIL**5540 7348 00**

CHECK VALVE W/FIXED ORIFICE


Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
0	5537 8124 00	1	SEAL KIT	TÄTNINGSSATS		
1	5541 5936 00	1	CARTRIDGE	PATRON		



Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5573 6541 00	1	TRANSMISSION	TRANSMISSION	Page 189	MOD-CLARK 5000 SERIES TRANS
2	5573 6542 00	2	PLATE	PLÅT		
3	5530 8817 00	12	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 1 NC X 4 G8
4	5559 9239 00	24	WASHER	PLÅTBRICKA		
5	5530 7241 00	12	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1 NC N



Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5570 5608 00	1	TRANSMISSION	TRANSMISSION	Page 191	TRANSMISSION SPEC- 5421-184
4	5537 2773 00	1	REDUCER	REDUCERING		REDUCER-BELL
5	5534 0154 00	1	O-RING	O-RING		O-RING
6	5535 9883 00	1	CAP	HUV		



(Sheet 1 of 6)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5541 7531 00	1	CONTROL	REGLAGE	Page 199	
	5570 5608 73	1	CASE	HÖLJE	Page 203	
	5570 5608 74	1	TRANSM.SPEC	TRANSM.SPEC	Page 205	
	5570 5608 75	1	TRANSM.SPEC	TRANSM.SPEC	Page 209	
1	5540 0793 00	1	RING	RING		
2	5501 2424 00	1	KIT	SATS		INPUT CLUTCH
3	5541 2289 00	4	PISTON RING	KOLVRING		
4	5537 5872 00	8	BOLT	BULT		
5	5535 3927 00	1	SUPPORT COMPL	STÖD KOMPLETT		
6	5537 8923 00	1	NUT	MUTTER		
9	5533 4001 00	1	BEARING	LAGER		
10	5533 3409 00	1	SPACER	DISTANS		
11	5533 3384 00	1	GEAR	VÄXEL		
12	5533 3480 00	1	GASKET	PACKNING		
13	5112 2392 40	6	LOCK WASHER	LÅSBRICKA		
14	0144 3287 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 25 - 8.8 FZB
14	5112 2467 47	2	SCREW	SKRUV		1C-624
15	5537 3610 00	1	VALVE	VENTIL	Page 211	CONTROL VALVE
16	5531 0417 00	6	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 2-1/2
17	5112 2392 40	6	LOCK WASHER	LÅSBRICKA		
18	5112 2392 19	6	O-RING	O-RING		
19	5533 9588 00	1	HOUSING	HUS		
20	5533 9589 00	1	DIP STICK	OLJESTICKA		
21	5533 4233 00	1	DIP STICK	OLJESTICKA		DIPSTICK TUBE
22	5533 9990 00	1	CAP	HUV		
23	5533 6801 00	1	FILLER	FYLLKROPP		
24	5533 3384 00	1	GEAR	VÄXEL		
25	5540 0797 00	1	SPACER	DISTANS		
26	5540 0798 00	1	SHAFT	AXEL		
27	5533 4002 00	1	BEARING	LAGER		
28	5533 3403 00	1	GASKET	PACKNING		
29	5533 3402 00	1	CAP	HUV		

TRANSMISSION / TRANSMISSION

5570 5608 00

(Sheet 2 of 6)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
30	5534 1361 00	1	SEAL	TÄTNING		
31	5112 2465 26	4	LOCK WASHER	LÅSBRICKA		
32	0144 3363 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 32 - 8.8 FZB
34	5533 9675 00	1	FLANGE	FLÄNS		
35	5533 9100 00	1	O-RING	O-RING		
36	5112 2466 71	1	WASHER	BRICKA		
37	5112 2466 72	1	NUT	MUTTER		
38	0144 3363 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 32 - 8.8 FZB
39	5112 2465 26	4	LOCK WASHER	LÅSBRICKA		
41	5533 3401 00	1	CAP	HUV		
42	5533 3403 00	1	GASKET	PACKNING		
43	5112 2466 72	1	NUT	MUTTER		
44	5533 3406 00	1	SPACER	DISTANS		
45	5533 4002 00	1	BEARING	LAGER		
46	5540 0798 00	1	SHAFT	AXEL		
47	5540 0797 00	1	SPACER	DISTANS		
48	5533 3409 00	1	SPACER	DISTANS		
49	5533 4001 00	1	BEARING	LAGER		
50	5537 8923 00	1	NUT	MUTTER		
53	5535 3927 00	1	SUPPORT COMPL	STÖD KOMPLETT		
54	5537 5872 00	8	BOLT	BULT		
55	5541 2289 00	4	PISTON RING	KOLVRING		
56	5501 2424 00	1	KIT	SATS		REVERSE GEAR CLUTCH
57	5540 0793 00	1	RING	RING		
58	5537 3188 00	1	RING	RING		
59	5533 3383 00	1	GEAR	VÄXEL		
60	5533 3465 00	1	CAP	HUV		
61	5533 3488 00	1	SHIM	SHIMS		
61	5533 3489 00	1	SHIM	SHIMS		
61	5533 3490 00	1	SHIM	SHIMS		
62	5540 5033 00	1	BEARING	LAGER		
63	5540 2848 00	1	ROLLER	RULLE		

TRANSMISSION / TRANSMISSION

5570 5608 00

(Sheet 3 of 6)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
64	5540 2848 00	1	ROLLER	RULLE		
65	5540 5033 00	1	BEARING	LAGER		
66	5533 3464 00	1	SPACER	DISTANS		
67	5533 3824 00	1	RING	RING		
68	5533 3449 00	1	SHIELD	SKÖLD		
69	5535 1153 00	1	SHAFT	AXEL		
70	5535 1151 00	1	BEARING	LAGER		
72	5535 1150 00	1	SHAFT	AXEL		
73	5540 0883 00	1	RING	RING		
79	5533 3507 00	1	COVER	KÅPA		
80	5535 2712 00	1	GASKET	PACKNING		
81	5537 8941 00	1	RING	RING		
82	5501 2424 00	1	KIT	SATS		1ST GEAR CLUTCH
83	5534 6190 00	2	RING	RING		
84	5534 6189 00	2	RING	RING		
85	5537 5872 00	8	BOLT	BULT		
86	5533 3351 00	1	SUPPORT COMPL	STÖD KOMPLETT		
87	5541 1254 00	1	SHAFT	AXEL		
88	5533 0093 00	1	BALL	KULA		
89	5533 3957 00	1	BEARING	LAGER		
90	5533 3835 00	1	RING	RING		
91	5533 3405 00	1	SPACER	DISTANS		
92	5536 3183 00	1	TRANSMISSION	TRANSMISSION		
93	5533 3739 00	1	WASHER	BRICKA		
94	5533 4003 00	1	BEARING	LAGER		
95	5537 8923 00	1	NUT	MUTTER		
98	5535 3927 00	1	SUPPORT COMPL	STÖD KOMPLETT		
99	5537 5872 00	8	BOLT	BULT		
100	5541 2289 00	4	PISTON RING	KOLVRING		
101	5501 2424 00	1	KIT	SATS		3RD GEAR CLUTCH
102	5112 2465 26	5	LOCK WASHER	LÅSBRICKA		
103	0144 3363 03	5	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 32 - 8.8 FZB
104	5540 0793 00	1	RING	RING		

TRANSMISSION / TRANSMISSION

5570 5608 00

(Sheet 4 of 6)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
105	5540 0793 00	1	RING	RING		
106	5501 2424 00	1	KIT	SATS		4TH GEAR CLUTCH
107	5541 2289 00	4	PISTON RING	KOLVRING		
108	5537 5872 00	8	BOLT	BULT		
109	5535 3927 00	1	SUPPORT COMPL	STÖD KOMPLETT		
110	5537 8923 00	1	NUT	MUTTER		
113	5533 4003 00	1	BEARING	LAGER		
114	5533 3739 00	1	WASHER	BRICKA		
115	5533 3405 00	1	SPACER	DISTANS		
116	5534 1456 00	1	GEAR	VÄXEL		
117	5535 1152 00	1	GEAR	VÄXEL		
118	5533 9992 00	1	PIPE FITTING	RÖRDEL		
119	5112 2392 09	1	AIR FILTER	LUFTFILTER		
120	5533 3835 00	1	RING	RING		
121	5533 3957 00	1	BEARING	LAGER		
122	5541 1254 00	1	SHAFT	AXEL		
123	5533 3351 00	1	SUPPORT COMPL	STÖD KOMPLETT		
124	5537 5872 00	8	BOLT	BULT		
125	5534 6189 00	2	RING	RING		
126	5534 6190 00	2	RING	RING		
127	5532 9984 00	1	FLAP COTTER	KLAFFSPRINT		
128	5501 2424 00	1	KIT	SATS		2ND GEAR CLUTCH
129	5537 8941 00	1	RING	RING		
130	5534 0003 00	4	SCREW	SKRUV		
131	5533 9963 00	4	LOCK WASHER	LÅSBRICKA		
132	5535 3781 00	20	WASHER	BRICKA		
133	5533 3103 00	20	SCREW	SKRUV		SCREW
137	5112 2805 15	1	NUT	MUTTER		
138	5533 3739 00	1	WASHER	BRICKA		
139	5540 0695 00	1	O-RING	O-RING		O-RING
140	5533 3400 00	1	FLANGE	FLÄNS		
141	0144 3363 03	6	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 32 - 8.8 FZB

TRANSMISSION / TRANSMISSION

5570 5608 00


(Sheet 5 of 6)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
142	5112 2465 26	6	LOCK WASHER	LÅSBRICKA		
143	5535 3782 00	1	CAP	HUV		
144	5534 0143 00	1	O-RING	O-RING		O-RING
145	5533 3983 00	1	SEAL	TÄTNING		SEAL-OIL
146	5540 4764 00	1	BEARING	LAGER		
147	5534 0824 00	1	CONE	KONA		
148	5533 3536 00	1	SHAFT	AXEL		
149	5533 3377 00	1	GEAR	VÄXEL		
150	5530 7892 00	2	PLUG	PLUGG		
151	5535 3781 00	18	WASHER	BRICKA		
152	5533 3103 00	18	SCREW	SKRUV		SCREW
153	5533 3427 00	1	OIL PAN	OLJETRÅG		
154	5540 0675 00	2	MAGNET	MAGNET		
155	5535 3213 00	1	GASKET	PACKNING		
156	5530 5056 00	3	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 2-1/4
157	5112 2392 40	3	LOCK WASHER	LÅSBRICKA		
158	5533 3533 00	1	GASKET	PACKNING		
159	5537 1564 00	1	FRAME	RAM		
160	5534 1455 00	1	GEAR	VÄXEL		
161	5534 0824 00	1	CONE	KONA		
162	5540 4764 00	1	BEARING	LAGER		
163	5533 3983 00	1	SEAL	TÄTNING		SEAL-OIL
164	5534 0143 00	1	O-RING	O-RING		O-RING
165	5533 3485 00	1	SHIM	SHIMS		
165	5533 3486 00	1	SHIM	SHIMS		
165	5533 3487 00	1	SHIM	SHIMS		
166	5535 3782 00	1	CAP	HUV		
167	5533 3400 00	1	FLANGE	FLÄNS		
168	5112 2465 26	6	LOCK WASHER	LÅSBRICKA		
169	0144 3363 03	6	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 32 - 8.8 FZB
170	5540 0695 00	1	O-RING	O-RING		O-RING
171	5533 3739 00	1	WASHER	BRICKA		
172	5532 9984 00	2	FLAP COTTER	KLAFFSPRINT		

TRANSMISSION / TRANSMISSION**5570 5608 00**

(Sheet 6 of 6)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
173	5112 2805 15	1	NUT	MUTTER		
174	5535 3214 00	1	GASKET	PACKNING		
175	5533 3457 00	1	COVER	KÅPA		
176	5535 3781 00	26	WASHER	BRICKA		
177	5533 3103 00	26	SCREW	SKRUV		SCREW
186	5533 6269 00	2	PLUG	PLUGG		



CONTROL / REGLAGE
5541 7531 00


(Sheet 1 of 2)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5534 5634 00	1	SEAL	TÄTNING		
2	5540 1137 00	1	RING	RING		
3	5533 3482 00	1	WASHER	BRICKA		
4	5533 4215 00	1	PISTON	KOLV		
4	5537 4963 00	1	SPOOL	SLID		
5	5540 1309 00	1	GASKET	PACKNING		
6	5534 1334 00	1	SPRING	FJÄDER		
7	5533 4219 00	1	PIN	TAPP		
7	5534 1334 00	1	SPRING	FJÄDER		
8	5533 0093 00	3	BALL	KULA		
8	5533 4217 00	1	SPRING	FJÄDER		
9	5537 3149 00	1	SWITCH	OMKOPPLARE		
10	5534 7225 00	1	BALL	KULA		
11	5112 2467 59	1	PLUG	PLUGG		
12	5112 2467 60	1	O-RING	O-RING		
13	5533 9678 00	1	SPACER	DISTANS		
14	5530 5160 00	2	PLUG	PROPP		ERS. AV 5112246748I MOVEX
15	5535 0686 00	1	HOUSING ASSY	HUS KPL		
16	5535 0699 00	1	PLUG	PROPP		
17	5535 0693 00	1	WASHER	BRICKA		
18	5534 1334 00	1	SPRING	FJÄDER		
19	5530 5056 00	9	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 2-1/4
20	5112 2392 40	9	LOCK WASHER	LÅSBICKA		
21	5112 2803 05	1	PLUG	PLUGG		
22	5537 4965 00	1	SELECTOR SWITCH	VÄLJAROMKOPPL.		
24	5533 9803 00	1	STOP	STOPP		
25	5540 1137 00	1	RING	RING		
26	5534 5634 00	1	SEAL	TÄTNING		
27	5533 9652 00	1	SPRING	FJÄDER		
28	5533 9648 00	1	SPOOL	SLID		
29	5112 2467 60	1	O-RING	O-RING		
30	5112 2467 59	1	PLUG	PLUGG		

CONTROL / REGLAGE**5541 7531 00**


(Sheet 2 of 2)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
31	5537 4966 00	1	MOUNTING PLATE	MONTERINGSPLÅT		
32	5534 0028 00	1	PLUG	PLUGG		
32	5537 4967 00	1	O-RING	O-RING		
33	5537 7591 00	1	CHECK VALVE	BACKVENTIL		
34	5533 0093 00	1	BALL	KULA		
35	5533 4241 00	1	SPRING	FJÄDER		
36	5533 4240 00	1	PIN	TAPP		
39	5533 4218 00	1	SPRING	FJÄDER		
41	5533 2721 00	1	O-RING	O-RING		O-RING (VITON)
42	5533 3732 00	1	STOP	STOPP		
43	5537 5267 00	1	RING	RING		
44	5534 0028 00	1	PLUG	PLUGG		
44	5537 4967 00	1	O-RING	O-RING		




5000 SERIES CASE ASSEMBLY
(4 SPEED)


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
2	5533 3504 00	1	TUBE	RÖR		
3	5533 3506 00	1	TUBE	RÖR		
4	5533 3505 00	1	TUBE	RÖR		
5	5112 2392 20	8	SLEEVE	HYLSA		
6	5112 2392 20	14	SLEEVE	HYLSA		
7	5534 4092 00	1	TUBE	RÖR		
8	5533 7368 00	1	TUBE	RÖR		
9	5532 9996 00	1	RIVET	NIT		
10	5559 9231 00	1	WASHER	PLÅTBRICKA		5/16 HT
11	5532 9997 00	1	RIVET	NIT		
12	5559 9231 00	1	WASHER	PLÅTBRICKA		5/16 HT
13	5533 7368 00	1	TUBE	RÖR		
14	5559 9230 00	1	WASHER	PLÅTBRICKA		1/4 HT
15	5532 9994 00	1	RIVET	NIT		
16	5533 7369 00	1	TUBE	RÖR		
17	5537 1567 00	1	TUBE	RÖR		
18	5533 3502 00	1	TUBE	RÖR		
19	5533 3494 00	1	TUBE	RÖR		
20	5536 3184 00	1	TUBE	RÖR		
21	5536 3185 00	1	TUBE	RÖR		
22	5536 3186 00	1	TUBE	RÖR		
23	5533 3496 00	1	TUBE	RÖR		
24	5533 3501 00	1	TUBE	RÖR		
25	5537 1568 00	1	TUBE	RÖR		
26	5112 2392 46	2	SLEEVE	HYLSA		
27	5112 2392 46	2	SLEEVE	HYLSA		




Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
2	5540 0035 00	1	HUB	NAV	Page 207	FWD, REV, 3RD, 4TH CLUTCH GRP.
3	5537 7590 00	6	SPRING	FJÄDER		
4	5533 3450 00	6	SPRING	FJÄDER		
5	5536 5332 00	9	DISK	SKIVA		
6	5533 4055 00	10	DISK	SKIVA		
7	5533 3368 00	1	END PLATE	ÄNDPLÅT		
8	5533 3350 00	1	RING	RING		
9	5533 3370 00	1	PISTON	KOLV		
11	5534 1457 00	1	RING	RING		RING
12	5533 3385 00	1	PISTON RING	KOLVRING		RING-PISTON
14	5537 6985 00	1	RING	RING		
14	5537 6986 00	1	WASHER	BRICKA		
15	5537 6987 00	1	WASHER	BRICKA		
15	5537 6988 00	1	WASHER	BRICKA		
15	5537 6989 00	1	WASHER	BRICKA		
16	5535 3932 00	1	BEARING	LAGER		
17	5535 3931 00	1	BEARING	LAGER		
18	5533 3364 00	1	BEARING PART	LAGERDEL		
19	5112 2805 57	1	BALL	KULA		
20	5535 5114 00	1	DRUM	TRUMMA		
21	5535 3928 00	1	CUP	YTERRING		
22	5535 3929 00	1	CONE	KONA		



Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
2	—	1		*		NOT SOLD SEPARATELY
3	5537 7590 00	6	SPRING	FJÄDER		
4	5533 3450 00	6	SPRING	FJÄDER		
5	5536 5332 00	9	DISK	SKIVA		
6	5533 4055 00	10	DISK	SKIVA		
7	5533 3368 00	1	END PLATE	ÄNDPLÅT		
8	5533 3350 00	1	RING	RING		
9	5533 3370 00	1	PISTON	KOLV		
10	5534 1457 00	1	RING	RING		RING
11	5533 3385 00	1	PISTON RING	KOLVRING		RING-PISTON
12	5537 6985 00	2	RING	RING		QTY AS REQ.
12A	5537 6986 00	2	WASHER	BRICKA		QTY AS REQ.
13	5537 6987 00	2	WASHER	BRICKA		QTY AS REQ.
13A	5537 6988 00	2	WASHER	BRICKA		QTY AS REQ.
13B	5537 6989 00	2	WASHER	BRICKA		QTY AS REQ.
14	5535 3932 00	1	BEARING	LAGER		
15	5535 3931 00	1	BEARING	LAGER		
16	5533 3364 00	1	BEARING PART	LAGERDEL		INCL. IN REF 18
17	5112 2805 57	1	BALL	KULA		INCL. IN REF 18
18	5540 4767 00	1	CLUTCH ASSY.	KOPPLINGSMONT.		INCLUDES REF 16-17
19	5540 4768 00	1	BEARING	LAGER		
20	5537 1583 00	1	CONE	KONA		



Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5533 3411 00	1	BAFFLE PLATE	AVSKÄRMN.PLÅT		
2	5540 1292 00	1	HUB	NAV		
3	5537 7590 00	8	SPRING	FJÄDER		
4	5533 3450 00	8	SPRING	FJÄDER		
5	5533 9692 00	9	DISK	SKIVA		
6	5533 9705 00	10	DISK	SKIVA		
7	5533 3355 00	1	RING	RING		
8	5533 3387 00	1	RING	RING		
9	5533 3356 00	1	PISTON	KOLV		
10	5540 5036 00	1	SPRING	FJÄDER		
11	5540 5037 00	1	PISTON RING	KOLVRING		
12	5537 6395 00	1	PISTON	KOLV		
13	5537 6393 00	1	SPRING	FJÄDER		
14	5533 8045 00	1	RING	RING		
15	5535 4511 00	1	WASHER	BRICKA		
16	5533 3835 00	1	RING	RING		
17	5533 3985 00	1	BEARING	LAGER		
18	5533 3354 00	1	PISTON	KOLV		
19	5112 2805 57	1	BALL	KULA		
20	5533 3352 00	1	DRUM	TRUMMA		
21	5535 5115 00	1	BEARING	LAGER		
22	5533 3820 00	1	RING	RING		
23	5535 0429 00	1	GEAR	VÄXEL		
24	5533 3491 00	1	RING	RING		



VALVE / VENTIL

5537 3610 00

CONTROL VALVE

(Sheet 1 of 3)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5533 4052 00	1	PLUG	PROPP		
2	5112 2467 60	1	O-RING	O-RING		
3	5533 4091 00	1	VALVE	VENTIL		
4	5534 2539 00	1	HOUSING	HUS		
5	5533 0450 00	1	ROLLER	RULLE		
6	5540 7844 00	1	WASHER	BRICKA		
7	5533 4054 00	1	PLUG	PROPP		
8	5533 0450 00	1	ROLLER	RULLE		
9	5112 2467 01	1	O-RING	O-RING		
10	5533 4090 00	1	VALVE	VENTIL		
11	5534 2531 00	1	VALVE	VENTIL		
12	5533 4591 00	1	PLUG	PROPP		
13	5533 9731 00	3	PIN	TAPP		
14	5533 7658 00	1	LOCKING PIN	SPÄRR PINNE		
15	5112 2467 48	3	PLUG	PROPP		CLARK 40K-02
16	5533 4053 00	1	PLUG	PROPP		
17	5540 7614 00	1	WASHER	BRICKA		
18	5533 4059 00	1	VALVE	VENTIL		
19	5533 4060 00	1	VALVE	VENTIL		
20	5540 0887 00	1	RING	RING		
21	5112 2467 01	1	O-RING	O-RING		
22	5533 4062 00	1	VALVE	VENTIL		
23	5533 4061 00	1	PLUG	PROPP		
24	5533 9994 00	1	ADAPTER	ADAPTER		
25	5540 1137 00	1	RING	RING		
26	5537 3436 00	1	GUIDE	STYRNING		
27	4090 0313 00	1	O-RING	O-RING		23,52 1,78 13 3930 90 -30
28	5537 3437 00	1	PISTON	KOLV		
29	5537 3438 00	1	STOP	STOPP		
30	5537 3439 00	1	SPACER	DISTANS		
31	5537 3440 00	1	SPRING	FJÄDER		
32	5537 3441 00	1	SLEEVE	HYLSA		

VALVE / VENTIL

5537 3610 00

(Sheet 2 of 3)


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
33	5533 4053 00	1	PLUG	PROPP		
34	5540 7614 00	1	WASHER	BRICKA		
35	5530 7400 00	1	PLUG	PROPP		PLUG-1/2BLK COUNTERSUNK H
36	5540 9113 00	1	SPOOL	SLID		
37	5537 3437 00	1	PISTON	KOLV		
38	4090 0313 00	1	O-RING	O-RING		23,52 1,78 13 3930 90 -30
39	5537 3436 00	1	GUIDE	STYRNING		
40	5540 1137 00	1	RING	RING		
41	5533 9994 00	1	ADAPTER	ADAPTER		
42	5112 2467 59	1	PLUG	PLUGG		
43	5112 2467 60	1	O-RING	O-RING		
45	5533 3471 00	1	SPOOL	SLID		
47	5533 3472 00	1	SPRING	FJÄDER		
48	5533 3689 00	1	STOP BLOCK	STOPPKLOTS		
49	5112 2392 22	1	O-RING	O-RING		
50	5533 2721 00	1	O-RING	O-RING		O-RING (VITON)
51	5533 3732 00	1	STOP	STOPP		
52	5536 9206 00	1	SPOOL	SLID		
53	5530 7053 00	17	WASHER	BRICKA		WASHER-STAR 1/4 ET
54	5112 2392 41	17	SCREW	SKRUV		
55	5537 3443 00	1	COVER	KÅPA		
56	5533 6269 00	2	PLUG	PLUGG		
57	5533 3475 00	1	SPRING	FJÄDER		
58	5533 3476 00	1	SPRING	FJÄDER		
59	5533 3732 00	1	STOP	STOPP		
60	5533 2721 00	1	O-RING	O-RING		O-RING (VITON)
61	5533 2721 00	1	O-RING	O-RING		O-RING (VITON)
62	5533 3732 00	1	STOP	STOPP		
63	5536 6916 00	1	SPRING	FJÄDER		
64	5533 3479 00	1	SPACER	DISTANS		
65	5533 0097 00	1	BALL	KULA		
66	5533 3477 00	1	VALVE	VENTIL		

VALVE / VENTIL

5537 3610 00

(Sheet 3 of 3)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
67	5533 3466 00	1	COVER PLATE	TÄCKPLÅT		



CONVERTER / OMVANDLARE
5573 5600 00

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5573 6031 00	1	CONVERTER	OMVANDLARE	Page 217	
2	5540 6695 00	8	CAPSCREW	HUVUDSKRUV		CPSCR-12PT 7/16NF X 2 G8
4	5541 2158 00	12	STUD	PINNBULT		STUD 7/16NC X7/17NF X 2.2
5	5559 9233 00	12	WASHER	PLÅTBRICKA		7/16 HT
6	5530 7721 00	12	NUT	BOTTENMUTTER		

CONVERTER / OMVANDLARE
5573 6031 00

(Sheet 1 of 5)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5533 3726 00	1	BAFFLE PLATE	AVSKÄRMN.PLÅT		
2	5534 0837 00	1	CUP	YTERRING		
3	5533 3550 00	1	SPACER	DISTANS		
4	5540 2848 00	1	ROLLER	RULLE		
5	5533 6149 00	1	CUP	YTERRING		
6	5533 9096 00	1	O-RING	O-RING		O-RING
7	5540 9603 00	4	STUD	PINNBULT		
8	5112 2465 26	4	LOCK WASHER	LÅSBRICKA		
9	5531 0783 00	4	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1/2 NF N
10	5533 3400 00	1	FLANGE	FLÄNS		
11	5533 3739 00	1	WASHER	BRICKA		
13	5112 2805 15	1	NUT	MUTTER		
14	5540 0695 00	1	O-RING	O-RING		O-RING
15	5533 3983 00	1	SEAL	TÄTNING		SEAL-OIL
16	5534 1490 00	1	CAP	HUV		
17	5533 3554 00	1	SHIM	SHIMS		SHIM .004
17	5533 3555 00	1	SHIM	SHIMS		SHIM .007
17	5533 3556 00	1	SHIM	SHIMS		SHIM .010
18	5533 3548 00	1	SHAFT	AXEL		
19	5540 4776 00	1	SHAFT	AXEL		
20	5534 0838 00	1	CONE	KONA		
21	5533 3828 00	1	RING	RING		
22	5533 3728 00	1	TUBE	RÖR		
23	5112 2467 48	1	PLUG	PROPP		CLARK 40K-02
24	5590 0002 31	1	CONVERTER	OMVANDLARE		
25	5533 4107 00	1	PISTON	KOLV	Page 223	
26	5112 2467 48	1	PLUG	PROPP		CLARK 40K-02
28	5533 2454 00	1	BUSHING	BUSSNING		
28	5533 4050 00	1	VALVE	VENTIL		
29	5112 2392 09	1	AIR FILTER	LUFTFILTER		
30	5533 3785 00	1	GASKET	PACKNING		
31	5533 3784 00	1	COVER	KÅPA		

(Sheet 2 of 5)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
32	0144 3287 03	3	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 25 - 8.8 FZB
33	5112 2392 40	3	LOCK WASHER	LÅSBRICKA		
35	5533 3577 00	1	CAP	HUV		
36	5112 2466 41	1	O-RING	O-RING		
37	5533 3549 00	1	TUBE	RÖR		
38	5112 2466 41	1	O-RING	O-RING		
39	5533 2740 00	1	O-RING	O-RING		O-RING
40	5540 9566 00	1	PISTON RING	KOLVRING		
41	5112 2803 18	3	SCREW	SKRUV		
42	5533 6149 00	1	CUP	YTERRING		
43	5540 8350 00	1	COVER	KÅPA		
44	5533 3568 00	1	O-RING	O-RING		
45	5540 4776 00	1	SHAFT	AXEL		
46	5533 3547 00	1	SHAFT	AXEL		
47	5534 0890 00	1	CONE	KONA		
48	5534 0889 00	1	CUP	YTERRING		
49	5540 9429 00	1	PISTON RING	KOLVRING		
51	5533 0091 00	1	BALL	KULA		
52	5537 5872 00	8	BOLT	BULT		
53	5534 2231 00	1	RING	RING		
54	5540 0343 00	1	GEAR	VÄXEL		
56	5540 9454 00	1	PISTON RING	KOLVRING		
57	5533 4423 00	1	CRANK	VEV		
58	5533 3546 00	1	SLEEVE	HYLSA		
59	0144 3284 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 16 - 8.8 FZB
59	5112 2392 40	4	LOCK WASHER	LÅSBRICKA		
60	5533 2910 00	2	COVER	KÅPA		
61	5537 6893 00	4	PLUG	PROPP		
62	5533 2910 00	1	COVER	KÅPA		
63	0144 3284 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 16 - 8.8 FZB
63	5112 2392 40	2	LOCK WASHER	LÅSBRICKA		
64	5540 2848 00	1	ROLLER	RULLE		

CONVERTER / OMVANDLARE
5573 6031 00

(Sheet 3 of 5)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
65	5533 3576 00	1	ADAPTER	ADAPTER		
67	5533 3551 00	1	SHIM	SHIMS		
67	5533 3552 00	1	SHIM	SHIMS		
67	5533 3553 00	1	SHIM	SHIMS		
68	5534 6738 00	1	SEAL	TÄTNING		
69	5533 2987 00	4	STUD	PINNBULT		
70	5112 2466 39	4	LOCK WASHER	LÅSBRICKA		CAPSCREW - ADJUSTING NUT LOCK
71	5530 8511 00	4	LOCK NUT	LÅSMUTTER		NUT-JAM 1/2 NF G8
72	5540 0820 00	2	BOLT	BULT		
73	5112 2465 26	2	LOCK WASHER	LÅSBRICKA		
74	5540 7612 00	1	COVER	KÅPA		
75	5540 7613 00	1	GASKET	PACKNING		
76	5530 6084 00	12	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 7/16NC X 1-1/2
77	5112 2466 39	12	LOCK WASHER	LÅSBRICKA		CAPSCREW - ADJUSTING NUT LOCK
78	5112 2392 29	1	PIN	PINNE		
79	5534 1435 00	3	PUMP DRIVE	PUMPDRIVNING		
80	5534 2503 00	3	BEARING	LAGER		
81	5541 4293 00	3	GEAR	VÄXEL		
82	5533 3845 00	3	RING	RING		RING SNAP
83	5536 5883 00	1	DETAILS	DETALJER		
84	5533 3570 00	1	SPACER	DISTANS		
85	5533 3986 00	1	BEARING	LAGER		
86	5536 4091 00	1	O-RING	O-RING		O-RING VITON
87	5112 2392 40	32	LOCK WASHER	LÅSBRICKA		
88	5112 2467 47	32	SCREW	SKRUV		1C-624
89	5537 4616 00	1	RING	RING		
90	5541 4750 00	8	CAPSCREW	HUVUDSKRUV		
91	5533 3543 00	1	BAFFLE PLATE	AVSKÄRMN.PLÅT		
92	5112 2392 63	1	SEAL	TÄTNING		
93	5540 0696 00	3	BEARING	LAGER		
94	5533 3731 00	3	WASHER	BRICKA		
95	5533 6149 00	3	CUP	YTTERRING		
96	5537 3278 00	1	GASKET	PACKNING		


(Sheet 4 of 5)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
97	5536 4764 00	1	MOUNT	FÄSTE		
98	5533 3716 00	1	PUMP DRIVE	PUMPDRIVNING		
99	5537 3278 00	1	GASKET	PACKNING		
100	5541 3639 00	1	PUMP	PUMP		
101	5531 0783 00	4	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1/2 NF N
102	5112 2465 26	4	LOCK WASHER	LÅSBRICKA		
103	5534 1441 00	4	STUD	PINNBULT		
105	5533 7366 00	4	WASHER	BRICKA		
106	0144 3363 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 32 - 8.8 FZB
107	5533 3846 00	3	RING	RING		
108	5533 3834 00	3	RING	RING		
109	5533 7456 00	3	WASHER	BRICKA		
110	5533 9963 00	3	LOCK WASHER	LÅSBRICKA		
111	5112 2803 18	3	SCREW	SKRUV		
112	5536 4097 00	1	O-RING	O-RING		O-RING
113	5536 6939 00	1	IMPELLER	PUMPHJUL		
114	5533 3750 00	1	HUB	NAV		
115	5533 3836 00	1	RING	RING		
116	5533 9732 00	1	PIN	TAPP		
117	5537 3188 00	1	RING	RING		
118	5112 2392 15	14	SCREW	SKRUV		
119	5112 2466 39	14	LOCK WASHER	LÅSBRICKA		CAPSCREW - ADJUSTING NUT LOCK
120	5540 6900 00	1	BACK PART	BAKDEL		
121	5540 7438 00	1	PLATE	PLÅT		
122	5501 2424 00	1	KIT	SATS		INCLUDES ITEM 22-32
123	5534 0148 00	1	O-RING	O-RING		O-RING
124	5535 5531 00	1	PISTON RING	KOLVRING		
125	5533 3987 00	1	BEARING	LAGER		
126	5533 3567 00	1	RING	RING		RING 2187
127	5533 9690 00	1	RING	RING		
128	5580 0073 34	1	O-RING	O-RING		HOUSING, PEC
129	5533 3539 00	1	DISK	SKIVA		

CONVERTER / OMVANDLARE**5573 6031 00**


(Sheet 5 of 5)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
130	5533 3539 00	1	DISK	SKIVA		
131	5533 3544 00	1	RING	RING		
132	5534 1491 00	1	PLATE	PLÅT		
133	5534 1492 00	1	PLATE	PLÅT		
134	5112 2392 41	1	SCREW	SKRUV		
135	5533 3542 00	1	TURBINE	TURBIN		
136	5537 4618 00	1	BACK PART	BAKDEL		
137	5537 4619 00	8	SCREW	SKRUV		
138	5536 5884 00	1	TURBINE	TURBIN		
139	5533 3708 00	2	DOWEL PIN	DUBBPINNE		
140	5533 3882 00	1	HOSE	SLANG		
141	5533 3540 00	1	PLATE	PLÅT		
142	5533 3538 00	1	DISK	SKIVA		
143	5533 3537 00	1	LOCK	LÅS		
144	5533 3539 00	1	DISK	SKIVA		
145	5540 9930 00	1	COVER	KÅPA		
146	5533 3573 00	1	RETAINER	FASTHÅLLARE		
147	5535 5532 00	1	SPRING	FJÄDER		
148	5540 6679 00	1	RING	RING		
149	5540 7019 00	1	CAP	HUV		



PISTON / KOLV
5533 4107 00

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5533 3732 00	1	STOP	STOPP		
2	5533 2721 00	1	O-RING	O-RING		O-RING (VITON)
3	5533 3239 00	1	SPRING	FJÄDER		
4	5533 7539 00	1	PIN	TAPP		
5	5112 2392 15	4	SCREW	SKRUV		
6	5112 2465 26	4	LOCK WASHER	LÅSBRICKA		
7	5112 2467 48	1	PLUG	PROPP		CLARK 40K-02
8	5537 7183 00	1	VALVE	VENTIL		
9	5533 7539 00	1	PIN	TAPP		
10	5535 0473 00	1	PLUG	PROPP		
11	5534 4099 00	1	SPOOL	SLID		
12	5533 2721 00	1	O-RING	O-RING		O-RING (VITON)
13	5533 3732 00	1	STOP	STOPP		
14	5533 4047 00	1	GASKET	PACKNING		
15	5533 4051 00	1	SPRING	FJÄDER		




SET OF WHEELS / HJULSATS

5590 0001 42


16.00-25

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5590 0001 38	4	WHEEL COMPL.	HJUL KOMPL.	Page 227	16.00-25
2	5530 8688 00	92	HEXAGON NUT	SEXKNT MUTTER		NUT-HEX 7/8 NF G8
3	5559 9238 00	92	WASHER	PLÅTBRICKA		



B0029512

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5541 6107 00	1	TIRE	DÄCK	Page 229	
2	5571 3470 00	1	RIM	FÄLG		
3	5535 6275 00	1	VALVE	VENTIL		STEM VALVE, NOT ILLUSTRATED
4	5534 4664 00	1	SEAL NUT	TÄTNINGSMUTTER		SPUD VALVE ASSY, NOT ILLUSTRATED



Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5571 3471 00	1	RIM BASE	RIM BASE		
2	5536 8090 00	1	SEAT	SÄTE		
3	5537 1716 00	2	SIDE	SIDA		
4	5537 1690 00	1	LOCK	LÅS		


OPERATORS AREA / MANÖVEROMRÅDE
LIST OF CONTENTS

Part no Detaljnr	Description	Benämning	See page Se sida	Remarks Anmärkning
–	OPERATORS AREA	MANÖVEROMRÅDE	233	
5573 5570 00	– DUMP CONTROL	– TIPPREGLAGE	235	
5573 5571 00	– THROTTLE CONTR.	– GASREGLAGE	237	
5540 8293 00	– – ACCEL. PEDAL	– – GASPEDAL	239	PEDAL-ELECTRONIC
5574 7220 00	– CONTROL	– REGLAGE	241	MONO STICK
5573 5574 00	– CONTROL	– REGLAGE	243	
5573 6786 00	– – CONTROL	– – REGLAGE	245	
5590 0001 72	– GAUGE PANEL	– INSTRUMENT PANEL	247	
5580 0028 29	– – GAUGE PANEL	– – INSTRUMENT PANEL	250	MT2000
5575 1837 00	– – – CABLE	– – – KABEL	255	HARNESS, GEAR-INDICATOR
5574 9944 00	– GAUGE	– MÄTINSTRUMENT	257	FUEL GAUGE INST-ELECTRICAL
5575 0115 00	– – LEVEL SENSOR	– – NIVÅGIVARE	259	
–	– DRIVERS C.COMPL	– FÖRARSTOL KOMPL	261	SEAT INST-GRAMMER, LOWERED
5573 5569 00	– BINDER BOX	– PÄRMFACK	263	



OPERATORS AREA / MANÖVEROMRÅDE



Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5573 5570 00	1	DUMP CONTROL	TIPPREGLAGE	Page 235	
	5573 5571 00	1	THROTTLE CONTR.	GASREGLAGE	Page 237	
	5574 7220 00	1	CONTROL	REGLAGE	Page 241	MONO STICK
	5573 5574 00	1	CONTROL	REGLAGE	Page 243	
	5590 0001 72	1	GAUGE PANEL	INSTRUMENT PANEL	Page 247	
	5574 9944 00	1	GAUGE	MÄTINSTRUMENT	Page 257	FUEL GAUGE INST-ELECTRICAL
	—	1	DRIVERS C.COMPL	FÖRARSTOL KOMPL	Page 261	SEAT INST-GRAMMER, LOWERED
	5573 5569 00	1	BINDER BOX	PÄRMFACK	Page 263	



DUMP CONTROL / TIPPREGLAGE

5573 5570 00

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5573 6520 00	1	LEVER	SPAK		
2	5537 1079 00	2	BEARING	LAGER		BEARING-SC 2BOLT FLANGE
3	5530 5013 00	2	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 1 G5
4	5112 2803 18	2	SCREW	SKRUV		
5	5530 5017 00	2	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 1-1/4
6	5559 9232 00	6	WASHER	PLÅTBRICKA		3/8 HT
7	5530 7116 00	2	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
8	5573 6521 00	1	FLANGE	FLÄNS		
10	5563 3090 00	1	LEVER	SPAK		
11	5563 3142 00	1	FLAT KEY	PLATTKIL		
12	5530 5272 00	1	SET SCREW	STOPPSKRUV		SETSCR-ALN HD 1/4NC X 1/4
13	5573 6533 00	1	CONNECTING ROD	VEVSTAKE		
14	5530 7102 00	2	CLEVIS	KLYKA		
15	5530 6163 00	2	LOCK NUT	LÅSMUTTER		NUT-JAM 1/2 NF G5
16	5112 2392 40	2	LOCK WASHER	LÅSBRICKA		
17	5573 1076 00	1	LABEL	DEKAL		
18	5574 1028 00	1	LABEL	DEKAL		




VIEW A-A


THROTTLE CONTR. / GASREGLAGE

5573 5571 00


Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5540 8293 00	1	ACCEL. PEDAL	GASPEDAL	Page 239	PEDAL-ELECTRONIC
2	0144 3248 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 5/16 X 25 - 8.8 FZB
3	5559 9231 00	5	WASHER	PLÅTBRICKA		5/16 HT
4	0144 3248 03	3	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 5/16 X 25 - 8.8 FZB
5	5571 7641 00	1	MOUNT	FÄSTE		
6	5573 6549 00	1	PLATE	PLÅT		
7	5573 6551 00	1	PLATE	PLÅT		
8	0144 3286 03	8	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 22 - 8.8 FZB
9	5559 9232 00	8	WASHER	PLÅTBRICKA		3/8 HT



Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5540 4595 00	1	KIT	SATS		THREADLE PIN KIT, INCLUDES ITEMS 2,3,4,18.
	5540 4596 00	1	ROLLER	RULLE		INCLUDES ITEMS 2,19,21.
	5540 4597 00	1	KIT	SATS		SENSOR KIT, INCLUDES ITEMS 6,7,13,29,31.
	5540 8444 00	1	PEDAL	PEDAL		INCLUDES ALL ITEMS EXCEPT 4,10 ,16,18.
1	—	1	NOT DEL. SEP.	LEV. EJ SEP.		SEE 5540 8444 00 PEDAL
2	5536 4023 00	3	RING	RING		
3	5535 1047 00	2	BUSHING	BUSSNING		
4	5540 8440 00	2	BUSHING	BUSSNING		
6	5540 4586 00	2	SCREW	SKRUV		
7	5540 4587 00	2	SCREW	SKRUV		
10	5540 8442 00	1	COVER	KÅPA		
11	—	1	NOT DEL. SEP.	LEV. EJ SEP.		SEE 5540 8440 00 PEDAL
12	—	1	NOT DEL. SEP.	LEV. EJ SEP.		SEE 5540 8440 00 PEDAL
13	5540 8441 00	1	CABLE	KABEL		
16	5540 8443 00	1	PLATE	PLÅT		
18	—	1	NOT DEL. SEP.	LEV. EJ SEP.		SEE 5540 4595 00 THREADLE PIN KIT
19	—	1	NOT DEL. SEP.	LEV. EJ SEP.		SEE 5540 4596 00 ROLLER
20	—	1	NOT DEL. SEP.	LEV. EJ SEP.		SEE 5540 8444 00 PEDAL
21	—	1	NOT DEL. SEP.	LEV. EJ SEP.		SEE 5540 4596 00 ROLLER
22	—	2	NOT DEL. SEP.	LEV. EJ SEP.		SEE 5540 8444 00 PEDAL
23	—	1	NOT DEL. SEP.	LEV. EJ SEP.		SEE 5540 8444 00 PEDAL
24	—	2	NOT DEL. SEP.	LEV. EJ SEP.		SEE 5540 8444 00 PEDAL
29	—	1	NOT DEL. SEP.	LEV. EJ SEP.		SEE 5540 4597 00 SENSOR KIT
31	5540 4592 00	2	CABLE CLAMP	KABELKLAMMA		




Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	—	1	BRACKET	KONSOL		
2	—	1	BOTTOM PLATE	BOTTENPLÅT		
3	—	1	WRAPPER	SVEP		
4	5541 0834 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX SKT BH-M6X20 A4
5	5541 0840 00	4	SPRING WASHER	FJÄDERBRICKA		WASHER-SPRING LOCK M6 A4
6	0144 3249 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 5/16 X 32 - 8.8 FZB
7	5530 7552 00	4	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 5/16NC N
8	5559 9231 00	12	WASHER	PLÅTBRICKA		5/16 HT
9	5541 3641 00	4	NUT	MUTTER		NUT-CAGED 5/16 NC
10	0144 3246 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 5/16 X 19 - 8.8FZB
11	5572 2793 00	1	LABEL	DEKAL		STEERING CONTROL
12	5541 0462 00	1	PLUG	PROPP		
17	5541 0721 00	1	GROMMET	GENOMFÖRING		GROMMET-1/4 ID



CONTROL / REGLAGE**5573 5574 00**

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5573 6786 00	1	CONTROL	REGLAGE	Page 245	
2	0144 3284 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 16 - 8.8 FZB
3	5559 9232 00	4	WASHER	PLÅTBRICKA		3/8 HT
4	5112 2392 40	4	LOCK WASHER	LÅSBRICKA		
6	5572 2930 00	1	LABEL	DEKAL		LABEL ISO-SAHR BRAKE RELEASE
7	5572 3041 00	1	LABEL	DEKAL		LABEL ISO-BRAKE RELEASE HAZARD



CONTROL / REGLAGE

5573 6786 00


Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5573 6787 00	1	ATTACHMENT	FÄSTE		
2	5540 8095 00	1	KNOB	KNOPP		KNOB
3	5574 8208 00	1	ARM	ARM		
4	5559 9232 00	1	WASHER	PLÅTBRICKA		3/8 HT
5	5534 9435 00	1	ROD END	LÄNKHUVUD		
6	5530 6163 00	2	LOCK NUT	LÅSMUTTER		NUT-JAM 1/2 NF G5
7	5559 9234 00	4	WASHER	PLÅTBRICKA		1/2 HT
8	5571 9986 00	1	ROD END	LÄNKHUVUD		
9	5537 8872 00	1	SPRING	FJÄDER		
10	5531 0783 00	1	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1/2 NF N
11	5550 2851 00	1	THREADED ROD	GÄNGAD STÅNG		
12	5530 6177 00	2	LOCK NUT	LÅSMUTTER		NUT-JAM 1/4 NF G5
13	5530 7123 00	1	CLEVIS	KLYKA		
14	5573 6792 00	1	LEVER ARM	HÄVARM		
15	5530 7116 00	1	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
16	5530 5164 00	2	CLEVIS PIN	BULT		
17	5530 5106 00	2	FLAP COTTER	KLAFFSPRINT		COTTER PIN-1/16 X 3/4 STE

GAUGE PANEL / INSTRUMENT PANEL

5590 0001 72


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5580 0028 29	1	GAUGE PANEL	INSTRUMENT PANEL	Page 250	MT2000
3	—	2	MOUNT	FÄSTE		
4	5540 5634 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 1 SS
5	5540 0541 00	12	WASHER	PLÅTBRICKA		WASHER-FLAT 3/8 SS
7	5540 8302 00	8	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC SS
8	5540 0540 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 1-1/4

Fig. 1 of 2



5580 0028 29 1/2 ed.03

Fig. 2 of 2



(Sheet 1 of 3)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	—	1	CONTROL PANEL	INSTRUM. PANEL		
2	—	1	LABEL	DEKAL		
3	5541 9275 00	1	RECEPTACLE	HONUTTAG		
4	5541 9311 00	1	GASKET	PACKNING		
5	5540 8579 00	1	TRANSFORMER	TRANSFORMATOR		CONVERTER 24V TO 12V Ö 2.5A
6	5541 0563 00	3	BUSBAR	SAMLINGSSKENA		BUSS MODULE-21 TERMINAL
7	5541 6102 00	1	BRACKET	KONSOL		BUSS BLOCK & MOUNTING BRACKET
8	5540 5993 00	2	SOCKET	SOCKEL		SOCKET-RELAY
9	5540 5980 00	2	LOCK	LÅS		LOCK-RELAY HOUSING
10	5541 0860 00	2	RELAY	RELÄ		RELAY 24V, DIODE SUPPRESSION
11	5541 9285 00	1	GAUGE	MÄTINSTRUMENT		
12	5540 9956 00	1	KIT	SATS		DIAGNOSTIC CONNECTOR KIT
13	5540 5511 00	4	SCREW	SKRUV		SCREW-RHD MCH 04-40 X 3/4
14	5540 5510 00	4	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 04-40 G5
15	5540 6696 00	2	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 10-32 SS
16	5572 4005 00	1	GAUGE	MÄTINSTRUMENT		GAUGE-ENG OIL PRESS
17	5572 4004 00	1	GAUGE	MÄTINSTRUMENT		GAUGE-ENGINE WATER TEMP
18	5541 3593 00	1	TACHOMETER	VARVRÄKNARE		2' TACHOMETER 0-3000RPM
19	5572 4002 00	1	GAUGE	MÄTINSTRUMENT		GAUGE-VOLTMETER
20	5572 4007 00	1	GAUGE	MÄTINSTRUMENT		GAUGE-TRANSMISSION OIL TEMP
21	5572 4000 00	1	GAUGE	MÄTINSTRUMENT		GAUGE-HYD ACCUM PRESS
22	5572 4008 00	1	GAUGE	MÄTINSTRUMENT		GAUGE-TRANS PRESS
23	5575 7003 17	1	HOUR METER	TIMRÄKNARE		
24	5537 4284 00	2	PLUG	PROPP		
25	5541 9282 00	1	INDICATOR	INDIKATOR		
26	5541 9281 00	2	INDICATOR	INDIKATOR		
27	5541 9283 00	1	INDICATOR	INDIKATOR		
28	5574 6160 00	1	CABLE	KABEL		
29	5572 8907 00	1	LABEL	DEKAL		LABEL ISO-MMC
30	5541 0825 00	2	CAPSCREW	HUVUDSKRUV		CPSCR-PHILLIP PH--M6X16 A
31	0301 2121 01	2	PLAIN WASHER	RUNDBRICKA		6,4 / 12 X 1,6 -ISO A4-50
32	5541 0815 00	10	CAPSCREW	HUVUDSKRUV		M 4 16 C1 4,4 8,0 H 3,1 -

GAUGE/PANEL / INSTRUMENT/PANEL


5580 0028 29

(Sheet 2 of 3)


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
33	5541 0838 00	10	SPRING WASHER	FJÄDERBRICKA		WASHER-SPRING LOCK M4 A4
34	5541 5509 00	2	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT M6 A4 SS
35	0261 1090 11	10	NUT	MUTTER		M 4 - ISO A4-50
36	0300 0275 02	4	PLAIN WASHER	RUNDBRICKA		4,3 / 12 X 0.8 -ISO A4-50
39	5540 7372 00	1	CONTACT BLOCK	KONTAKTBLOCK		OPERATOR W/CONTACT BLOCK-G.E.
40	5536 4571 00	1	LENS	LINS		LENS-RED
41	3176 0005 47	1	LIGHT EMIT. DIO	LYSDIOD		
42	3217 0010 25	1	PALM GRIP	VRED		
43	3217 0005 02	3	CONTACT BLOCK	KONTAKTBLOCK		
44	3217 0010 13	2	PALM GRIP	VRED		
45	3217 0004 94	1	PALM GRIP	VRED		
46	3217 0004 93	1	LAMP INSERT	LAMPINSATS		
47	5541 0600 00	1	CONTROL LAMP	KONTROLLAMPA		
48	3217 0004 47	1	TRIGGER	TRYCKE		
49	3217 0004 96	3	CONTACT BLOCK	KONTAKTBLOCK		
50	3217 0004 44	1	TRIGGER	TRYCKE		
51	5541 3174 00	30	CABLE TIES	BUNTBAND		
52	5541 0462 00	2	PLUG	PROPP		
53	5540 8596 00	1	CONNECTOR	KONTAKTDON		
55	5540 8597 00	1	CONNECTOR LOCK	KONTAKTLÅS		SEC LOCK FOR PLUG SOCKT DT SER
56	5541 0347 00	1	CONNECTOR	KONTAKTDON		CONN-RECEPT-4 POS-PIN TYPE
57	5541 0354 00	1	CONNECTOR LOCK	KONTAKTLÅS		SECONDARY LOCK-4 POS-PIN TYPE
58	5541 0350 00	1	CONNECTOR	KONTAKTDON		CONN-PLUG-4 POS-SOCKET TYPE
59	5541 0345 00	1	CONNECTOR LOCK	KONTAKTLÅS		
60	5572 4009 00	8	WIRING	KABLAGE		CONNECTOR CABLE - GAUGES 5 PIN
61	5575 1837 00	1	CABLE	KABEL	Page 255	HARNESS, GEAR-INDICATOR
62	3217 0010 11	1	SWITCH	VRED		
63	5541 0679 00	1	ABSORBER	ABSORBATOR		MOISTURE ABSORBING PACKAGE
64	5541 0820 00	2	CAPSCREW	HUVUDSKRUV		CPSCR-PHILLIP PH-M5X16 A4
65	0291 1128 03	2	LOCK NUT	LÅSMUTTER		M 5 - ISO A4
66	0301 2118 01	2	PLAIN WASHER	RUNDBRICKA		5,3 / 10 X 1 - ISO A2-50
67	5540 9948 00	2	SEAL WASHER	TÄTNINGSBRICKA		WASHER, SEALING, 10
68	0301 2335 00	2	PLAIN WASHER	RUNDBRICKA		8,4 / 16 X 1,6 -HB200 FZB

(Sheet 3 of 3)


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
69	0291 1128 18	2	LOCK NUT	LÅSMUTTER		M 8 - 8 FZB / ISO 7040
70	3222 3060 87	1	GROUND BRAID	JORDFLÄTA		
71	5534 8254 00	23	SEAL PLUG	TÄTNINGSPLUGG		TERM-SEAL



Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5541 9503 00	1	CONNECTOR	KONTAKTDON		
2	5540 8593 00	1	CONNECTOR	KONTAKTDON		CONNECTOR RECEPTACLE 6-PIN
3	5540 4555 00	6	CABLE LUG	KABELSKO		TERM-PIN
4	5540 8594 00	1	CONNECTOR LOCK	KONTAKTLÅS		SEC LOCK FOR PIN RECEPT DT SER




FUEL TANK



INSTRUMENT PANEL


Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5575 0115 00	1	LEVEL SENSOR	NIVÄGIVARE	Page 259	
2	5572 4003 00	1	GAUGE	MÄTINSTRUMENT		GAUGE-FUEL
3	5572 4009 00	1	WIRING	KABLAG		CONNECTOR CABLE - GAUGES 5 PIN
4	0346 1002 05	1	PIPE CLAMP	RÖRKLAMMA		D=16 NORMA TYP RSGU
5	0301 2321 00	1	PLAIN WASHER	RUNDBRICKA		6,4 / 12 X 1,6 -HB200 FZB
6	0147 1245 03	1	SCREW, HEX HEAD	SKRUV, SEXKANT		M 6 X 14 - 8.8 FZB



LEVEL SENSOR / NIVÅGIVARE

5575 0115 00


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	—	1	GAUGE	MÄTINSTRUMENT		
2	5541 0272 00	1	CONNECTOR	KONTAKTDON		CONN. PLUG 2-SOCKET DT SERIES
3	5541 0273 00	1	CONNECTOR LOCK	KONTAKTLÅS		CONN. LOCK 2-SOCKET DT SERIES
4	5541 0368 00	1	BOOT	BOOT		
5	5540 8598 00	2	CABLE LUG	KABELSKO		TERM-SOCK



DRIVERS C.COMPL / FÖRARSTOL KOMPL

SEAT INST-GRAMMER, LOWERED

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5590 0002 88	1	DRIVERS CHAIR	FÖRARSTOL		
2	5572 8337 00	1	MOUNT	FÄSTE		
3	0144 3248 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 5/16 X 25 - 8.8 FZB
4	5530 7552 00	4	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 5/16NC N
5	5559 9231 00	4	WASHER	PLÅTBRICKA		5/16 HT
7	0144 3362 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 25 - 8.8 FZB
8	5559 9234 00	4	WASHER	PLÅTBRICKA		1/2 HT
10	5535 6250 00	1	KIT	SATS		KIT-FLOOR BELT W/HARDWARE




BINDER BOX / PÄRMFACK**5573 5569 00**

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5540 9942 00	1	BOX	LÅDA		BOX-OPERATORS MANUAL
2	0144 3207 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/4 X 22 - 8.8 FZB
4	5537 4605 00	4	WASHER	PLÅTBRICKA		WASHER-FLAT 1/4 FENDER
5	5541 1249 00	1	BELT	REM		
6	0144 3209 03	1	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/4 X 32 - 8,8 FZB
7	5559 9230 00	6	WASHER	PLÅTBRICKA		1/4 HT
8	5530 7055 00	5	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1/4 NC NE

STEERING SYSTEM / STYRSYSTEM
LIST OF CONTENTS


Part no Detaljnr	Description	Benämning	See page Se sida	Remarks Anmärkning
–	STEERING SYSTEM	STYRSYSTEM	267	
5574 4753 00	– CYLINDER SET	– CYLINDERSATS	269	CYLINDER INST-STEERING
5574 1198 00	– – CYLINDER ASSY	– – CYLINDER KPL	271	
5575 7006 00	– HYDR. SYSTEM	– HYDRAULSYSTEM	273	STEERING
5541 4375 00	– – HYDRAULIC PUMP	– – HYDRAULPUMP	277	PUMP-HYDRAULIC 34GPM
5575 7003 16	– – JOYSTICK	– – JOYSTICK	279	
5575 7003 15	– – – VALVE	– – – VENTIL	281	PILOT CONTROL
5573 7009 00	– – – CONTROL	– – – REGLAGE	283	HANDLE-ROCK TOUGH CONTROL
5537 5677 00	– – VALVE	– – VENTIL	285	
5540 0882 00	– – VALVE	– – VENTIL	287	VALVE-PILOT PRESSURE

STEERING SYSTEM / STYRSYSTEM



STEERING SYSTEM / STYRSYSTEM

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5574 4753 00	1	CYLINDER SET	CYLINDERSATS	Page 269	CYLINDER INST-STEERING
	5575 7006 00	1	HYDR. SYSTEM	HYDRAULSYSTEM	Page 273	STEERING




CYLINDER SET / CYLINDERSATS

5574 4753 00

CYLINDER INST-STEERING


Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5574 1198 00	2	CYLINDER ASSY	CYLINDER KPL	Page 271	
2	5574 4754 00	1	TUBE	RÖR		
3	5574 4755 00	1	TUBE	RÖR		
4	5574 4756 00	1	TUBE	RÖR		
5	5574 4757 00	1	TUBE	RÖR		
6	0144 3379 03	4	HEX. HEAD SCREW	6-KANTSKRUV		UNC 1/2 13 114 22 32 7,9
7	5530 7551 00	4	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1/2 NC N
8	5559 9234 00	8	WASHER	PLÅTBRICKA		1/2 HT
9	5537 1136 00	2	CLAMP	KLAMMA		
10	5574 4758 00	2	MOUNT	FÄSTE		
11	5572 9426 00	2	PIN	TAPP		
12	5572 9427 00	2	PIN	TAPP		
13	0570 7041 13	4	ELBOW NIPPLE	VINKELNIPPEL		B1 14 16 UNS 25,40 1 14 U
14	5572 8185 00	12	SPACER RING	DISTANSRING		3.2MM
15	0663 9055 01	4	O-RING	O-RING		12,42X 1,78 90 SHORE



CYLINDER ASSY / CYLINDER KPL

5574 1198 00

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5541 3662 00	1	SEAL KIT	TÄTNINGSSATS		
1	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
2	5541 3344 00	1	LOCK NUT	LÅSMUTTER		
3	—	2	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
4	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
5	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
6	5541 3742 00	1	PISTON	KOLV		
7	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
8	5541 3941 00	1	CYL.BARREL	CYLINDERRÖR		
9	5541 5596 00	1	PISTON ROD	KOLVSTÅNG		
10	5541 3741 00	1	CYLINDER COVER	CYLINDERLOCK		
11	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
12	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
13	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
14	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
15	5541 1438 00	8	CAPSCREW	HUVUDSKRUV		
16	5541 1439 00	8	WASHER	BRICKA		
17	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
18	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
19	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
20	5541 3359 00	1	SNAP RING	FJÄDER RING		
21	5541 5490 00	1	BUSHING	BUSSNING		
22	5541 5491 00	1	BUSHING	BUSSNING		




5575 7006 00 1/2 ED.01

(Sheet 1 of 2)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5541 4375 00	1	HYDRAULIC PUMP	HYDRAULPUMP	Page 277	PUMP-HYDRAULIC 34GPM
2	5559 8586 00	1	GASKET	PACKNING		
3	5575 7003 16	1	JOYSTICK	JOYSTICK	Page 279	
4	5535 8859 00	1	VALVE	VENTIL		VALVE-PRIORITY FLOW CONTR
5	5537 5677 00	1	VALVE	VENTIL	Page 285	
6	5540 0882 00	1	VALVE	VENTIL	Page 287	VALVE-PILOT PRESSURE
8	5571 9008 00	1	MANIFOLD	SAMLINGSRÖR		MANIFOLD-STEERING
13	5536 6300 00	1	SLEEVE	HYLSA		
14	0144 3365 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 38 - 8.8 FZB
15	5112 2465 26	2	LOCK WASHER	LÅSBRICKA		
17	5559 9231 00	3	WASHER	PLÅTBRICKA		5/16 HT
19	0144 3363 03	16	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 32 - 8.8 FZB
20	5112 2465 26	16	LOCK WASHER	LÅSBRICKA		
21	5530 8318 00	3	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 5/16NC X 2-1/2
22	5112 2392 40	6	LOCK WASHER	LÅSBRICKA		
23	5530 6046 00	2	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 2-3/4
25	5531 0417 00	2	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 2-1/2
26	5559 9232 00	4	WASHER	PLÅTBRICKA		3/8 HT
27	5537 5196 00	1	COUPLE	KOPPEL		COUPLER-QD FEMALE,8 ORS
30	0144 3292 03	2	HEXAGON SCREW	SEXKANTSSKRUV		UNC 3/8 - 51 16,5 25 6 14
31	0570 7000 06	1	STRAIGHT NIPPLE	RAK NIPPEL		B1 22 25 UN 1 7/16-12 UN
32	0570 7025 08	2	NIPPLE	NIPPEL		B1 8-10 UNF 11/16-16
33	5501 1746 00	1	BUSHING	BUSSNING		BUSHING (O-RING/O-RING)
34	5500 7556 00	3	COUPLE	KOPPEL		COUPLER-QD MALE,6 ORB,W/C
35	0570 7049 08	1	T-NIPPLE	T-NIPPEL		B2 22 25 UN -2A 36,51 1 7
36	0570 7041 18	1	ELBOW NIPPLE	VINKELNIPPEL		B1 18 20 UN 30,16 1 3/16
37	5500 2176 00	4	NIPPLE	NIPPEL		ELBOW-45 (ORS/O-RING)
38	5501 1786 00	3	NIPPLE	NIPPEL		ELBOW-90 (ORS/O-RING)
39	0570 7049 03	1	T-NIPPLE	T-NIPPEL		B2 12 - UNF-2A 20,64 13/1
40	0570 7041 15	4	ELBOW NIPPLE	VINKELNIPPEL		B1 8 10 UNF 17,46 11/16 1
41	5501 1742 00	1	BUSHING	BUSSNING		BUSHING (O-RING/O-RING)
42	5500 9687 00	2	PLUG	PROPP		PLUG-HEX (O-RING)

(Sheet 2 of 2)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
43	0570 7025 20	2	NIPPLE	NIPPEL		B1 18-20 UN 1 3/16-12
44	5501 1839 00	2	NIPPLE	NIPPEL		ELBOW-45 (ORS/O-RING)
48	5500 7884 00	1	PLUG	PROPP		PLUG-INV (O-RING)
58	0638 0521 00	2	FLANGE HALF	FLÄNSHALVA		25 X 45,24 SAE 1 PR.345
59	5533 2727 00	1	O-RING	O-RING		O-RING (VITON 16-SPFL)
60	0144 3288 03	4	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 32 - 8.8 FZB
61	5533 2729 00	4	O-RING	O-RING		O-RING (VITON 24-SPFL)
62	3176 7922 00	8	FLANGE HALF	FLÄNSHALVA		38 61,09
64	5501 1859 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/O-RING) LON
66	3176 7868 06	1	PLUG	PROPP		3/4-16 UNF, TYPE A,STEEL
67	5501 7095 00	2	NIPPLE	NIPPEL		
68	0570 7041 16	1	ELBOW NIPPLE	VINKELNIPPEL		B1 8 10 UNF 17,46 11/16 1
101	5505 8687 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
102	5507 2072 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
104	5506 2965 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
105	5500 9041 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
106	5507 2373 00	1	HOSE ASSEMBLY	SLANGLEDNING		1C00116GGG0810A
109	5507 3059 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
110	5507 3059 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
111	5507 4165 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
112	5506 5984 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
113	5506 5984 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
114	5506 5984 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
115	5506 5984 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
116	5507 3060 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
119	5575 7004 28	1	HOSE ASSEMBLY	SLANGLEDNING		
120	5505 0761 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY




HYDRAULIC PUMP / HYDRAULPUMP

5541 4375 00

PUMP-HYDRAULIC 34GPM

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5540 2583 00	1	COVER	KÅPA		
2	5536 5409 00	2	SEAL RING	TÄTNINGSRING		
3	5536 5408 00	4	BEARING	LAGER		
4	5534 5788 00	1	SEAL	TÄTNING		
5	5535 4973 00	2	PLATE	PLÅT		
6	5537 4037 00	12	SEAL	TÄTNING		
7	5536 4792 00	1	PLUG	PROPP		
8	5540 7048 00	1	HOUSING	HUS		
9	5535 4968 00	1	HOUSING	HUS		
10	5534 5791 00	2	GASKET	PACKNING		
11	5535 4967 00	4	PIN	TAPP		PIN
12	5541 4680 00	1	CROSS	KORS		
13	5537 5542 00	4	WASHER	BRICKA		






5575 7003 16 ED.01

JOYSTICK / JOYSTICK

5575 7003 16

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5575 7003 15	1	VALVE	VENTIL	Page 281	PILOT CONTROL
2	5573 7009 00	1	CONTROL	REGLAGE	Page 283	HANDLE-ROCK TOUGH CONTROL
3	5573 4655 00	1	NUT	MUTTER		
4	—	1	ADAPTER	ADAPTER		
5	5530 6170 00	1	LOCK NUT	LÅSMUTTER		NUT-JAM 1/2 NC G5




ISO SYMBOL

5575 7003 15 ed.02

VALVE / VENTIL**5575 7003 15**

PILOT CONTROL


Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5575 7007 18	1	VALVE	VENTIL		
2	5575 7007 19	1	STUD	PINNSKRUV		



CONTROL / REGLAGE**5573 7009 00**

HANDLE-ROCK TOUGH CONTROL



Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
2	5541 0943 00	1	SWITCH	OMKOPPLARE		SWITCH KIT-HANDLE



VALVE / VENTIL

5537 5677 00

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5537 4546 00	1	STUD	PINNBULT		
2	5537 8092 00	1	CROSS	KORS		
3	5537 4551 00	1	COVER	KÅPA		
4	5537 7009 00	1	KIT	SATS		P.O.B. SERVICE KIT
5	5537 8093 00	1	VALVE	VENTIL		
6	5537 4560 00	1	SEAL KIT	TÄTNINGSSATS		MAIN RELIEF SEAL KIT
7	5537 3211 00	2	RELIEF VALVE	AVLASTN.VENTIL		RELIEF
8	5537 5077 00	1	KIT	SATS		
9	5537 5078 00	1	SEAL KIT	TÄTNINGSSATS		KIT-SEAL
10	5537 7012 00	1	ACTUATOR	VRIDMOTOR		ACTUATOR
11	5537 7010 00	1	ACTUATOR	VRIDMOTOR		ACTUATOR
12	5537 7011 00	1	SEAL KIT	TÄTNINGSSATS		SEAL KIT
13	5537 7006 00	1	VALVE	VENTIL		VALVE SECT



VALVE / VENTIL

5540 0882 00

VALVE-PILOT PRESSURE

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5540 1692 00	1	VALVE	VENTIL		
2	5540 1693 00	1	SEAL KIT	TÄTNINGSSATS		
3	5540 1694 00	1	CARTRIDGE	PATRON		
4	5537 8125 00	1	SEAL KIT	TÄTNINGSSATS		

DUMP SYSTEM / TIPP SYSTEM
LIST OF CONTENTS


Part no Detaljnr	Description	Benämning	See page Se sida	Remarks Anmärkning
–	DUMP SYSTEM	TIPP SYSTEM	291	
5564 0934 00	– CYLINDER SET	– CYLINDERSATS	293	DUMPING
5500 6845 00	– – CYLINDER ASSY	– – CYLINDER KPL	295	
5574 0338 00	– HYDR. SYSTEM	– HYDRAULSYSTEM	298	DUMPING
5507 2064 00	– – HOSE SET	– – SLANGSATS	301	DUMP SYSTEM
5532 9331 00	– – VALVE	– – VENTIL	303	

DUMP SYSTEM / TIPP SYSTEM



DUMP SYSTEM / TIPP SYSTEM

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5564 0934 00	1	CYLINDER SET	CYLINDERSATS	Page 293	DUMPING
	5574 0338 00	1	HYDR. SYSTEM	HYDRAULSYSTEM	Page 298	DUMPING




CYLINDER SET / CYLINDERSATS

5564 0934 00

DUMPING

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5500 6845 00	2	CYLINDER ASSY	CYLINDER KPL	Page 295	
2	5557 9836 00	2	PIN	TAPP		
3	5562 9588 00	2	PIN	TAPP		
4	0144 3363 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 32 - 8.8 FZB
5	0144 3345 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 89 - 8.8 FZB
6	5531 0060 00	2	LOCK NUT	LÅSMUTTER		NUT-OVALOK 1/2 NC GR.C
8	5500 6816 00	2	SPACER TUBE	DISTANSRÖR		
9	5530 5145 00	4	GREASE NIPPLE	FETTNIPPEL		GREASE FITTING-1/8(STRAIG
10	5500 6139 00	2	WASHER	PLÅTBRICKA		WASHER-FLAT 1/2 HT 1-3/8
11	5559 9232 00	8	WASHER	PLÅTBRICKA		3/8 HT
12	0144 3288 03	8	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 32 - 8.8 FZB
13	5558 2323 00	4	BAR	STÅNG		
14	5565 2241 00	2	GUARD	SKYDD		




CYLINDER ASSY / CYLINDER KPL

5500 6845 00


Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5535 1809 00	1	CYLINDER SET	CYLINDERSATS		REPAIR KIT, REF. 7-11, 13-17, 19-20
1	5564 0936 00	1	CYL.BARREL	CYLINDERRÖR		
2	5564 0939 00	1	BARREL	HYLSA		
3	5564 0949 00	1	BARREL	HYLSA		
4	5564 0941 00	1	PACKING	TÄTNING		
5	5557 9331 00	1	PACKING	TÄTNING		
6	5557 9332 00	1	ROD END	LÄNKHUVUD		
7	5535 0522 00	1	SEAL	TÄTNING		SEAL
8	5535 0898 00	2	RING	RING		RING-WEAR
9	5534 5753 00	2	RING	RING		RING
10	5535 0520 00	1	O-RING	O-RING		ORING
11	5535 0525 00	1	RING	RING		RING-WIPER
12	5535 0522 00	1	SEAL	TÄTNING		SEAL
13	5535 3251 00	1	RING	RING		RING-WIPER
14	5535 0526 00	1	RING	RING		RING-WEAR
15	5534 0144 00	1	O-RING	O-RING		
16	5535 0521 00	1	SEAL	TÄTNING		SEAL
17	5535 0899 00	1	RING	RING		RING-WIPER
19	5535 0518 00	1	RING	RING		RING-BACK UP
20	5535 0519 00	1	RING	RING		RING-BACKUP
21	5533 2883 00	1	BUSHING	BUSSNING		BUSHING-BALL

Fig. 1 of 2



5574 0338 00 bl.1/2 ed.05

Fig. 2 of 2



5574 0338 00 bl.2/2 ed.05


(Sheet 1 of 2)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
0	5507 2064 00	1	HOSE SET	SLANGSATS	Page 301	DUMP SYSTEM
1	5532 9331 00	1	VALVE	VENTIL	Page 303	
2	5565 2848 00	1	JUNCTION BLOCK	KOPPLINGSBLOCK		
3	5503 0024 00	1	ADAPTER FLANGE	ADAPTERFLÄNS		
4	5500 9416 00	1	NIPPLE	NIPPEL		ELBOW-90 (SPL FLNG/SPL FLNG)
5	5501 7094 00	1	NIPPLE	NIPPEL		
6	0570 7041 14	1	ELBOW NIPPLE	VINKELNIPPEL		B1 22 25 UN 36,51 1 7/16
7	0570 7017 04	1	NIPPLE	NIPPEL		A 18-20 UN 1 3/16-12
8	0570 7017 09	1	NIPPLE	NIPPEL		A 22-25 UN 1 7/16-12
9	0570 7017 12	1	BULKHEAD CONN.	SKOTTGENOMGÅNG		C2 22 25 UN 36,51 1 7/16
10	0570 7017 11	1	BULKHEAD CONN.	SKOTTGENOMGÅNG		C2 18 20 UN 30,16 1 3/16
11	0570 7057 07	2	REDUCING BUSHIN	REDUCERNIPPEL		B 22 25 UN -2A 30,16 1 3/16
12	0570 7017 04	2	NIPPLE	NIPPEL		A 18-20 UN 1 3/16-12
14	5573 6220 00	2	FITTING	FÖRSKRUVNING		
15	5506 2797 00	2	NIPPLE	NIPPEL		ELBOW-90 (ORS/PIPE)
17	0570 7017 03	2	NIPPLE	NIPPEL		A 14-16 UNS 1 -14
19	5500 7883 00	1	PLUG	PROPP		PLUG-INV (O-RING)
20	5559 9231 00	2	WASHER	PLÅTBRICKA		5/16 HT
21	5112 2466 39	12	LOCK WASHER	LÅSBRICKA		CAPSCREW - ADJUSTING NUT LOCK
22	5112 2465 26	4	LOCK WASHER	LÅSBRICKA		
23	5112 2392 40	12	LOCK WASHER	LÅSBRICKA		
24	0144 3288 03	12	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 32 - 8.8 FZB
25	5530 6084 00	8	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 7/16NC X 1-1/2
26	5530 6121 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 1/2 NC X 1-1/2
27	5530 5097 00	3	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 1/2 NC X 5 G5
28	5530 7551 00	3	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1/2 NC N
29	5530 9218 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 7/16NC X 3-1/4
30	5533 2727 00	3	O-RING	O-RING		O-RING (VITON 16-SPFL)
31	5533 2728 00	4	O-RING	O-RING		O-RING (VITON 20-SPFL)
32	5533 2731 00	1	O-RING	O-RING		O-RING (VITON 32-SPFL)
34	0638 0521 00	6	FLANGE HALF	FLÄNSHALVA		25 X 45,24 SAE 1 PR.345
35	0638 0527 00	6	FLANGE HALF	FLÄNSHALVA		32 X 51,59 SAE 1 1/4 P276

HYDR. SYSTEM / HYDRAULSYSTEM**5574 0338 00**

(Sheet 2 of 2)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
37	5112 2392 41	2	SCREW	SKRUV		
41	5573 6221 00	1	PLATE	PLÅT		
42	5573 6222 00	1	PLATE	PLÅT		
43	5559 9232 00	3	WASHER	PLÅTBRICKA		3/8 HT
44	5112 2803 18	3	SCREW	SKRUV		
50	5500 7556 00	1	COUPLE	KOPPEL		COUPLER-QD MALE,6 ORB,W/C
51	5501 1825 00	2	NIPPLE	NIPPEL		ELBOW-90 (ORS/PIPE)




5574 0338 00 bl.1/2 ed.05

HOSE SET / SLANGSATS

5507 2064 00

DUMP SYSTEM

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
101	5504 7646 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
102	5507 3056 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
103	5507 3951 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
104	5507 4353 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
105	5507 4159 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
106	5507 4160 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
107	5507 4161 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
108	0574 7802 71	1	HOSE ASSEMBLY	SLANGLEDNING		16 800 C1 22,4 UNS 1 -14
109	0574 7802 71	1	HOSE ASSEMBLY	SLANGLEDNING		16 800 C1 22,4 UNS 1 -14
110	5507 4162 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
111	5507 4163 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
112	0574 7802 70	1	HOSE ASSEMBLY	SLANGLEDNING		19 740 C1 21,0 UN 1 3/16-
113	0574 7802 70	1	HOSE ASSEMBLY	SLANGLEDNING		19 740 C1 21,0 UN 1 3/16-
114	5506 9114 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
115	5506 9114 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
116	5507 4164 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY



VALVE / VENTIL

5532 9331 00

(Sheet 1 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
0	5534 0265 00	1	SEAL KIT	TÄTNINGSSATS		
0	5534 0272 00	1	SEAL KIT	TÄTNINGSSATS		
1	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
2	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
3	5533 6394 00	1	POPPET VALVE	SÄTESVENTIL		
4	5533 6391 00	1	SEAT	SÄTE		
5	5533 6392 00	1	SEAT	SÄTE		
6	5533 6405 00	1	RETAINER	FASTHÅLLARE		
7	5533 6412 00	2	RETAINER	FASTHÅLLARE		
8	5533 6907 00	1	PLUNGER	PLUNGE		
9	5533 6593 00	1	PACKING	TÄTNING		
10	5533 6954 00	1	CAP	HUV		
11	5534 7360 00	1	HOUSING	HUS		
12	5533 7035 00	1	RETAINER	FASTHÅLLARE		
13	5540 8538 00	1	PLATE	PLÅT		
14	5533 7029 00	1	PLATE	PLÅT		
15	5533 8206 00	1	SPACER RING	DISTANSRING		
16	5533 7216 00	1	PLUG	PROPP		
17	5532 5179 00	4	CAPSCREW	HUVUDSKRUV		
18	5532 5222 00	4	CAPSCREW	HUVUDSKRUV		CPSCR-SKT0211220000
19	5532 5267 00	1	SCREW	SKRUV		
20	5532 5270 00	1	NUT	MUTTER		
21	5532 5272 00	1	NUT	MUTTER		
22	5532 5286 00	8	WASHER	BRICKA		
23	5112 2467 48	1	PLUG	PROPP		CLARK 40K-02
24	5532 5205 00	11	BALL	KULA		
25	5541 4036 00	1	O-RING	O-RING		
26	5532 5321 00	2	RING	RING		
27	5532 5345 00	2	WASHER	BRICKA		
28	5532 5367 00	1	SPRING	FJÄDER		
29	5532 5380 00	1	SPRING	FJÄDER		
30	5532 5390 00	1	SPRING	FJÄDER		

(Sheet 2 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
31	5532 5396 00	1	RING	RING		
32	5532 5208 00	2	QUAD-RING	X-RING		
33	5532 5212 00	1	SEAL	TÄTNING		
34	5532 8589 00	1	SEAL	TÄTNING		
35	5533 8208 00	1	SPACER RING	DISTANSRING		
36	5533 6397 00	1	RETAINER	FASTHÅLLARE		
37	5533 6403 00	1	GUIDE	STYRNING		
38	5533 6958 00	1	SOCKET	SOCKEL		
39	5533 6959 00	1	CAP	HUV		
40	5533 6969 00	1	EYE	ÖGLA		
41	5533 6909 00	1	VALVE	VENTIL		
42	5533 7182 00	1	PLUNGER	PLUNGE		
43	5532 5423 00	1	PIN	TAPP		
44	5532 5320 00	1	O-RING	O-RING		
45	5532 5373 00	1	SPRING	FJÄDER		
46	5540 8331 00	1	SPRING	FJÄDER		

BRAKE SYSTEM / BROMSSYSTEM
LIST OF CONTENTS


Part no Detaljnr	Description	Benämning	See page Se sida	Remarks Anmärkning
–	BRAKE SYSTEM	BROMSSYSTEM	307	
5574 0344 00	– HYDR. SYSTEM	– HYDRAULSYSTEM	310	BRAKE COOL SYSTEM
5574 0342 00	– BRAKE SYSTEM	– BROMSSYSTEM	314	PLMG-BRAKE,S50,457,SS,115'
5540 1355 00	– – HYDRAULIC PUMP	– – HYDRAULPUMP	319	PUMP-HYDRAULIC
5537 7888 00	– – VALVE	– – VENTIL	321	ACCUMULATOR CHARGE
5540 4633 00	– – ACCUMULATOR	– – ACKUMULATOR	323	ACCUMULATOR-1 GAL
5541 0093 00	– – FOOT BRAKE	– – FOTBROMS	325	
5541 7067 00	– – HAND PUMP	– – HANDPUMP	327	



BRAKE SYSTEM / BROMSSYSTEM




Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5574 0344 00	1	HYDR. SYSTEM	HYDRAULSYSTEM	Page 310	BRAKE COOL SYSTEM
	5574 0342 00	1	BRAKE SYSTEM	BROMSSYSTEM	Page 314	PLMG-BRAKE,S50,457,SS,115'

Fig. 1 of 2



5574 0344 00 1/2 ed.06

Fig. 2 of 2



(Sheet 1 of 2)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
5	0570 7025 24	1	NIPPLE	NIPPEL		B1 18-20 UN 1 3/16-12
6	0570 7041 19	1	ELBOW NIPPLE	VINKELNIPPEL		B1 18 20 UN 30,16 1 3/16
7	5500 2176 00	2	NIPPLE	NIPPEL		ELBOW-45 (ORS/O-RING)
8	0570 7025 20	3	NIPPLE	NIPPEL		B1 18-20 UN 1 3/16-12
9	5500 7556 00	1	COUPLE	KOPPEL		COUPLER-QD MALE,6 ORB,W/C
10	5500 4094 00	1	PLUG	PROPP		PLUG-INV (O-RING)
11	5501 1859 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/O-RING) LON
12	5537 7987 00	1	CARTRIDGE	PATRON		
13	5565 4201 00	1	JUNCTION BLOCK	KOPPLINGSBLOCK		
15	5500 7585 00	2	TEE	T-RÖR		TEE-RUN (ORS/ORS/ORS) BLK
16	5501 1751 00	4	NIPPLE	NIPPEL		CONNECTOR (ORS/O-RING)
17	0570 7025 10	4	NIPPLE	NIPPEL		B1 12 UNF 13/16-16
19	0570 7041 18	3	ELBOW NIPPLE	VINKELNIPPEL		B1 18 20 UN 30,16 1 3/16
20	5500 7586 00	2	TEE	T-RÖR		TEE-RUN (ORS/ORS/ORS) BLK
21	5501 1797 00	2	CONNECTOR	KONTAKTDON		CONNECTOR (ORS/ORS) BULKH
22	5500 7569 00	2	CONNECTOR	KONTAKTDON		CONNECTOR (ORS/ORS) BULKH
23	5501 1783 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/O-RING)
24	0570 7041 17	1	ELBOW NIPPLE	VINKELNIPPEL		B1 14 16 UNS 25,40 1 14 U
25	5501 1859 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/O-RING) LON
30	5531 0417 00	2	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 2-1/2
31	0301 2343 00	2	PLAIN WASHER	RUNDBRICKA		10,5 / 18 X 2 - HB200 FZB
33	5573 6420 00	2	MOUNT	FÄSTE		
35	5540 7807 00	1	OIL COOLER	OLJEKYLARE		
36	0144 3297 03	8	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 76 - 8.8 FZB
37	5530 7116 00	8	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
38	5559 9232 00	16	WASHER	PLÅTBRICKA		3/8 HT
40	5541 2578 00	4	CLAMP	KLAMMA		
101	5507 3074 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
102	5580 0045 91	1	HOSE ASSEMBLY	SLANGLEDNING		1C01265KKK1500A
103	5580 0046 72	1	HOSE ASSEMBLY	SLANGLEDNING		1C01265KKK1800A
104	5505 8460 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
105	5507 3076 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY

HYDR. SYSTEM / HYDRAULSYSTEM**5574 0344 00**

(Sheet 2 of 2)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
106	0574 7802 69	1	HOSE ASSEMBLY	SLANGLEDNING		12 3800 B1 34,5 UNF 13/16
107	5507 2720 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
108	5506 7404 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
109	5506 9457 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
110	5506 9458 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
111	0574 7802 94	1	HOSE ASSEMBLY	SLANGLEDNING		16 3800 B1 10,5 UNS 1 -14
112	5507 1620 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
113	5506 6854 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
114	5507 3180 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
115	5507 3181 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
116	5506 9461 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
117	5575 7002 99	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
118	5506 9251 00	1	HOSE ASSEMBLY	SLANGLEDNING		1C01266JJJ0800A
119	5507 3077 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
120	5507 4170 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
121	5505 7504 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY

54 53 04

ACCUMULATOR CHARGE VALVE

06

SEE BRAKE COOLING SYSTEM

05

102

53

52

51

03

01

50

52

53

02

101

27

28

29

56

47

57

104

37

2000 PSI

HYDRAULIC HAND PUMP

34

33

17

72

74

76

71

30

210

HANDLE

VALVE CONTROL LEVER

TURN TO OPEN

TURN TO CLOSE

PUMP OUTLET 1/4 NPT

PUMP INLET/RETURN 1/4 NPT (HIDDEN FROM VIEW)

HAND PUMP

MINERAL BASE FLUIDS ONLY

NOTE: PRECHARGE ACCUMULATORS TO 1200 PSI

53

64

201

202

14

62

63

77

203

06

110

129

49

109

12

07

11

78

79

08

10

60

61

53

REF ELECTRICAL SYSTEM

ACCU TRANSFORMER

BRAKE PRESSURE J-BLOCK

125

126

116

28

24

28

117

25

25

LEFT HUB

FRONT AXLE

RIGHT HUB

TO HYDRAULIC TANK (BRAKE COOLING CIRCUIT)

FROM CHECK VALVE (BRAKE COOLING CIRCUIT)

19

53

61

60

16

SVC BRAKE J-BLOCK

22

09

20

36

114

120

115

124

23

122

28

127

121

24

28

123

25

25

LEFT HUB

REAR AXLE

RIGHT HUB

TO HYDRAULIC TANK (BRAKE COOLING CIRCUIT)

FROM CHECK VALVE (BRAKE COOLING CIRCUIT)

06

103

108

07

38

41

40

16

65

67

69

68

66

113

112

39

HYD TANK

08




08

26

BRAKE CONTROL VALVE

5574 0342 00 bl.1/2 ed.10

Fig. 2 of 2



5574 0342 00 bl.2/2 ed.10

(Sheet 1 of 3)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5540 1355 00	1	HYDRAULIC PUMP	HYDRAULPUMP	Page 319	PUMP-HYDRAULIC
2	5533 2727 00	2	O-RING	O-RING		O-RING (VITON 16-SPFL)
3	5533 2724 00	1	O-RING	O-RING		O-RING (VITON 12-SPFL)
4	5537 7888 00	1	VALVE	VENTIL	Page 321	ACCUMULATOR CHARGE
5	0570 7041 18	1	ELBOW NIPPLE	VINKELNIPPEL		B1 18 20 UN 30,16 1 3/16
6	5500 2155 00	5	NIPPLE	NIPPEL		ELBOW-90 (ORS/O-RING)
7	5501 1781 00	3	NIPPLE	NIPPEL		ELBOW-90 (ORS/O-RING)
8	5500 2142 00	4	CONNECTOR	KONTAKTDON		CONNECTOR (ORS/O-RING)
9	5500 2176 00	1	NIPPLE	NIPPEL		ELBOW-45 (ORS/O-RING)
10	5501 1779 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/O-RING)
11	5500 5088 00	1	BUSHING	BUSSNING		BUSHING (O-RING/PIPE)
12	5500 7564 00	1	CONNECTOR	KONTAKTDON		CONNECTOR (ORS/O-RING)
14	5540 4633 00	2	ACCUMULATOR	ACKUMULATOR	Page 323	ACCUMULATOR-1 GAL
15	5500 7567 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/O-RING)
16	5500 7884 00	2	PLUG	PROPP		PLUG-INV (O-RING)
17	5501 1843 00	1	NIPPLE	NIPPEL		ELBOW-45 (ORS/PIPE)
19	5500 7556 00	1	COUPLE	KOPPEL		COUPLER-QD MALE,6 ORB,W/C
20	5500 2153 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/O-RING)
21	5500 9416 00	1	NIPPLE	NIPPEL		ELBOW-90 (SPL FLNG/SPL FLNG)
22	5501 1833 00	1	NIPPLE	NIPPEL		ELBOW-45 (ORS/O-RING)
23	5501 1810 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/ORS) BULKHE
24	5500 2180 00	2	TEE	T-RÖR		TEE-RUN (ORS/ORS/ORS) BLK
25	5500 2140 00	4	CONNECTOR	KONTAKTDON		CONNECTOR (ORS/O-RING)
26	5541 0093 00	1	FOOT BRAKE	FOTBROMS	Page 325	
27	5500 9561 00	1	ADAPTER FLANGE	ADAPTERFLÄNS		
28	5500 2139 00	5	CONNECTOR	KONTAKTDON		CONNECTOR (ORS/O-RING)
29	5533 2728 00	1	O-RING	O-RING		O-RING (VITON 20-SPFL)
30	5541 7067 00	1	HAND PUMP	HANDPUMP	Page 327	
33	5535 7219 00	1	VALVE	VENTIL		VALVE-CHECK
34	5500 4958 00	1	NIPPLE	NIPPEL		ELBOW-90 (PIPE/PIPE)
36	0570 7017 01	1	NIPPLE	NIPPEL		A 8-10 UNF 11/16-16
37	0570 7041 24	1	ELBOW NIPPLE	VINKELNIPPEL		E 6 UNF 9/16-18

BRAKE SYSTEM / BROMSSYSTEM

5574 0342 00

(Sheet 2 of 3)


Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
38	5500 2164 00	1	PIPE CONNECTION	RÖRANSLUTNING		CONNECTOR (ORS/PIPE)
39	5501 1858 00	1	NIPPLE	NIPPEL		ELBOW-90 (ORS/O-RING) LON
40	5500 5088 00	1	BUSHING	BUSSNING		BUSHING (O-RING/PIPE)
41	5500 4988 00	1	TEE	T-RÖR		TEE-RUN (PIPE/PIPE/PIPE)
43	5570 5263 00	4	FITTING	FÖRSKRUVNING		
44	5533 5496 00	4	BLEEDER SCREW	AVLUFTN.SKRUV		
47	5530 8478 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 7/16NC X 2-1/4
48	5500 4966 00	4	NIPPLE	NIPPEL		ELBOW-90 (PIPE/PIPE)
49	5500 2149 00	1	TEE	T-RÖR		TEE-RUN (ORS/O-RING)
50	5535 5536 00	4	FLANGE	FLÄNS		CLAMP-SPLIT FLANGE (16)
51	5536 1748 00	2	FLANGE	FLÄNS		CLAMP-SPLIT FLANGE (12)
52	5530 5017 00	18	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 1-1/4
53	5112 2392 40	24	LOCK WASHER	LÅSBRICKA		
54	5530 7531 00	2	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 4 G5
56	5540 5197 00	2	FLANGE	FLÄNS		CLAMP-SPLIT FLANGE (20)
57	5112 2466 39	4	LOCK WASHER	LÅSBRICKA		CAPSCREW - ADJUSTING NUT LOCK
60	5564 0889 00	2	JUNCTION BLOCK	KOPPLINGSBLOCK		
61	5530 6039 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 2 G5
62	5112 2465 26	4	LOCK WASHER	LÅSBRICKA		
63	5530 6000 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 1/2 NF X 1 G5
64	5530 6045 00	4	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 4-1/2
65	5565 4520 00	1	BLOCK	BLOCK		
66	5530 9880 00	4	CAPSCREW	HUVUDSKRUV		CPSCR-SKT 10-24 X 1 1/4 G
67	5559 9230 00	2	WASHER	PLÅTBRICKA		1/4 HT
68	5531 0854 00	2	CAPSCREW	HUVUDSKRUV		CPSCR-SKT 1/4 NC X 1-1/2
69	5531 0127 00	2	LOCK NUT	LÅSMUTTER		NUT-OVALOK 1/4 NC GR.C
70	5573 6694 00	1	MOUNTING PLATE	MONTERINGSPLÅT		
71	5530 5013 00	6	SCREW, HEX HEAD	SKRUV, SEXKANT		CPSCR-HEX 3/8 NC X 1 G5
72	5559 9232 00	18	WASHER	PLÅTBRICKA		3/8 HT
73	5559 9231 00	8	WASHER	PLÅTBRICKA		5/16 HT
74	5530 7116 00	10	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
76	5112 2467 47	4	SCREW	SKRUV		1C-624
77	5559 9234 00	4	WASHER	PLÅTBRICKA		1/2 HT

BRAKE SYSTEM / BROMSSYSTEM



5574 0342 00

(Sheet 3 of 3)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
78	5500 2131 00	1	COUPLE	KOPPEL		COUPLER-QD MALE, 1/4NPT,W/
79	5500 4988 00	1	TEE	T-RÖR		TEE-RUN (PIPE/PIPE/PIPE)
101	5507 4488 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
102	5507 1624 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
103	5507 3850 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
104	5507 3070 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
105	5500 9025 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
107	0574 2043 95	1	HOSE ASSEMBLY	SLANGLEDNING		HOSES ASSY
108	5507 7730 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
109	5507 4166 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
110	5506 3052 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
112	5504 8523 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
113	5507 1630 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
114	5507 1631 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
115	5507 2390 00	1	HOSE ASSEMBLY	SLANGLEDNING		1C01437GGG0540A
116	5506 9453 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
117	5507 3179 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
120	5506 6573 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
121	0574 7802 68	1	HOSE ASSEMBLY	SLANGLEDNING		10 4100 B1 34,5 UNF 11/16
122	5507 2724 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
123	5507 2725 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
124	0574 2043 97	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
125	0574 2043 98	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
126	0574 2043 99	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
127	0574 2043 68	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY.
128	0574 2043 68	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY.
129	5506 6888 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY



Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
3	5540 4190 00	1	SEAL	TÄTNING		
4	5537 5532 00	1	COVER	KÅPA		
6	—	4	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
7	5537 5534 00	2	CHANNEL	U-BALK		
8	5537 5535 00	2	CROSS	KORS		
9	5540 1164 00	1	GEAR	VÄXEL		
10	5540 6324 00	2	GASKET	PACKNING		
11	5537 5539 00	4	DOWEL PIN	DUBBPINNE		
12	5537 5538 00	1	HOUSING	HUS		
17	5537 5540 00	1	COVER	KÅPA		
18	5537 5541 00	4	SCREW	SKRUV		
19	5537 5542 00	4	WASHER	BRICKA		




VALVE / VENTIL

5537 7888 00

ACCUMULATOR CHARGE

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5540 6087 00	1	BODY	RAM		
2	5540 6088 00	1	VALVE	VENTIL		
3	5537 8122 00	1	SEAL KIT	TÄTNINGSSATS		
4	5540 9222 00	1	CONTROL	REGLAGE		
5	5537 8123 00	1	SEAL KIT	TÄTNINGSSATS		
6	5540 4823 00	1	RELIEF VALVE	AVLASTN.VENTIL		
7	5537 8124 00	1	SEAL KIT	TÄTNINGSSATS		
8	5537 5455 00	1	CARTRIDGE	PATRON		
9	5537 8125 00	1	SEAL KIT	TÄTNINGSSATS		
10	5501 1738 00	1	COUPLE	KOPPEL		
11	5540 6090 00	1	PLUG	PROPP		
12	5540 6091 00	1	O-RING	O-RING		
13	5540 6092 00	1	PLUG	PROPP		
14	5540 6093 00	1	O-RING	O-RING		




ACCUMULATOR / ACKUMULATOR

5540 4633 00



ACCUMULATOR-1 GAL

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5537 1931 00	1	SEAL KIT	TÄTNINGSSATS		
2	5540 4910 00	1	CAP	HUV		
3	5540 4911 00	1	CAP	HUV		
5	5540 4912 00	1	O-RING	O-RING		
6	5540 4914 00	2	RING	RING		
7	5540 4915 00	2	BODY	RAM		
8	3115 0262 00	1	VALVE	VENTIL		
9	5537 2622 00	1	PROTECTION	SKYDD		
5A	5540 4913 00	2	WASHER	BRICKA		
8A	5537 4323 00	1	O-RING	O-RING		
9A	5537 2623 00	2	PROTECT. SCREW	SKYDDSSKRUV		



FOOT BRAKE / FOTBROMS**5541 0093 00**

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
0	5537 2961 00	1	REPAIR KIT	RENOVERINGSSATS		
1	5540 9671 00	1	PEDAL	PEDAL		
2	5537 8835 00	1	VALVE	VENTIL		



HAND PUMP / HANDPUMP

5541 7067 00

(Sheet 1 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
2	5537 5023 00	1	PLUNGER	PLUNGE		
3	5537 5024 00	2	PACKING	TÄTNING		
4	5537 5025 00	2	CAP	HUV		
5	5535 5198 00	2	O-RING	O-RING		
6	5541 7078 00	1	LEVER	SPAK		
7	5537 5028 00	1	PACKING	TÄTNING		
8	5537 5029 00	1	PIN	TAPP		
9	5537 5170 00	2	BACK-UP RING	STÖDRING		
10	5537 5030 00	1	SEAL	TÄTNING		
11	5537 5031 00	1	RETAINER	FASTHÅLLARE		
12	5537 5032 00	2	SCREW	SKRUV		
13	5537 5033 00	2	SEAT	SÄTE		
14	5537 5034 00	1	PLUG	PROPP		
15	5537 5035 00	1	BALL	KULA		
16	5537 5036 00	1	VALVE	VENTIL		
17	5537 5037 00	1	O-RING	O-RING		
18	5537 5038 00	1	LEVER	SPAK		
19	5537 5039 00	1	SCREW	SKRUV		
20	5537 5040 00	2	O-RING	O-RING		
21	5537 5041 00	2	SEAT	SÄTE		
22	5537 4998 00	2	O-RING	O-RING		
23	5537 4999 00	2	BALL	KULA		
24	5537 5000 00	2	BALL	KULA		
25	5537 5001 00	2	SPRING	FJÄDER		
26	5537 5002 00	2	SPRING	FJÄDER		
27	5537 5003 00	2	SPRING	FJÄDER		
28	5537 5004 00	2	PLUG	PROPP		
29	5536 3766 00	3	PLUG	PROPP		
30	5537 5005 00	2	PLUG	PROPP		
31	—	1	NOT DEL. SEP.	LEV. EJ SEP.		SEE ITEM 52
32	—	1	NOT DEL. SEP.	LEV. EJ SEP.		SEE ITEM 52

(Sheet 2 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
33	5537 5171 00	1	PLUG	PLUGG		
34	—	1	NOT DEL. SEP.	LEV. EJ SEP.		SEE ITEM 52
46	5537 5015 00	1	CAP	HUV		
47	5537 5016 00	1	GASKET	PACKNING		
48	5537 5017 00	2	SPACER	DISTANS		
49	5537 4994 00	2	SPACER	DISTANS		
50	5537 4995 00	1	SPRING	FJÄDER		
51	5537 4996 00	1	POPPET VALVE	SÄTESVENTIL		
52	5537 4997 00	1	HANDLE	HANDTAG		NOT ILLUSTRATED, INCLUDES ITEMS 31, 32, 34

LUBRICATION SET / SMÖRJUTRUSTNING
LIST OF CONTENTS

Part no Detaljnr	Description	Benämning	See page Se sida	Remarks Anmärkning
–	LUBRICATION SET	SMÖRJUTRUSTNING	331	
5574 2867 00	– LUBR. SYSTEM	– SMÖRJSYSTEM	335	
5540 9376 00	– – GREASE PUMP	– – FETTPUMP	339	PUMP-GREASE,24VDC
5573 0712 00	– – BLOCK	– – BLOCK	343	
5573 0713 00	– – BLOCK	– – BLOCK	345	

LUBRICATION SET / SMÖRJUTRUSTNING

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5574 2867 00	1	LUBR. SYSTEM	SMÖRJSYSTEM	Page 335	

Fig. 1 of 3




Fig. 2 of 3







Fig. 3 of 3




5574 2876 00_3/3

(Sheet 1 of 2)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5540 9376 00	1	GREASE PUMP	FETTPUMP	Page 339	PUMP-GREASE,24VDC
2	5573 0712 00	1	BLOCK	BLOCK	Page 343	
3	5573 0713 00	1	BLOCK	BLOCK	Page 345	
5	5573 0697 00	2	MOUNT	FÄSTE		
6	5590 0026 38	1	COVER	KÅPA		
8	5530 7552 00	2	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 5/16NC N
9	0144 3251 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 5/16 X 38 - 8.8 FZB
10	0144 3211 03	8	HEXAGON SCREW	SEXXANTSSKRUV		UNC 1/4 - 38 12,8 19 4 11
11	5559 9230 00	8	WASHER	PLÅTBRICKA		1/4 HT
13	5530 7116 00	5	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 3/8 NC N
14	5590 0026 32	1	COVER	KÅPA		
16	0570 5090 01	1	NIPPLE	NIPPEL		UNF 7/16 - NPTF 1/4
17	0144 3290 03	5	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 38 - 8.8 FZB
18	5575 5802 00	1	CABLE COMPLETE	KABEL KOMPLETT		FUEL COOL / LINCOLN LUBE
20	3177 3063 00	1	NIPPLE	NIPPEL		UNF 7/16 - NPTF 1/4
21	3176 7058 00	16	NIPPLE	NIPPEL		UNF 7/16 - NPTF 1/8
22	5500 4628 00	4	NIPPLE	NIPPEL		ELBOW-45 (PIPE/JIC)
23	0570 5090 21	8	NIPPLE	NIPPEL		UNF 7/16 - NPTF 1/8
24	0570 5090 28	3	NIPPLE	NIPPEL		UNF 7/16 - NPTF 1/8
25	5112 2467 48	3	PLUG	PROPP		CLARK 40K-02
26	0570 5090 34	3	NIPPLE	NIPPEL		UNF 7/16 - NPTF 1/8
28	0144 3367 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 1/2 X 51 - 8.8 FZB
29	0300 0274 93	10	PLAIN WASHER	RUNDBRICKA		10 10,5 28 A
30	5559 9234 00	4	WASHER	PLÅTBRICKA		1/2 HT
32	5530 7551 00	2	LOCK NUT	LÅSMUTTER		NUT-POLY INSERT 1/2 NC N
33	5559 9231 00	2	WASHER	PLÅTBRICKA		5/16 HT
39	5530 8985 00	16	WELDING BOLT	SVETSBULT		WELD STUD-5/16NC X 1 & FE
38	5590 0023 78	1	CABLE COMPLETE	KABEL KOMPLETT		HARNESS - LINCOLN LUBE
40	5580 0010 04	0.16M	CHAIN	KEDJA		
41	5537 1189 00	1	PIN	PINNE		PIN-Q/R 1/2 DIA X 1 5/8 L
50	5573 2275 00	1	LABEL	DEKAL		LABEL-LUBE FILL
51	0300 8019 00	2	PLAIN WASHER	RUNDBRICKA		8,4 / 25 X 2 -11 1312 FZB

(Sheet 2 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
52	0144 3291 03	2	SCREW, HEX HEAD	SKRUV, SEXKANT		UNC 3/8 X 45 - 8.8 FZB
53	5559 9232 00	1	WASHER	PLÅTBRICKA		3/8 HT
101	5500 7940 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
102	5501 3757 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
103	5501 3777 00	1	HOSE ASSEMBLY	SLANGLEDNING		1C00010EEE1390A
104	5505 5507 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
105	5500 7948 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
106	5500 7915 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
107	5501 3727 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
108	5507 2264 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
109	5501 3788 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
110	5508 1802 00	1	HOSE ASSEMBLY	SLANGLEDNING		1C00013EEE2040A
111	5507 7265 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
112	0574 1254 07	1	HOSE ASSEMBLY	SLANGLEDNING		6,3 3810 I90-E 190 UNF 7/
114	5501 3756 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
115	0574 1254 08	1	HOSE ASSEMBLY	SLANGLEDNING		6,3 4521 I90-E 190 UNF 7/
117	5505 1431 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
118	5501 3738 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
119	5501 3769 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
121	5500 8636 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
122	5501 3112 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY
123	5501 3112 00	1	HOSE ASSEMBLY	SLANGLEDNING		HOSE ASSY



(Sheet 1 of 2)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5541 2461 00	1	MOTOR SET	MOTORSATS		MOTOR KIT
	5541 2462 00	1	SEAL KIT	TÄTNINGSSATS		SEAL KIT-HOUSING
1	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
2	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
3	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
4	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
5	—	2	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
6	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
7	—	2	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
8	5541 2453 00	1	PLATE	PLATTA		LINCOLN GREASE PUMP
9	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
10	—	2	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
11	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
12	5541 2455 00	1	CAM	KAM		LINCOLN GREASE PUMP
13	—	3	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
14	—	3	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
15	—	3	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
16	5541 2454 00	1	PUMP HOUSING	PUMPHUS		
17	5541 2450 00	2	PLUG	PROPP		LINCOLN GREASE PUMP
18	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
19	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
20	—	4	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
21	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
22	5541 2451 00	1	PLUG	PROPP		
25	5540 6277 00	1	FITTING	FÖRSKRUVNING		FITTING-LUBE FILL
26	5541 2465 00	1	CIRCUIT BOARD	KRETSKORT		CIRCUIT BOARD-PRINTED
27	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
28	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
29	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
30	5541 2499 00	1	COVER	KÅPA		ELEMENT
31	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
34	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.

GREASE PUMP / FETTPUMP**5540 9376 00**


(Sheet 2 of 2)

Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
35	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
36	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
37	5541 2448 00	1	VALVE	VENTIL		VALVE-PRESSURE RELIEF
38	—	1	NOT DEL. SEP.	LEV. EJ SEP.		NOT DEL. SEP.
39	5541 2447 00	1	CAP	HUV		CAP-GREASE
40	5541 2446 00	1	FITTING	FÖRSKRUVNING		FITTING
41	5541 2456 00	1	ADAPTER	ADAPTER		ADAPTER FOR RELIEF ASSY
42	5541 2457 00	1	KIT	SATS		
43	5541 2458 00	1	RESERVOIR	BEHÅLLARE		
44	5541 2459 00	1	KIT	SATS		KIT-PADDLE
45	5541 2460 00	1	BEARING	LAGER		KIT-BEARING & SEAL
47	5541 2464 00	1	KIT	SATS		KIT-POWER PLUG
48	3128 2538 01	1	PUMP ELEMENT	PUMPELEMENT		


GREASE PUMP / FETTPUMP

5540 9376 00

5540 9376 00 006K



Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5541 2329 00	1	PLATE	PLATTA		
2	5541 2332 00	3	PLATE	PLATTA		
3	5541 2334 00	1	PLATE	PLATTA		
5	5541 2986 00	1	RING	RING		
6	5541 2330 00	1	VALVE	VENTIL		
7	5541 2415 00	1	TIE ROD	STYRSTAG		
8	5541 2336 00	5	INDICATOR	INDIKATOR		



Ref no	Part no Detaljnr	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5541 2329 00	1	PLATE	PLATTA		
2	5541 2332 00	7	PLATE	PLATTA		
3	5541 2334 00	1	PLATE	PLATTA		
4	5541 2981 00	1	VALVE	VENTIL		
5	5541 2982 00	1	VALVE	VENTIL		
7	5541 2983 00	3	RING	RING		
8	5541 2333 00	1	VALVE	VENTIL		
10	5541 2336 00	11	INDICATOR	INDIKATOR		


SIGN SET / SKYLTSATS
LIST OF CONTENTS

Part no Detaljnr	Description	Benämning	See page Se sida	Remarks Anmärkning
–	SIGN SET	SKYLTSATS	349	
5574 8836 00	– SIGN SET	– SKYLTSATS	353	LABEL INST-MT2000

SIGN SET / SKYLTSATS

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
	5574 8836 00	1	SIGN SET	SKYLTSATS	Page 353	LABEL INST-MT2000

Fig. 1 of 3



NOTE 1: ITM. XX (CE LABEL) SEE VEHICLE STRUCTURE 8997 XXXX XX
SIGNS TO BE PLACED ON FUEL AND HYDRAULIC TANK
CAN NOT BE USED WITH SCREWS OR RIVETS, ONLY AHDESIVE

Fig. 2 of 3





Fig. 3 of 3



SIGN SET / SKYLTSATS

5574 8836 00

(Sheet 1 of 2)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
1	5562 0309 00	1	LABEL	DEKAL		LABEL-PATENTS PENDING
2	9106 1071 12	1	BATTERY SWITCH	BATTERIFR.SKILJ		
3	5572 2795 00	1	LABEL	DEKAL		ISO-LUBE INSTRUCTIONS
4	9106 1071 15	1	FUEL	BRÄNSLE		
5	5572 3041 00	1	LABEL	DEKAL		LABEL ISO-BRAKE RELEASE HAZARD
6	5572 2789 00	1	LABEL	DEKAL		LABEL ISO-DIESEL FUEL
7	5573 2275 00	2	LABEL	DEKAL		LABEL-LUBE FILL
8	9106 1073 13	4	FALLING BOOM	FALLANDE BOM		
9	5572 8766 00	2	LABEL	DEKAL		
10	5572 3167 00	1	LABEL	DEKAL		LABEL ISO-NO SMOKING
11	5572 3036 00	1	LABEL	DEKAL		LABEL ISO-FIRE HAZARD
12	5572 3329 00	4	LABEL	DEKAL		LABEL ISO-TOWING POINT
13	5572 2784 00	1	LABEL	DEKAL		LABEL ISO-ENG OIL FILTER
14	5572 5703 00	2	LABEL	DEKAL		LABEL ISO-NO STEP
15	9106 1073 16	4	RISK OF CRUSH.	KLÄMRISK		
16	5572 3035 00	3	LABEL	DEKAL		LABEL ISO-EXTREME TEMP HAZARD
17	9106 1073 32	3	HAZARDOUS PRES.	RISKABELT TRYCK		
18	5572 2786 00	1	LABEL	DEKAL		LABEL ISO-TRANS OIL FILTER
19	5572 2788 00	1	LABEL	DEKAL		LABEL ISO-TRANS OIL
20	5572 2787 00	1	LABEL	DEKAL		LABEL ISO-TRANS LEVEL
21	5572 2792 00	1	LABEL	DEKAL		LABEL ISO-HYD OIL FILTER
22	5572 2791 00	1	LABEL	DEKAL		LABEL ISO-HYD OIL
23	5575 0776 00	1	LABEL	DEKAL		LABEL-ROLLOVER, SMALL
24	5575 0777 00	2	LABEL	DEKAL		LABEL-ROLLOVER, LARGE
25	9106 1071 00	1	READ INSTR.BOOK	LÄS INSTR.BOK		
26	9106 1071 07	1	WATER INLET	VATTENINTAG		
27	5572 2783 00	1	LABEL	DEKAL		LABEL ISO-ENG OIL
28	9106 1073 16	1	RISK OF CRUSH.	KLÄMRISK		
29	5575 7009 93	2	INSTRUCTIONSIGN	INSTRUKT.SKYL		
30	5575 7009 94	2	INSTRUCTIONSIGN	INSTRUKT.SKYL		
31	0244 4166 00	110	SCREW, DRIVE	SKRUV, DRIV		KDS 2,9 X 10 SMS1549 FZB
32	9106 1073 06	1	HIGH SOUND LEV.	HÖG LJUDNIVÅ		

(Sheet 2 of 2)

Ref no	Part no Detaljn	Qty Antal	Description	Benämning	See page Se sida	Remarks Anmärkning
33	9106 1071 01	1	READ INSTR.BOOK	LÄS INSTR.BOK		
34	9106 1073 31	1	HAZARDOUS PRES.	RISKABELT TRYCK		
35	9106 1071 03	1	NO ADMITTANCE	TILLTRÄDE FÖRB.		

CROSS REFERENCE LIST

Part no Detaljnr	Description	Ref no	See page Se sida
0144 3203 03	SCREW, HEX HEAD	29	32
0144 3203 03	SCREW, HEX HEAD	28	21
0144 3206 03	HEXAGON SCREW	7	110
0144 3206 03	HEXAGON SCREW	45	22
0144 3207 03	SCREW, HEX HEAD	2	263
0144 3207 03	SCREW, HEX HEAD	30	105
0144 3209 03	SCREW, HEX HEAD	6	263
0144 3211 03	HEXAGON SCREW	47	22
0144 3211 03	HEXAGON SCREW	10	335
0144 3245 03	SCREW, HEX HEAD	34	21
0144 3246 03	SCREW, HEX HEAD	10	241
0144 3248 03	SCREW, HEX HEAD	2	237
0144 3248 03	SCREW, HEX HEAD	4	237
0144 3248 03	SCREW, HEX HEAD	3	261
0144 3248 03	SCREW, HEX HEAD	9	161
0144 3248 03	SCREW, HEX HEAD	34	117
0144 3248 03	SCREW, HEX HEAD	3	125
0144 3249 03	SCREW, HEX HEAD	34	172
0144 3249 03	SCREW, HEX HEAD	6	241
0144 3251 03	SCREW, HEX HEAD	9	335
0144 3284 03	SCREW, HEX HEAD	23	21
0144 3284 03	SCREW, HEX HEAD	63	218
0144 3284 03	SCREW, HEX HEAD	27	117
0144 3284 03	SCREW, HEX HEAD	2	243
0144 3284 03	SCREW, HEX HEAD	59	218
0144 3285 03	SCREW, HEX HEAD	24	172
0144 3285 03	SCREW, HEX HEAD	12	161
0144 3286 03	SCREW, HEX HEAD	8	237
0144 3286 03	SCREW, HEX HEAD	36	22

Part no Detaljnr	Description	Ref no	See page Se sida
0144 3287 03	SCREW, HEX HEAD	14	191
0144 3287 03	SCREW, HEX HEAD	19	165
0144 3287 03	SCREW, HEX HEAD	7	71
0144 3287 03	SCREW, HEX HEAD	43	86
0144 3287 03	SCREW, HEX HEAD	30	117
0144 3287 03	SCREW, HEX HEAD	32	218
0144 3288 03	SCREW, HEX HEAD	60	274
0144 3288 03	SCREW, HEX HEAD	14	78
0144 3288 03	SCREW, HEX HEAD	93	11
0144 3288 03	SCREW, HEX HEAD	12	293
0144 3288 03	SCREW, HEX HEAD	4	71
0144 3288 03	SCREW, HEX HEAD	21	165
0144 3288 03	SCREW, HEX HEAD	38	22
0144 3288 03	SCREW, HEX HEAD	24	298
0144 3288 03	SCREW, HEX HEAD	33	97
0144 3290 03	SCREW, HEX HEAD	20	71
0144 3290 03	SCREW, HEX HEAD	46	86
0144 3290 03	SCREW, HEX HEAD	38	148
0144 3290 03	SCREW, HEX HEAD	17	335
0144 3291 03	SCREW, HEX HEAD	53	87
0144 3291 03	SCREW, HEX HEAD	21	71
0144 3291 03	SCREW, HEX HEAD	52	336
0144 3292 03	HEXAGON SCREW	20	165
0144 3292 03	HEXAGON SCREW	30	273
0144 3297 03	SCREW, HEX HEAD	18	165
0144 3297 03	SCREW, HEX HEAD	36	310
0144 3345 03	SCREW, HEX HEAD	5	293
0144 3362 03	SCREW, HEX HEAD	98	11
0144 3362 03	SCREW, HEX HEAD	7	261

Part no Detaljnr	Description	Ref no	See page Se sida
0144 3362 03	SCREW, HEX HEAD	94	11
0144 3362 03	SCREW, HEX HEAD	11	105
0144 3363 03	SCREW, HEX HEAD	141	194
0144 3363 03	SCREW, HEX HEAD	38	166
0144 3363 03	SCREW, HEX HEAD	169	195
0144 3363 03	SCREW, HEX HEAD	103	193
0144 3363 03	SCREW, HEX HEAD	38	192
0144 3363 03	SCREW, HEX HEAD	106	220
0144 3363 03	SCREW, HEX HEAD	32	192
0144 3363 03	SCREW, HEX HEAD	4	293
0144 3363 03	SCREW, HEX HEAD	19	273
0144 3365 03	SCREW, HEX HEAD	23	165
0144 3365 03	SCREW, HEX HEAD	14	273
0144 3366 03	SCREW, HEX HEAD	86	11
0144 3366 03	SCREW, HEX HEAD	22	21
0144 3367 03	SCREW, HEX HEAD	15	148
0144 3367 03	SCREW, HEX HEAD	28	335
0144 3368 03	SCREW, HEX HEAD	19	21
0144 3370 03	SCREW, HEX HEAD	40	148
0144 3379 03	HEX. HEAD SCREW	6	269
0144 4000 95	HEXAGON SCREW	80	11
0144 4001 95	HEXAGON SCREW	18	172
0147 1245 03	SCREW, HEX HEAD	6	257
0147 1253 03	SCREW, HEX HEAD	4	25
0147 1326 03	SCREW, HEX HEAD	15	66
0147 1358 03	SCREW, HEX HEAD	46	98
0147 1362 03	SCREW, HEX HEAD	60	87
0147 1362 03	SCREW, HEX HEAD	2080	141
0147 1363 03	SCREW, HEX HEAD	36	78
0147 1364 03	SCREW, HEX HEAD	39	79

Part no Detaljnr	Description	Ref no	See page Se sida
0147 1364 03	SCREW, HEX HEAD	60	22
0147 1364 03	SCREW, HEX HEAD	9	110
0147 1365 03	SCREW, HEX HEAD	4	110
0147 1367 03	SCREW, HEX HEAD	59	87
0147 1369 03	SCREW, HEX HEAD	58	87
0244 4166 00	SCREW, DRIVE	31	353
0261 1090 11	NUT	35	251
0268 4138 20	HEXAGON NUT	20	66
0291 1128 03	LOCK NUT	65	251
0291 1128 15	LOCK NUT	5	25
0291 1128 18	LOCK NUT	17	66
0291 1128 18	LOCK NUT	69	252
0291 1128 20	LOCK NUT	61	22
0291 1128 20	LOCK NUT	5	110
0291 1128 20	LOCK NUT	38	79
0291 1128 22	LOCK NUT	38	173
0291 1128 43	LOCK NUT	11	15
0300 0274 93	PLAIN WASHER	29	335
0300 0275 02	PLAIN WASHER	36	251
0300 8019 00	PLAIN WASHER	51	335
0301 2118 01	PLAIN WASHER	66	251
0301 2121 01	PLAIN WASHER	31	250
0301 2321 00	PLAIN WASHER	5	257
0301 2335 00	PLAIN WASHER	16	66
0301 2335 00	PLAIN WASHER	68	251
0301 2343 00	PLAIN WASHER	31	310
0301 2344 00	PLAIN WASHER	61	87
0301 2344 00	PLAIN WASHER	62	22
0301 2344 00	PLAIN WASHER	6	110
0301 2344 00	PLAIN WASHER	37	79

Part no Detaljn	Description	Ref no	See page Se sida
0301 2344 00	PLAIN WASHER	13	161
0301 2344 00	PLAIN WASHER	47	98
0333 2174 22	SPRING WASHER	11	69
0333 2174 34	SPRING WASHER	3630	138
0333 2174 34	SPRING WASHER	2480	141
0346 1002 05	PIPE CLAMP	4	257
0347 6100 21	HOSE CLIP	45	98
0570 5090 01	NIPPLE	1	117
0570 5090 01	NIPPLE	16	335
0570 5090 21	NIPPLE	23	335
0570 5090 28	NIPPLE	24	335
0570 5090 34	NIPPLE	26	335
0570 7000 06	STRAIGHT NIPPLE	31	273
0570 7000 07	NIPPLE	4	165
0570 7000 09	CAP	42	98
0570 7000 10	CAP	23	69
0570 7000 16	PLUG	23	110
0570 7009 02	NIPPLE	17	110
0570 7009 04	NIPPLE	22	69
0570 7009 18	NIPPLE	35	172
0570 7017 01	NIPPLE	36	314
0570 7017 03	NIPPLE	17	298
0570 7017 04	NIPPLE	12	298
0570 7017 04	NIPPLE	7	298
0570 7017 08	NIPPLE	21	66
0570 7017 09	NIPPLE	8	298
0570 7017 11	BULKHEAD CONN.	10	298
0570 7017 12	BULKHEAD CONN.	9	298
0570 7025 08	NIPPLE	32	273
0570 7025 08	NIPPLE	7	172

Part no Detaljn	Description	Ref no	See page Se sida
0570 7025 10	NIPPLE	17	310
0570 7025 11	NIPPLE	11	86
0570 7025 20	NIPPLE	43	274
0570 7025 20	NIPPLE	8	310
0570 7025 21	NIPPLE	43	98
0570 7025 21	NIPPLE	2	172
0570 7025 22	NIPPLE	3	86
0570 7025 24	NIPPLE	5	310
0570 7025 27	NIPPLE	21	69
0570 7025 51	STRAIGHT NIPPLE	25	110
0570 7041 13	ELBOW NIPPLE	13	269
0570 7041 14	ELBOW NIPPLE	6	298
0570 7041 15	ELBOW NIPPLE	40	273
0570 7041 16	ELBOW NIPPLE	68	274
0570 7041 16	ELBOW NIPPLE	4	172
0570 7041 17	ELBOW NIPPLE	24	310
0570 7041 18	ELBOW NIPPLE	36	273
0570 7041 18	ELBOW NIPPLE	19	310
0570 7041 18	ELBOW NIPPLE	5	314
0570 7041 19	ELBOW NIPPLE	6	310
0570 7041 24	ELBOW NIPPLE	37	314
0570 7041 24	ELBOW NIPPLE	47	166
0570 7041 24	ELBOW NIPPLE	5	172
0570 7041 25	NIPPLE	12	86
0570 7041 25	NIPPLE	2	165
0570 7041 26	ELBOW NIPPLE	33	172
0570 7041 27	ELBOW NIPPLE	9	86
0570 7049 03	T-NIPPLE	39	273
0570 7049 08	T-NIPPLE	35	273
0570 7057 07	REDUCING BUSHIN	11	298

Part no Detaljnr	Description	Ref no	See page Se sida
0574 1254 07	HOSE ASSEMBLY	112	336
0574 1254 08	HOSE ASSEMBLY	115	336
0574 2043 68	HOSE ASSEMBLY	128	316
0574 2043 68	HOSE ASSEMBLY	127	316
0574 2043 95	HOSE ASSEMBLY	107	316
0574 2043 97	HOSE ASSEMBLY	124	316
0574 2043 98	HOSE ASSEMBLY	125	316
0574 2043 99	HOSE ASSEMBLY	126	316
0574 2253 16	HOSE ASSEMBLY	101	89
0574 7802 68	HOSE ASSEMBLY	121	316
0574 7802 69	HOSE ASSEMBLY	106	311
0574 7802 70	HOSE ASSEMBLY	113	301
0574 7802 70	HOSE ASSEMBLY	112	301
0574 7802 71	HOSE ASSEMBLY	108	301
0574 7802 71	HOSE ASSEMBLY	109	301
0574 7802 94	HOSE ASSEMBLY	111	311
0607 1100 22	SOCKET	7	35
0638 0521 00	FLANGE HALF	31	166
0638 0521 00	FLANGE HALF	58	274
0638 0521 00	FLANGE HALF	34	298
0638 0527 00	FLANGE HALF	32	166
0638 0527 00	FLANGE HALF	35	298
0638 0545 00	FLANGE HALF	34	166
0663 9050 01	O-RING	3	41
0663 9055 01	O-RING	15	269
3115 0262 00	VALVE	8	323
3128 2538 01	PUMP ELEMENT	48	340
3176 0005 47	LIGHT EMIT. DIO	41	251
3176 0577 00	PLUG	62	87
3176 0577 00	PLUG	25	97

Part no Detaljnr	Description	Ref no	See page Se sida
3176 0577 00	PLUG	36	32
3176 1672 00	NIPPLE	22	97
3176 1949 00	NIPPLE	6	117
3176 2786 00	NIPPLE	7	117
3176 3681 00	STRAP	24	110
3176 6540 00	NIPPLE	21	97
3176 6570 00	NIPPLE	31	172
3176 6573 00	NIPPLE	5	117
3176 6573 00	NIPPLE	18	117
3176 7058 00	NIPPLE	21	335
3176 7467 01	PUMP	1	110
3176 7868 03	PLUG	26	172
3176 7868 06	PLUG	3	165
3176 7868 06	PLUG	33	86
3176 7868 06	PLUG	66	274
3176 7868 07	PLUG	13	86
3176 7922 00	FLANGE HALF	33	166
3176 7922 00	FLANGE HALF	62	274
3177 3063 00	NIPPLE	4	117
3177 3063 00	NIPPLE	20	335
3217 0004 44	TRIGGER	50	251
3217 0004 47	TRIGGER	48	251
3217 0004 93	LAMP INSERT	46	251
3217 0004 94	PALM GRIP	45	251
3217 0004 96	CONTACT BLOCK	49	251
3217 0005 02	CONTACT BLOCK	43	251
3217 0010 11	SWITCH	62	251
3217 0010 13	PALM GRIP	44	251
3217 0010 25	PALM GRIP	42	251
3217 9316 25	SEAL	43	118

Part no Detaljn	Description	Ref no	See page Se sida
3217 9316 42	ATTACHMENT	2	121
3222 3060 87	GROUND BRAID	70	252
3455 0400 02	PLUG	5	86
3455 0400 04	PLUG	38	86
4090 0313 00	O-RING	27	211
4090 0313 00	O-RING	38	212
5112 2392 09	AIR FILTER	119	194
5112 2392 09	AIR FILTER	29	217
5112 2392 15	SCREW	118	220
5112 2392 15	SCREW	5	223
5112 2392 19	O-RING	18	191
5112 2392 20	SLEEVE	6	203
5112 2392 20	SLEEVE	5	203
5112 2392 22	O-RING	49	212
5112 2392 29	PIN	78	219
5112 2392 40	LOCK WASHER	23	298
5112 2392 40	LOCK WASHER	87	219
5112 2392 40	LOCK WASHER	53	315
5112 2392 40	LOCK WASHER	20	199
5112 2392 40	LOCK WASHER	59	218
5112 2392 40	LOCK WASHER	41	47
5112 2392 40	LOCK WASHER	33	218
5112 2392 40	LOCK WASHER	29	117
5112 2392 40	LOCK WASHER	24	165
5112 2392 40	LOCK WASHER	16	235
5112 2392 40	LOCK WASHER	17	191
5112 2392 40	LOCK WASHER	13	191
5112 2392 40	LOCK WASHER	4	243
5112 2392 40	LOCK WASHER	13	175
5112 2392 40	LOCK WASHER	22	273

Part no Detaljn	Description	Ref no	See page Se sida
5112 2392 40	LOCK WASHER	63	218
5112 2392 40	LOCK WASHER	157	195
5112 2392 40	LOCK WASHER	12	133
5112 2392 41	SCREW	37	299
5112 2392 41	SCREW	54	212
5112 2392 41	SCREW	134	221
5112 2392 41	SCREW	14	117
5112 2392 46	SLEEVE	26	203
5112 2392 46	SLEEVE	27	203
5112 2392 63	SEAL	92	219
5112 2465 26	LOCK WASHER	102	220
5112 2465 26	LOCK WASHER	6	223
5112 2465 26	LOCK WASHER	73	219
5112 2465 26	LOCK WASHER	26	165
5112 2465 26	LOCK WASHER	15	273
5112 2465 26	LOCK WASHER	62	315
5112 2465 26	LOCK WASHER	5	53
5112 2465 26	LOCK WASHER	168	195
5112 2465 26	LOCK WASHER	142	195
5112 2465 26	LOCK WASHER	102	193
5112 2465 26	LOCK WASHER	22	298
5112 2465 26	LOCK WASHER	20	273
5112 2465 26	LOCK WASHER	31	192
5112 2465 26	LOCK WASHER	39	192
5112 2465 26	LOCK WASHER	8	217
5112 2466 39	LOCK WASHER	21	298
5112 2466 39	LOCK WASHER	25	165
5112 2466 39	LOCK WASHER	77	219
5112 2466 39	LOCK WASHER	57	315
5112 2466 39	LOCK WASHER	70	219

Part no Detaljn	Description	Ref no	See page Se sida
5112 2466 39	LOCK WASHER	119	220
5112 2466 41	O-RING	38	218
5112 2466 41	O-RING	36	218
5112 2466 71	WASHER	36	192
5112 2466 72	NUT	37	192
5112 2466 72	NUT	43	192
5112 2467 01	O-RING	21	211
5112 2467 01	O-RING	9	211
5112 2467 42	O-RING	17	177
5112 2467 43	O-RING	18	177
5112 2467 44	O-RING	19	177
5112 2467 45	SOLENOID VALVE	15	175
5112 2467 47	SCREW	14	191
5112 2467 47	SCREW	76	315
5112 2467 47	SCREW	2	41
5112 2467 47	SCREW	31	21
5112 2467 47	SCREW	13	78
5112 2467 47	SCREW	89	11
5112 2467 47	SCREW	88	219
5112 2467 47	SCREW	55	166
5112 2467 48	PLUG	44	98
5112 2467 48	PLUG	23	217
5112 2467 48	PLUG	15	211
5112 2467 48	PLUG	7	223
5112 2467 48	PLUG	23	71
5112 2467 48	PLUG	25	335
5112 2467 48	PLUG	23	303
5112 2467 48	PLUG	26	217
5112 2467 59	PLUG	42	212
5112 2467 59	PLUG	11	199

Part no Detaljn	Description	Ref no	See page Se sida
5112 2467 59	PLUG	30	199
5112 2467 60	O-RING	12	199
5112 2467 60	O-RING	6	175
5112 2467 60	O-RING	19	175
5112 2467 60	O-RING	2	211
5112 2467 60	O-RING	29	199
5112 2467 60	O-RING	43	212
5112 2467 60	O-RING	19	179
5112 2467 60	O-RING	6	179
5112 2467 60	O-RING	2	175
5112 2467 60	O-RING	2	179
5112 2803 05	PLUG	12	179
5112 2803 05	PLUG	21	179
5112 2803 05	PLUG	21	199
5112 2803 05	PLUG	23	175
5112 2803 05	PLUG	23	179
5112 2803 05	PLUG	21	175
5112 2803 05	PLUG	12	175
5112 2803 18	SCREW	9	47
5112 2803 18	SCREW	4	235
5112 2803 18	SCREW	111	220
5112 2803 18	SCREW	21	29
5112 2803 18	SCREW	44	299
5112 2803 18	SCREW	41	218
5112 2803 18	SCREW	18	35
5112 2805 15	NUT	137	194
5112 2805 15	NUT	173	196
5112 2805 15	NUT	13	217
5112 2805 57	BALL	19	205
5112 2805 57	BALL	19	209

Part no Detaljnr	Description	Ref no	See page Se sida
5112 2805 57	BALL	17	207
5112 3116 49	SCREW	31	32
5112 3190 27	COIL	21	177
5500 2131 00	COUPLE	78	316
5500 2139 00	CONNECTOR	28	314
5500 2140 00	CONNECTOR	25	314
5500 2142 00	CONNECTOR	8	314
5500 2148 00	TEE	40	166
5500 2149 00	TEE	49	315
5500 2153 00	NIPPLE	20	314
5500 2155 00	NIPPLE	6	314
5500 2155 00	NIPPLE	16	110
5500 2158 00	NIPPLE	6	165
5500 2161 00	TEE	10	172
5500 2164 00	PIPE CONNECTION	38	315
5500 2165 00	PIPE CONNECTION	12	110
5500 2167 00	NIPPLE	20	97
5500 2176 00	NIPPLE	7	310
5500 2176 00	NIPPLE	14	110
5500 2176 00	NIPPLE	37	273
5500 2176 00	NIPPLE	9	314
5500 2180 00	TEE	24	314
5500 4094 00	PLUG	10	310
5500 4628 00	NIPPLE	22	335
5500 4638 00	NIPPLE	19	117
5500 4867 00	NIPPLE	29	172
5500 4911 00	BUSHING	19	110
5500 4940 00	PIPE CONNECTION	24	71
5500 4958 00	NIPPLE	34	314
5500 4966 00	NIPPLE	48	315

Part no Detaljnr	Description	Ref no	See page Se sida
5500 4968 00	NIPPLE	2	117
5500 4972 00	NIPPLE	8	117
5500 4988 00	TEE	79	316
5500 4988 00	TEE	41	315
5500 4988 00	TEE	42	118
5500 5088 00	BUSHING	11	314
5500 5088 00	BUSHING	40	315
5500 5092 00	BUSHING	32	86
5500 5125 00	TEE	3	117
5500 6139 00	WASHER	41	22
5500 6139 00	WASHER	10	293
5500 6816 00	SPACER TUBE	8	293
5500 6845 00	CYLINDER ASSY	1	293
5500 7285 00	NIPPLE	31	86
5500 7556 00	COUPLE	9	310
5500 7556 00	COUPLE	34	273
5500 7556 00	COUPLE	19	314
5500 7556 00	COUPLE	50	299
5500 7564 00	CONNECTOR	12	314
5500 7567 00	NIPPLE	15	314
5500 7569 00	CONNECTOR	22	310
5500 7577 00	NIPPLE	9	172
5500 7577 00	NIPPLE	20	86
5500 7577 00	NIPPLE	6	86
5500 7577 00	NIPPLE	35	86
5500 7577 00	NIPPLE	14	86
5500 7580 00	NIPPLE	24	97
5500 7585 00	TEE	15	310
5500 7586 00	TEE	20	310
5500 7883 00	PLUG	19	298

Part no Detaljnr	Description	Ref no	See page Se sida
5500 7883 00	PLUG	37	86
5500 7884 00	PLUG	7	86
5500 7884 00	PLUG	16	314
5500 7884 00	PLUG	28	172
5500 7884 00	PLUG	1	165
5500 7884 00	PLUG	48	274
5500 7904 00	HOSE ASSEMBLY	51	118
5500 7915 00	HOSE ASSEMBLY	106	336
5500 7940 00	HOSE ASSEMBLY	101	336
5500 7948 00	HOSE ASSEMBLY	105	336
5500 8186 00	HOSE ASSEMBLY	58	118
5500 8186 00	HOSE ASSEMBLY	55	118
5500 8625 00	HOSE ASSEMBLY	53	118
5500 8636 00	HOSE ASSEMBLY	121	336
5500 8999 00	HOSE ASSEMBLY	108	173
5500 9025 00	HOSE ASSEMBLY	105	316
5500 9037 00	HOSE ASSEMBLY	111	173
5500 9041 00	HOSE ASSEMBLY	105	274
5500 9065 00	HOSE ASSEMBLY	109	173
5500 9305 00	CONNECTOR	12	172
5500 9416 00	NIPPLE	21	314
5500 9416 00	NIPPLE	4	298
5500 9561 00	ADAPTER FLANGE	27	314
5500 9687 00	PLUG	42	273
5500 9687 00	PLUG	35	32
5501 1722 00	QUICK COUPLING	11	110
5501 1725 00	QUICK COUPLING	26	110
5501 1727 00	CAP	10	110
5501 1731 00	COUPLE	27	110
5501 1738 00	COUPLE	10	321

Part no Detaljnr	Description	Ref no	See page Se sida
5501 1742 00	BUSHING	41	273
5501 1746 00	BUSHING	33	273
5501 1751 00	NIPPLE	16	310
5501 1759 00	CONNECTOR	7	165
5501 1779 00	NIPPLE	32	172
5501 1779 00	NIPPLE	10	314
5501 1780 00	NIPPLE	27	172
5501 1781 00	NIPPLE	7	314
5501 1783 00	NIPPLE	23	310
5501 1786 00	NIPPLE	38	273
5501 1797 00	CONNECTOR	21	310
5501 1810 00	NIPPLE	41	98
5501 1810 00	NIPPLE	23	314
5501 1813 00	PIPE CONNECTION	48	166
5501 1816 00	PIPE CONNECTION	18	110
5501 1825 00	NIPPLE	51	299
5501 1827 00	NIPPLE	8	165
5501 1833 00	NIPPLE	22	314
5501 1837 00	NIPPLE	36	86
5501 1839 00	NIPPLE	44	274
5501 1842 00	NIPPLE	10	165
5501 1843 00	NIPPLE	17	314
5501 1848 00	NIPPLE	22	66
5501 1858 00	NIPPLE	39	315
5501 1859 00	NIPPLE	25	310
5501 1859 00	NIPPLE	11	310
5501 1859 00	NIPPLE	64	274
5501 2424 00	KIT	106	194
5501 2424 00	KIT	2	191
5501 2424 00	KIT	101	193

Part no Detaljnr	Description	Ref no	See page Se sida
5501 2424 00	KIT	82	193
5501 2424 00	KIT	122	220
5501 2424 00	KIT	56	192
5501 2424 00	KIT	128	194
5501 3112 00	HOSE ASSEMBLY	122	336
5501 3112 00	HOSE ASSEMBLY	123	336
5501 3136 00	HOSE ASSEMBLY	52	118
5501 3260 00	HOSE ASSEMBLY	57	118
5501 3727 00	HOSE ASSEMBLY	107	336
5501 3738 00	HOSE ASSEMBLY	118	336
5501 3756 00	HOSE ASSEMBLY	114	336
5501 3757 00	HOSE ASSEMBLY	102	336
5501 3769 00	HOSE ASSEMBLY	119	336
5501 3777 00	HOSE ASSEMBLY	103	336
5501 3788 00	HOSE ASSEMBLY	109	336
5501 4234 00	HOSE ASSEMBLY	112	173
5501 4241 00	HOSE ASSEMBLY	102	173
5501 4245 00	HOSE ASSEMBLY	105	173
5501 4248 00	HOSE ASSEMBLY	101	101
5501 4259 00	HOSE ASSEMBLY	107	173
5501 4370 00	HOSE ASSEMBLY	101	110
5501 4411 00	HOSE ASSEMBLY	110	173
5501 4417 00	HOSE ASSEMBLY	105	101
5501 4447 00	HOSE ASSEMBLY	103	110
5501 5349 00	NIPPLE	17	117
5501 6032 00	PIPE CONNECTION	36	173
5501 7094 00	NIPPLE	5	298
5501 7095 00	NIPPLE	67	274
5501 8497 00	TUBE	8	78
5502 9911 00	INSERT	23	47

Part no Detaljnr	Description	Ref no	See page Se sida
5503 0024 00	ADAPTER FLANGE	3	298
5503 1907 00	MANIFOLD	14	172
5503 7225 00	PLUG	25	29
5503 7225 00	PLUG	22	32
5503 9644 00	HOSE ASSEMBLY	104	101
5504 6603 00	HOSE ASSEMBLY	103	101
5504 7646 00	HOSE ASSEMBLY	101	301
5504 8523 00	HOSE ASSEMBLY	112	316
5504 9797 00	HOSE ASSEMBLY	106	173
5504 9797 00	HOSE ASSEMBLY	104	173
5505 0761 00	HOSE ASSEMBLY	120	274
5505 1112 00	NIPPLE	8	86
5505 1431 00	HOSE ASSEMBLY	117	336
5505 5507 00	HOSE ASSEMBLY	104	336
5505 6286 00	BUSHING	20	110
5505 7504 00	HOSE ASSEMBLY	121	311
5505 8456 00	HOSE ASSEMBLY	102	110
5505 8460 00	HOSE ASSEMBLY	104	310
5505 8533 00	HOSE ASSEMBLY	103	173
5505 8687 00	HOSE ASSEMBLY	101	274
5506 2797 00	NIPPLE	15	298
5506 2845 00	PIPE CONNECTION	23	97
5506 2965 00	HOSE ASSEMBLY	104	274
5506 3052 00	HOSE ASSEMBLY	110	316
5506 3063 00	HOSE ASSEMBLY	103	89
5506 5984 00	HOSE ASSEMBLY	114	274
5506 5984 00	HOSE ASSEMBLY	115	274
5506 5984 00	HOSE ASSEMBLY	113	274
5506 5984 00	HOSE ASSEMBLY	112	274
5506 6573 00	HOSE ASSEMBLY	120	316

Part no Detaljnr	Description	Ref no	See page Se sida
5506 6854 00	HOSE ASSEMBLY	113	311
5506 6888 00	HOSE ASSEMBLY	129	316
5506 7404 00	HOSE ASSEMBLY	108	311
5506 9114 00	HOSE ASSEMBLY	114	301
5506 9114 00	HOSE ASSEMBLY	115	301
5506 9251 00	HOSE ASSEMBLY	118	311
5506 9453 00	HOSE ASSEMBLY	116	316
5506 9457 00	HOSE ASSEMBLY	109	311
5506 9458 00	HOSE ASSEMBLY	110	311
5506 9461 00	HOSE ASSEMBLY	116	311
5507 1571 00	NIPPLE	4	86
5507 1607 00	HOSE ASSEMBLY	102	89
5507 1620 00	HOSE ASSEMBLY	112	311
5507 1624 00	HOSE ASSEMBLY	102	316
5507 1630 00	HOSE ASSEMBLY	113	316
5507 1631 00	HOSE ASSEMBLY	114	316
5507 2064 00	HOSE SET	0	298
5507 2072 00	HOSE ASSEMBLY	102	274
5507 2091 00	HOSE ASSEMBLY	110	166
5507 2264 00	HOSE ASSEMBLY	108	336
5507 2373 00	HOSE ASSEMBLY	106	274
5507 2381 00	HOSE ASSEMBLY	106	166
5507 2390 00	HOSE ASSEMBLY	115	316
5507 2720 00	HOSE ASSEMBLY	107	311
5507 2724 00	HOSE ASSEMBLY	122	316
5507 2725 00	HOSE ASSEMBLY	123	316
5507 3056 00	HOSE ASSEMBLY	102	301
5507 3059 00	HOSE ASSEMBLY	110	274
5507 3059 00	HOSE ASSEMBLY	109	274
5507 3060 00	HOSE ASSEMBLY	116	274

Part no Detaljnr	Description	Ref no	See page Se sida
5507 3069 00	HOSE ASSEMBLY	103	166
5507 3070 00	HOSE ASSEMBLY	104	316
5507 3074 00	HOSE ASSEMBLY	101	310
5507 3076 00	HOSE ASSEMBLY	105	310
5507 3077 00	HOSE ASSEMBLY	119	311
5507 3138 00	HOSE ASSEMBLY	56	118
5507 3179 00	HOSE ASSEMBLY	117	316
5507 3180 00	HOSE ASSEMBLY	114	311
5507 3181 00	HOSE ASSEMBLY	115	311
5507 3850 00	HOSE ASSEMBLY	103	316
5507 3855 00	HOSE ASSEMBLY	104	166
5507 3856 00	HOSE ASSEMBLY	107	166
5507 3951 00	HOSE ASSEMBLY	103	301
5507 4159 00	HOSE ASSEMBLY	105	301
5507 4160 00	HOSE ASSEMBLY	106	301
5507 4161 00	HOSE ASSEMBLY	107	301
5507 4162 00	HOSE ASSEMBLY	110	301
5507 4163 00	HOSE ASSEMBLY	111	301
5507 4164 00	HOSE ASSEMBLY	116	301
5507 4165 00	HOSE ASSEMBLY	111	274
5507 4166 00	HOSE ASSEMBLY	109	316
5507 4170 00	HOSE ASSEMBLY	120	311
5507 4234 00	HOSE ASSEMBLY	102	101
5507 4353 00	HOSE ASSEMBLY	104	301
5507 4488 00	HOSE ASSEMBLY	101	316
5507 5010 00	HOSE ASSEMBLY	112	166
5507 5011 00	HOSE ASSEMBLY	113	166
5507 6422 00	HOSE ASSEMBLY	106	89
5507 7265 00	HOSE ASSEMBLY	111	336
5507 7567 00	WAGNER PART	22	110

Part no Detaljn	Description	Ref no	See page Se sida
5507 7714 00	HOSE ASSEMBLY	101	173
5507 7730 00	HOSE ASSEMBLY	108	316
5507 8168 00	HOSE ASSEMBLY	104	110
5507 8909 00	OBSOLETE	4	159
5508 1802 00	HOSE ASSEMBLY	110	336
5508 1914 00	HOSE LIST		86
5508 1940 00	HOSE SET	0	97
5530 0742 00	REPAIR SET		57
5530 5013 00	SCREW, HEX HEAD	71	315
5530 5013 00	SCREW, HEX HEAD	3	235
5530 5017 00	SCREW, HEX HEAD	5	235
5530 5017 00	SCREW, HEX HEAD	52	315
5530 5040 00	SCREW	7	32
5530 5056 00	SCREW, HEX HEAD	156	195
5530 5056 00	SCREW, HEX HEAD	37	97
5530 5056 00	SCREW, HEX HEAD	19	199
5530 5097 00	SCREW, HEX HEAD	27	298
5530 5106 00	FLAP COTTER	17	245
5530 5145 00	GREASE NIPPLE	45	47
5530 5145 00	GREASE NIPPLE	3	53
5530 5145 00	GREASE NIPPLE	13	55
5530 5145 00	GREASE NIPPLE	9	293
5530 5160 00	PLUG	14	199
5530 5164 00	CLEVIS PIN	16	245
5530 5257 00	SCREW, HEX HEAD	42	47
5530 5271 00	SET SCREW	27	57
5530 5272 00	SET SCREW	12	235
5530 6000 00	SCREW, HEX HEAD	63	315
5530 6004 00	SCREW, HEX HEAD	4	53
5530 6039 00	SCREW, HEX HEAD	61	315

Part no Detaljn	Description	Ref no	See page Se sida
5530 6043 00	SCREW, HEX HEAD	54	166
5530 6045 00	SCREW, HEX HEAD	64	315
5530 6046 00	SCREW, HEX HEAD	23	273
5530 6084 00	SCREW, HEX HEAD	25	298
5530 6084 00	SCREW, HEX HEAD	76	219
5530 6084 00	SCREW, HEX HEAD	22	165
5530 6119 00	SCREW, HEX HEAD	13	105
5530 6121 00	SCREW, HEX HEAD	26	298
5530 6137 00	SCREW, HEX HEAD	13	57
5530 6163 00	LOCK NUT	6	245
5530 6163 00	LOCK NUT	15	235
5530 6170 00	LOCK NUT	5	279
5530 6177 00	LOCK NUT	12	245
5530 7027 00	LOCK WASHER	15	117
5530 7029 00	LOCK WASHER	8	32
5530 7030 00	LOCK WASHER	43	47
5530 7032 00	LOCK WASHER	48	22
5530 7033 00	LOCK WASHER	7	105
5530 7053 00	WASHER	53	212
5530 7055 00	LOCK NUT	32	105
5530 7055 00	LOCK NUT	8	263
5530 7055 00	LOCK NUT	46	22
5530 7057 00	LOCK NUT	26	148
5530 7102 00	CLEVIS	14	235
5530 7112 00	LOCK NUT	12	55
5530 7116 00	LOCK NUT	74	315
5530 7116 00	LOCK NUT	6	71
5530 7116 00	LOCK NUT	35	97
5530 7116 00	LOCK NUT	7	235
5530 7116 00	LOCK NUT	33	32

Part no Detaljnr	Description	Ref no	See page Se sida
5530 7116 00	LOCK NUT	15	245
5530 7116 00	LOCK NUT	90	11
5530 7116 00	LOCK NUT	25	21
5530 7116 00	LOCK NUT	15	78
5530 7116 00	LOCK NUT	41	148
5530 7116 00	LOCK NUT	42	86
5530 7116 00	LOCK NUT	13	335
5530 7116 00	LOCK NUT	57	166
5530 7116 00	LOCK NUT	37	310
5530 7116 00	LOCK NUT	27	86
5530 7116 00	LOCK NUT	33	117
5530 7116 00	LOCK NUT	39	22
5530 7123 00	CLEVIS	13	245
5530 7241 00	LOCK NUT	10	66
5530 7241 00	LOCK NUT	3	17
5530 7241 00	LOCK NUT	58	47
5530 7241 00	LOCK NUT	5	187
5530 7356 00	LOCK NUT	4	15
5530 7356 00	LOCK NUT	44	47
5530 7356 00	LOCK NUT	13	66
5530 7400 00	PLUG	35	212
5530 7531 00	SCREW, HEX HEAD	54	315
5530 7531 00	SCREW, HEX HEAD	21	172
5530 7551 00	LOCK NUT	7	269
5530 7551 00	LOCK NUT	88	11
5530 7551 00	LOCK NUT	6	53
5530 7551 00	LOCK NUT	32	335
5530 7551 00	LOCK NUT	28	298
5530 7551 00	LOCK NUT	16	148
5530 7551 00	LOCK NUT	21	21

Part no Detaljnr	Description	Ref no	See page Se sida
5530 7551 00	LOCK NUT	14	105
5530 7552 00	LOCK NUT	6	125
5530 7552 00	LOCK NUT	7	241
5530 7552 00	LOCK NUT	35	117
5530 7552 00	LOCK NUT	8	335
5530 7552 00	LOCK NUT	4	261
5530 7721 00	NUT	6	215
5530 7880 00	SCREW, HEX HEAD	2	15
5530 7892 00	PLUG	150	195
5530 7892 00	PLUG	27	32
5530 7894 00	PLUG	24	29
5530 7895 00	PLUG	23	29
5530 8072 00	SCREW, HEX HEAD	6	66
5530 8072 00	SCREW, HEX HEAD	14	57
5530 8108 00	WASHER	39	173
5530 8111 00	HEXAGON NUT	32	32
5530 8144 00	SCREW, HEX HEAD	5	13
5530 8318 00	SCREW, HEX HEAD	21	273
5530 8458 00	SCREW, HEX HEAD	11	66
5530 8472 00	SCREW, HEX HEAD	9	105
5530 8478 00	SCREW, HEX HEAD	47	315
5530 8490 00	SCREW, HEX HEAD	28	148
5530 8511 00	LOCK NUT	71	219
5530 8517 00	SCREW, HEX HEAD	6	105
5530 8576 00	SCREW, HEX HEAD	57	47
5530 8645 00	SCREW, HEX HEAD	38	118
5530 8687 00	PLUG	16	78
5530 8688 00	HEXAGON NUT	2	225
5530 8817 00	SCREW, HEX HEAD	3	187
5530 8977 00	SCREW, HEX HEAD	3	32

Part no Detaljnr	Description	Ref no	See page Se sida
5530 8985 00	WELDING BOLT	39	335
5530 9109 00	SCREW, HEX HEAD	25	148
5530 9141 00	WASHER	42	22
5530 9218 00	SCREW, HEX HEAD	29	298
5530 9234 00	SCREW, HEX HEAD	8	133
5530 9235 00	SCREW, HEX HEAD	2	17
5530 9466 00	SCREW, HEX HEAD	44	166
5530 9645 00	LOCK NUT	19	172
5530 9821 00	SCREW, HEX HEAD	7	133
5530 9821 00	SCREW, HEX HEAD	2	145
5530 9880 00	CAPSCREW	66	315
5531 0059 00	GREASE NIPPLE	17	69
5531 0060 00	LOCK NUT	6	293
5531 0127 00	LOCK NUT	69	315
5531 0128 00	LOCK NUT	6	41
5531 0199 00	SCREW, HEX HEAD	9	133
5531 0417 00	SCREW, HEX HEAD	30	310
5531 0417 00	SCREW, HEX HEAD	25	273
5531 0417 00	SCREW, HEX HEAD	16	191
5531 0603 00	SCREW, HEX HEAD	30	57
5531 0673 00	FLANGE SCREW	35	78
5531 0686 00	FLANGE NUT	11	78
5531 0783 00	LOCK NUT	9	217
5531 0783 00	LOCK NUT	101	220
5531 0783 00	LOCK NUT	10	245
5531 0800 00	LOCK NUT	3	145
5531 0800 00	LOCK NUT	10	133
5531 0831 00	SCREW, HEX HEAD	8	66
5531 0854 00	CAPSCREW	68	315
5532 5179 00	CAPSCREW	17	303

Part no Detaljnr	Description	Ref no	See page Se sida
5532 5205 00	BALL	24	303
5532 5208 00	QUAD-RING	32	304
5532 5212 00	SEAL	33	304
5532 5222 00	CAPSCREW	18	303
5532 5267 00	SCREW	19	303
5532 5270 00	NUT	20	303
5532 5272 00	NUT	21	303
5532 5286 00	WASHER	22	303
5532 5320 00	O-RING	44	304
5532 5321 00	RING	26	303
5532 5345 00	WASHER	27	303
5532 5367 00	SPRING	28	303
5532 5373 00	SPRING	45	304
5532 5380 00	SPRING	29	303
5532 5390 00	SPRING	30	303
5532 5396 00	RING	31	304
5532 5423 00	PIN	43	304
5532 8589 00	SEAL	34	304
5532 8743 00	CLAMP	12	75
5532 8803 00	O-RING	11	75
5532 9331 00	VALVE	1	298
5532 9984 00	FLAP COTTER	172	195
5532 9984 00	FLAP COTTER	127	194
5532 9994 00	RIVET	15	203
5532 9996 00	RIVET	9	203
5532 9997 00	RIVET	11	203
5533 0091 00	BALL	51	218
5533 0091 00	BALL	10	179
5533 0091 00	BALL	10	175
5533 0093 00	BALL	34	200

Part no Detaljn	Description	Ref no	See page Se sida
5533 0093 00	BALL	88	193
5533 0093 00	BALL	8	199
5533 0097 00	BALL	65	212
5533 0450 00	ROLLER	5	211
5533 0450 00	ROLLER	8	211
5533 2168 00	VALVE	26	117
5533 2454 00	BUSHING	28	217
5533 2721 00	O-RING	50	212
5533 2721 00	O-RING	12	223
5533 2721 00	O-RING	2	223
5533 2721 00	O-RING	60	212
5533 2721 00	O-RING	41	200
5533 2721 00	O-RING	61	212
5533 2724 00	O-RING	3	314
5533 2727 00	O-RING	2	314
5533 2727 00	O-RING	30	298
5533 2727 00	O-RING	59	274
5533 2727 00	O-RING	27	165
5533 2728 00	O-RING	31	298
5533 2728 00	O-RING	28	165
5533 2728 00	O-RING	29	314
5533 2729 00	O-RING	61	274
5533 2729 00	O-RING	29	165
5533 2731 00	O-RING	32	298
5533 2731 00	O-RING	30	165
5533 2733 00	O-RING	6	183
5533 2736 00	O-RING	2	32
5533 2740 00	O-RING	39	218
5533 2754 00	O-RING	20	29
5533 2754 00	O-RING	22	35

Part no Detaljn	Description	Ref no	See page Se sida
5533 2883 00	BUSHING	21	295
5533 2883 00	BUSHING	21	47
5533 2910 00	COVER	60	218
5533 2910 00	COVER	62	218
5533 2987 00	STUD	69	219
5533 3103 00	SCREW	152	195
5533 3103 00	SCREW	133	194
5533 3103 00	SCREW	177	196
5533 3239 00	SPRING	3	223
5533 3350 00	RING	8	205
5533 3350 00	RING	8	207
5533 3351 00	SUPPORT COMPL	123	194
5533 3351 00	SUPPORT COMPL	86	193
5533 3352 00	DRUM	20	209
5533 3354 00	PISTON	18	209
5533 3355 00	RING	7	209
5533 3356 00	PISTON	9	209
5533 3364 00	BEARING PART	16	207
5533 3364 00	BEARING PART	18	205
5533 3368 00	END PLATE	7	207
5533 3368 00	END PLATE	7	205
5533 3370 00	PISTON	9	205
5533 3370 00	PISTON	9	207
5533 3377 00	GEAR	149	195
5533 3383 00	GEAR	59	192
5533 3384 00	GEAR	24	191
5533 3384 00	GEAR	11	191
5533 3385 00	PISTON RING	11	207
5533 3385 00	PISTON RING	12	205
5533 3387 00	RING	8	209

Part no Detaljnr	Description	Ref no	See page Se sida
5533 3400 00	FLANGE	167	195
5533 3400 00	FLANGE	10	217
5533 3400 00	FLANGE	140	194
5533 3401 00	CAP	41	192
5533 3402 00	CAP	29	191
5533 3403 00	GASKET	42	192
5533 3403 00	GASKET	28	191
5533 3405 00	SPACER	115	194
5533 3405 00	SPACER	91	193
5533 3406 00	SPACER	44	192
5533 3409 00	SPACER	48	192
5533 3409 00	SPACER	10	191
5533 3411 00	BAFFLE PLATE	1	209
5533 3427 00	OIL PAN	153	195
5533 3449 00	SHIELD	68	193
5533 3450 00	SPRING	4	207
5533 3450 00	SPRING	4	209
5533 3450 00	SPRING	4	205
5533 3457 00	COVER	175	196
5533 3464 00	SPACER	66	193
5533 3465 00	CAP	60	192
5533 3466 00	COVER PLATE	67	213
5533 3471 00	SPOOL	45	212
5533 3472 00	SPRING	47	212
5533 3475 00	SPRING	57	212
5533 3476 00	SPRING	58	212
5533 3477 00	VALVE	66	212
5533 3479 00	SPACER	64	212
5533 3480 00	GASKET	12	191
5533 3482 00	WASHER	3	199

Part no Detaljnr	Description	Ref no	See page Se sida
5533 3485 00	SHIM	165	195
5533 3486 00	SHIM	165	195
5533 3487 00	SHIM	165	195
5533 3488 00	SHIM	61	192
5533 3489 00	SHIM	61	192
5533 3490 00	SHIM	61	192
5533 3491 00	RING	24	209
5533 3494 00	TUBE	19	203
5533 3496 00	TUBE	23	203
5533 3501 00	TUBE	24	203
5533 3502 00	TUBE	18	203
5533 3504 00	TUBE	2	203
5533 3505 00	TUBE	4	203
5533 3506 00	TUBE	3	203
5533 3507 00	COVER	79	193
5533 3533 00	GASKET	158	195
5533 3536 00	SHAFT	148	195
5533 3537 00	LOCK	143	221
5533 3538 00	DISK	142	221
5533 3539 00	DISK	130	221
5533 3539 00	DISK	129	220
5533 3539 00	DISK	144	221
5533 3540 00	PLATE	141	221
5533 3542 00	TURBINE	135	221
5533 3543 00	BAFFLE PLATE	91	219
5533 3544 00	RING	131	221
5533 3546 00	SLEEVE	58	218
5533 3547 00	SHAFT	46	218
5533 3548 00	SHAFT	18	217
5533 3549 00	TUBE	37	218

Part no Detaljnr	Description	Ref no	See page Se sida
5533 3550 00	SPACER	3	217
5533 3551 00	SHIM	67	219
5533 3552 00	SHIM	67	219
5533 3553 00	SHIM	67	219
5533 3554 00	SHIM	17	217
5533 3555 00	SHIM	17	217
5533 3556 00	SHIM	17	217
5533 3567 00	RING	126	220
5533 3568 00	O-RING	44	218
5533 3570 00	SPACER	84	219
5533 3573 00	RETAINER	146	221
5533 3576 00	ADAPTER	65	219
5533 3577 00	CAP	35	218
5533 3689 00	STOP BLOCK	48	212
5533 3708 00	DOWEL PIN	139	221
5533 3716 00	PUMP DRIVE	98	220
5533 3726 00	BAFFLE PLATE	1	217
5533 3728 00	TUBE	22	217
5533 3731 00	WASHER	94	219
5533 3732 00	STOP	42	200
5533 3732 00	STOP	59	212
5533 3732 00	STOP	13	223
5533 3732 00	STOP	51	212
5533 3732 00	STOP	62	212
5533 3732 00	STOP	1	223
5533 3739 00	WASHER	11	217
5533 3739 00	WASHER	93	193
5533 3739 00	WASHER	171	195
5533 3739 00	WASHER	138	194
5533 3739 00	WASHER	114	194

Part no Detaljnr	Description	Ref no	See page Se sida
5533 3750 00	HUB	114	220
5533 3784 00	COVER	31	217
5533 3785 00	GASKET	30	217
5533 3820 00	RING	22	209
5533 3824 00	RING	67	193
5533 3828 00	RING	21	217
5533 3834 00	RING	108	220
5533 3835 00	RING	16	209
5533 3835 00	RING	90	193
5533 3835 00	RING	120	194
5533 3836 00	RING	115	220
5533 3845 00	RING	82	219
5533 3846 00	RING	107	220
5533 3882 00	HOSE	140	221
5533 3957 00	BEARING	121	194
5533 3957 00	BEARING	89	193
5533 3983 00	SEAL	15	217
5533 3983 00	SEAL	163	195
5533 3983 00	SEAL	145	195
5533 3985 00	BEARING	17	209
5533 3986 00	BEARING	85	219
5533 3987 00	BEARING	125	220
5533 4001 00	BEARING	49	192
5533 4001 00	BEARING	9	191
5533 4002 00	BEARING	27	191
5533 4002 00	BEARING	45	192
5533 4003 00	BEARING	113	194
5533 4003 00	BEARING	94	193
5533 4047 00	GASKET	14	223
5533 4050 00	VALVE	28	217

Part no Detaljnr	Description	Ref no	See page Se sida
5533 4051 00	SPRING	15	223
5533 4052 00	PLUG	1	211
5533 4053 00	PLUG	33	212
5533 4053 00	PLUG	16	211
5533 4054 00	PLUG	7	211
5533 4055 00	DISK	6	207
5533 4055 00	DISK	6	205
5533 4059 00	VALVE	18	211
5533 4060 00	VALVE	19	211
5533 4061 00	PLUG	23	211
5533 4062 00	VALVE	22	211
5533 4090 00	VALVE	10	211
5533 4091 00	VALVE	3	211
5533 4107 00	PISTON	25	217
5533 4215 00	PISTON	4	199
5533 4217 00	SPRING	8	199
5533 4218 00	SPRING	39	200
5533 4219 00	PIN	7	199
5533 4233 00	DIP STICK	21	191
5533 4240 00	PIN	36	200
5533 4241 00	SPRING	35	200
5533 4423 00	CRANK	57	218
5533 4591 00	PLUG	12	211
5533 5001 00	YOKE	2	155
5533 5318 00	BRACKET	2	25
5533 5391 00	HOOD SUPPORT	3	25
5533 5496 00	BLEEDER SCREW	44	315
5533 6149 00	CUP	42	218
5533 6149 00	CUP	5	217
5533 6149 00	CUP	95	219

Part no Detaljnr	Description	Ref no	See page Se sida
5533 6269 00	PLUG	186	196
5533 6269 00	PLUG	56	212
5533 6391 00	SEAT	4	303
5533 6392 00	SEAT	5	303
5533 6394 00	POPPET VALVE	3	303
5533 6397 00	RETAINER	36	304
5533 6403 00	GUIDE	37	304
5533 6405 00	RETAINER	6	303
5533 6412 00	RETAINER	7	303
5533 6438 00	VALVE	21	86
5533 6593 00	PACKING	9	303
5533 6801 00	FILLER	23	191
5533 6841 00	KNOB	97	11
5533 6907 00	PLUNGER	8	303
5533 6909 00	VALVE	41	304
5533 6954 00	CAP	10	303
5533 6958 00	SOCKET	38	304
5533 6959 00	CAP	39	304
5533 6969 00	EYE	40	304
5533 7029 00	PLATE	14	303
5533 7035 00	RETAINER	12	303
5533 7182 00	PLUNGER	42	304
5533 7216 00	PLUG	16	303
5533 7366 00	WASHER	105	220
5533 7368 00	TUBE	13	203
5533 7368 00	TUBE	8	203
5533 7369 00	TUBE	16	203
5533 7456 00	WASHER	109	220
5533 7539 00	PIN	4	223
5533 7539 00	PIN	9	223

Part no Detaljn	Description	Ref no	See page Se sida
5533 7658 00	LOCKING PIN	14	211
5533 7708 00	LATCH	1	25
5533 8045 00	RING	14	209
5533 8206 00	SPACER RING	15	303
5533 8208 00	SPACER RING	35	304
5533 9096 00	O-RING	6	217
5533 9100 00	O-RING	35	192
5533 9588 00	HOUSING	19	191
5533 9589 00	DIP STICK	20	191
5533 9648 00	SPOOL	28	199
5533 9652 00	SPRING	27	199
5533 9675 00	FLANGE	34	192
5533 9678 00	SPACER	13	199
5533 9690 00	RING	127	220
5533 9692 00	DISK	5	209
5533 9705 00	DISK	6	209
5533 9731 00	PIN	13	211
5533 9732 00	PIN	116	220
5533 9803 00	STOP	24	199
5533 9963 00	LOCK WASHER	110	220
5533 9963 00	LOCK WASHER	131	194
5533 9990 00	CAP	22	191
5533 9992 00	PIPE FITTING	118	194
5533 9994 00	ADAPTER	24	211
5533 9994 00	ADAPTER	41	212
5534 0003 00	SCREW	130	194
5534 0028 00	PLUG	44	200
5534 0028 00	PLUG	32	200
5534 0143 00	O-RING	144	195
5534 0143 00	O-RING	164	195

Part no Detaljn	Description	Ref no	See page Se sida
5534 0144 00	O-RING	15	295
5534 0148 00	O-RING	123	220
5534 0154 00	O-RING	7	41
5534 0154 00	O-RING	25	32
5534 0154 00	O-RING	5	189
5534 0265 00	SEAL KIT	0	303
5534 0272 00	SEAL KIT	0	303
5534 0824 00	CONE	147	195
5534 0824 00	CONE	161	195
5534 0837 00	CUP	2	217
5534 0838 00	CONE	20	217
5534 0889 00	CUP	48	218
5534 0890 00	CONE	47	218
5534 1334 00	SPRING	18	199
5534 1334 00	SPRING	6	199
5534 1334 00	SPRING	7	199
5534 1361 00	SEAL	30	192
5534 1435 00	PUMP DRIVE	79	219
5534 1441 00	STUD	103	220
5534 1455 00	GEAR	160	195
5534 1456 00	GEAR	116	194
5534 1457 00	RING	11	205
5534 1457 00	RING	10	207
5534 1490 00	CAP	16	217
5534 1491 00	PLATE	132	221
5534 1492 00	PLATE	133	221
5534 1706 00	DRAIN VALVE	10	39
5534 2231 00	RING	53	218
5534 2503 00	BEARING	80	219
5534 2531 00	VALVE	11	211

Part no Detaljnr	Description	Ref no	See page Se sida
5534 2539 00	HOUSING	4	211
5534 2799 00	ELEMENT	2	113
5534 4092 00	TUBE	7	203
5534 4099 00	SPOOL	11	223
5534 4664 00	SEAL NUT	4	227
5534 5330 00	CLAMP	20	69
5534 5551 00	GAUGE	21	32
5534 5551 00	GAUGE	4	27
5534 5551 00	GAUGE	39	98
5534 5634 00	SEAL	1	199
5534 5634 00	SEAL	26	199
5534 5753 00	RING	9	295
5534 5788 00	SEAL	4	277
5534 5791 00	GASKET	10	277
5534 6189 00	RING	84	193
5534 6189 00	RING	125	194
5534 6190 00	RING	83	193
5534 6190 00	RING	126	194
5534 6367 00	GASKET	5	75
5534 6368 00	NUT	2	75
5534 6738 00	SEAL	68	219
5534 6929 00	HOSE ASSEMBLY	15	71
5534 7225 00	BALL	10	199
5534 7360 00	HOUSING	11	303
5534 7657 00	WASHER	49	87
5534 8254 00	SEAL PLUG	71	252
5534 8485 00	REPAIR KIT	1	43
5534 9435 00	ROD END	5	245
5535 0429 00	GEAR	23	209
5535 0467 00	FLANGE	13	35

Part no Detaljnr	Description	Ref no	See page Se sida
5535 0473 00	PLUG	10	223
5535 0482 00	MOUNT	16	71
5535 0503 00	CLAMP	7	78
5535 0518 00	RING	19	295
5535 0519 00	RING	20	295
5535 0520 00	O-RING	10	295
5535 0521 00	SEAL	16	295
5535 0522 00	SEAL	12	295
5535 0522 00	SEAL	7	295
5535 0525 00	RING	11	295
5535 0526 00	RING	14	295
5535 0528 00	FLANGE	5	155
5535 0686 00	HOUSING ASSY	15	199
5535 0693 00	WASHER	17	199
5535 0699 00	PLUG	16	199
5535 0898 00	RING	8	295
5535 0899 00	RING	17	295
5535 0931 00	V-BELT	6	69
5535 1047 00	BUSHING	3	239
5535 1150 00	SHAFT	72	193
5535 1151 00	BEARING	70	193
5535 1152 00	GEAR	117	194
5535 1153 00	SHAFT	69	193
5535 1313 00	SCREW, HEX HEAD	58	166
5535 1809 00	CYLINDER SET		295
5535 2442 00	FITTING	12	71
5535 2447 00	RUBBER	10	71
5535 2573 00	CAP	2	73
5535 2712 00	GASKET	80	193
5535 2716 00	ELEMENT	20	39

Part no Detaljn	Description	Ref no	See page Se sida
5535 2776 00	VALVE	26	32
5535 2806 00	PIN	6	59
5535 2806 00	PIN	6	49
5535 3213 00	GASKET	155	195
5535 3214 00	GASKET	174	196
5535 3228 00	INDICATOR	17	71
5535 3251 00	RING	13	295
5535 3361 00	O-RING	4	39
5535 3362 00	WINDOW	5	39
5535 3363 00	KIT	6	39
5535 3378 00	O-RING	7	39
5535 3379 00	PLUG	8	39
5535 3380 00	O-RING	9	39
5535 3383 00	SEAL	12	39
5535 3384 00	SPRING	13	39
5535 3385 00	BOLT	14	39
5535 3386 00	MAGNET	15	39
5535 3388 00	BODY	17	39
5535 3389 00	BRACKET	18	39
5535 3390 00	O-RING	19	39
5535 3781 00	WASHER	151	195
5535 3781 00	WASHER	132	194
5535 3781 00	WASHER	176	196
5535 3782 00	CAP	143	195
5535 3782 00	CAP	166	195
5535 3927 00	SUPPORT COMPL	5	191
5535 3927 00	SUPPORT COMPL	53	192
5535 3927 00	SUPPORT COMPL	98	193
5535 3927 00	SUPPORT COMPL	109	194
5535 3928 00	CUP	21	205

Part no Detaljn	Description	Ref no	See page Se sida
5535 3929 00	CONE	22	205
5535 3931 00	BEARING	17	205
5535 3931 00	BEARING	15	207
5535 3932 00	BEARING	14	207
5535 3932 00	BEARING	16	205
5535 4511 00	WASHER	15	209
5535 4557 00	FILTER	1	37
5535 4734 00	YOKE	2	153
5535 4734 00	YOKE	2	151
5535 4734 00	YOKE	2	157
5535 4829 00	HEAD	2	39
5535 4830 00	VALVE	11	39
5535 4832 00	TUBE	16	39
5535 4889 00	COVER	1	75
5535 4890 00	CLAMP	9	75
5535 4967 00	PIN	11	277
5535 4968 00	HOUSING	9	277
5535 4973 00	PLATE	5	277
5535 5007 00	CLAMP	19	69
5535 5074 00	CAP	11	71
5535 5114 00	DRUM	20	205
5535 5115 00	BEARING	21	209
5535 5146 00	FLANGE	9	35
5535 5198 00	O-RING	5	327
5535 5426 00	VALVE	3	73
5535 5531 00	PISTON RING	124	220
5535 5532 00	SPRING	147	221
5535 5536 00	FLANGE	50	315
5535 5619 00	BEARING	6	155
5535 6250 00	KIT	10	261

Part no Detaljn	Description	Ref no	See page Se sida
5535 6275 00	VALVE	3	227
5535 7209 00	BEARING	3	153
5535 7209 00	BEARING	3	157
5535 7209 00	BEARING	1	159
5535 7209 00	BEARING	2	159
5535 7209 00	BEARING	4	153
5535 7209 00	BEARING	3	151
5535 7210 00	BEARING	4	157
5535 7219 00	VALVE	33	314
5535 8426 00	CLAMP	13	97
5535 8859 00	VALVE	4	273
5535 8979 00	CARTRIDGE	3	121
5535 8980 00	CARTRIDGE	4	121
5535 9158 00	FLANGE SCREW	28	78
5535 9883 00	CAP	6	189
5536 1070 00	YOKE	3	159
5536 1748 00	FLANGE	51	315
5536 2608 00	ANSUL SYSTEM	20	117
5536 2760 00	ELEMENT	6	75
5536 2785 00	CLAMP	9	71
5536 2786 00	CLAMP	19	71
5536 2809 00	U-BOLT	12	117
5536 3183 00	TRANSMISSION	92	193
5536 3184 00	TUBE	20	203
5536 3185 00	TUBE	21	203
5536 3186 00	TUBE	22	203
5536 3766 00	PLUG	29	327
5536 3858 00	CLAMP	40	86
5536 3858 00	CLAMP	9	97
5536 4023 00	RING	2	239

Part no Detaljn	Description	Ref no	See page Se sida
5536 4091 00	O-RING	86	219
5536 4097 00	O-RING	112	220
5536 4553 00	FLANGE SCREW	84	11
5536 4571 00	LENS	40	251
5536 4764 00	MOUNT	97	220
5536 4792 00	PLUG	7	277
5536 5332 00	DISK	5	205
5536 5332 00	DISK	5	207
5536 5349 00	PLUG	1	175
5536 5349 00	PLUG	5	179
5536 5349 00	PLUG	20	175
5536 5349 00	PLUG	1	179
5536 5349 00	PLUG	5	175
5536 5349 00	PLUG	20	179
5536 5408 00	BEARING	3	277
5536 5409 00	SEAL RING	2	277
5536 5883 00	DETAILS	83	219
5536 5884 00	TURBINE	138	221
5536 6300 00	SLEEVE	13	273
5536 6470 00	NUT	3	39
5536 6916 00	SPRING	63	212
5536 6939 00	IMPELLER	113	220
5536 8090 00	SEAT	2	229
5536 8661 00	FILTER	2	110
5536 9206 00	SPOOL	52	212
5537 0013 00	BRACKET	22	117
5537 0095 00	TRIGGER	23	117
5537 0239 00	VALVE	25	117
5537 0522 00	SPRING	7	179
5537 0522 00	SPRING	7	175

Part no Detaljn	Description	Ref no	See page Se sida
5537 0986 00	SPRING	18	175
5537 0986 00	SPRING	18	179
5537 0987 00	SPRING	17	175
5537 0987 00	SPRING	17	179
5537 1079 00	BEARING	2	235
5537 1136 00	CLAMP	9	269
5537 1136 00	CLAMP	13	71
5537 1189 00	PIN	41	335
5537 1198 00	FIRE EXTINGUIS.	1	125
5537 1199 00	MOUNT	2	125
5537 1564 00	FRAME	159	195
5537 1567 00	TUBE	17	203
5537 1568 00	TUBE	25	203
5537 1583 00	CONE	20	207
5537 1690 00	LOCK	4	229
5537 1716 00	SIDE	3	229
5537 1906 00	NOZZLE	9	117
5537 1931 00	SEAL KIT		323
5537 2070 00	SPRING	4	183
5537 2622 00	PROTECTION	9	323
5537 2623 00	PROTECT. SCREW	9A	323
5537 2773 00	REDUCER	4	189
5537 2961 00	REPAIR KIT	0	325
5537 2976 00	CLAMP	17	165
5537 3149 00	SWITCH	9	199
5537 3188 00	RING	117	220
5537 3188 00	RING	58	192
5537 3211 00	RELIEF VALVE	7	285
5537 3232 00	BODY	21	39
5537 3278 00	GASKET	99	220

Part no Detaljn	Description	Ref no	See page Se sida
5537 3278 00	GASKET	96	219
5537 3436 00	GUIDE	26	211
5537 3436 00	GUIDE	39	212
5537 3437 00	PISTON	37	212
5537 3437 00	PISTON	28	211
5537 3438 00	STOP	29	211
5537 3439 00	SPACER	30	211
5537 3440 00	SPRING	31	211
5537 3441 00	SLEEVE	32	211
5537 3443 00	COVER	55	212
5537 3610 00	VALVE	15	191
5537 3877 00	CLAMP	3	81
5537 3877 00	CLAMP	1	83
5537 3877 00	CLAMP	32	78
5537 3878 00	GASKET	33	78
5537 3878 00	GASKET	2	83
5537 3878 00	GASKET	4	81
5537 3879 00	PLUG	5	81
5537 4037 00	SEAL	6	277
5537 4284 00	PLUG	24	250
5537 4323 00	O-RING	8A	323
5537 4546 00	STUD	1	285
5537 4551 00	COVER	3	285
5537 4560 00	SEAL KIT	6	285
5537 4605 00	WASHER	4	263
5537 4616 00	RING	89	219
5537 4618 00	BACK PART	136	221
5537 4619 00	SCREW	137	221
5537 4630 00	PLUG	1	169
5537 4631 00	FILTER ELEMENT	3	169

Part no Detaljn	Description	Ref no	See page Se sida
5537 4963 00	SPOOL	4	199
5537 4965 00	SELECTOR SWITCH	22	199
5537 4966 00	MOUNTING PLATE	31	200
5537 4967 00	O-RING	44	200
5537 4967 00	O-RING	32	200
5537 4994 00	SPACER	49	328
5537 4995 00	SPRING	50	328
5537 4996 00	POPPET VALVE	51	328
5537 4997 00	HANDLE	52	328
5537 4998 00	O-RING	22	327
5537 4999 00	BALL	23	327
5537 5000 00	BALL	24	327
5537 5001 00	SPRING	25	327
5537 5002 00	SPRING	26	327
5537 5003 00	SPRING	27	327
5537 5004 00	PLUG	28	327
5537 5005 00	PLUG	30	327
5537 5015 00	CAP	46	328
5537 5016 00	GASKET	47	328
5537 5017 00	SPACER	48	328
5537 5023 00	PLUNGER	2	327
5537 5024 00	PACKING	3	327
5537 5025 00	CAP	4	327
5537 5028 00	PACKING	7	327
5537 5029 00	PIN	8	327
5537 5030 00	SEAL	10	327
5537 5031 00	RETAINER	11	327
5537 5032 00	SCREW	12	327
5537 5033 00	SEAT	13	327
5537 5034 00	PLUG	14	327

Part no Detaljn	Description	Ref no	See page Se sida
5537 5035 00	BALL	15	327
5537 5036 00	VALVE	16	327
5537 5037 00	O-RING	17	327
5537 5038 00	LEVER	18	327
5537 5039 00	SCREW	19	327
5537 5040 00	O-RING	20	327
5537 5041 00	SEAT	21	327
5537 5077 00	KIT	8	285
5537 5078 00	SEAL KIT	9	285
5537 5170 00	BACK-UP RING	9	327
5537 5171 00	PLUG	33	328
5537 5194 00	RING	8	183
5537 5196 00	COUPLE	27	273
5537 5267 00	RING	43	200
5537 5455 00	CARTRIDGE	8	321
5537 5532 00	COVER	4	319
5537 5534 00	CHANNEL	7	319
5537 5535 00	CROSS	8	319
5537 5538 00	HOUSING	12	319
5537 5539 00	DOWEL PIN	11	319
5537 5540 00	COVER	17	319
5537 5541 00	SCREW	18	319
5537 5542 00	WASHER	19	319
5537 5542 00	WASHER	13	277
5537 5547 00	CONE	2	81
5537 5548 00	CONE	2	81
5537 5554 00	CAP	2	27
5537 5677 00	VALVE	5	273
5537 5835 00	CLAMP	10	78
5537 5872 00	BOLT	4	191

Part no Detaljnr	Description	Ref no	See page Se sida
5537 5872 00	BOLT	54	192
5537 5872 00	BOLT	99	193
5537 5872 00	BOLT	52	218
5537 5872 00	BOLT	124	194
5537 5872 00	BOLT	85	193
5537 5872 00	BOLT	108	194
5537 5898 00	SEAL KIT	0	181
5537 6169 00	PLUG	25	172
5537 6393 00	SPRING	13	209
5537 6395 00	PISTON	12	209
5537 6893 00	PLUG	61	218
5537 6985 00	RING	12	207
5537 6985 00	RING	14	205
5537 6986 00	WASHER	12A	207
5537 6986 00	WASHER	14	205
5537 6987 00	WASHER	15	205
5537 6987 00	WASHER	13	207
5537 6988 00	WASHER	15	205
5537 6988 00	WASHER	13A	207
5537 6989 00	WASHER	15	205
5537 6989 00	WASHER	13B	207
5537 7006 00	VALVE	13	285
5537 7009 00	KIT	4	285
5537 7010 00	ACTUATOR	11	285
5537 7011 00	SEAL KIT	12	285
5537 7012 00	ACTUATOR	10	285
5537 7183 00	VALVE	8	223
5537 7590 00	SPRING	3	207
5537 7590 00	SPRING	3	209
5537 7590 00	SPRING	3	205

Part no Detaljnr	Description	Ref no	See page Se sida
5537 7591 00	CHECK VALVE	33	200
5537 7888 00	VALVE	4	314
5537 7987 00	CARTRIDGE	12	310
5537 8092 00	CROSS	2	285
5537 8093 00	VALVE	5	285
5537 8114 00	BOLT	7	81
5537 8122 00	SEAL KIT	3	321
5537 8123 00	SEAL KIT	5	321
5537 8124 00	SEAL KIT	7	321
5537 8124 00	SEAL KIT	0	185
5537 8125 00	SEAL KIT	9	321
5537 8125 00	SEAL KIT	4	287
5537 8137 00	DETAILS	2540	141
5537 8163 00	BODY	1	81
5537 8455 00	TEE	11	117
5537 8630 00	SOLENOID	15	172
5537 8735 00	BOLT	2470	141
5537 8776 00	FLANGE	2	135
5537 8780 00	PIN	3640	138
5537 8781 00	LOCK	2060	141
5537 8782 00	PLATE	2070	141
5537 8786 00	CAP	1940	141
5537 8791 00	OIL SEPARAT.	2430	141
5537 8794 00	NUT	2520	141
5537 8795 00	WASHER	2530	141
5537 8835 00	VALVE	2	325
5537 8847 00	O-RING	1030	137
5537 8847 00	O-RING	1110	137
5537 8853 00	BREATHER	1380	137
5537 8854 00	CAP	1390	137

Part no Detaljnr	Description	Ref no	See page Se sida
5537 8872 00	SPRING	9	245
5537 8911 00	VALVE	11	172
5537 8923 00	NUT	95	193
5537 8923 00	NUT	50	192
5537 8923 00	NUT	6	191
5537 8923 00	NUT	110	194
5537 8941 00	RING	129	194
5537 8941 00	RING	81	193
5540 0018 00	BOLT	3920	138
5540 0025 00	RETAINING RING	4740	139
5540 0035 00	HUB	2	205
5540 0343 00	GEAR	54	218
5540 0540 00	SCREW, HEX HEAD	8	247
5540 0541 00	WASHER	5	247
5540 0573 00	BEARING	2420	141
5540 0577 00	O-RING	1320	137
5540 0586 00	O-RING	1330	137
5540 0587 00	SPRING	1340	137
5540 0588 00	BOLT	1640	137
5540 0589 00	BOLT	1350	137
5540 0591 00	PISTON	1400	137
5540 0595 00	WASHER	1360	137
5540 0595 00	WASHER	1650	137
5540 0628 00	DOWEL PIN	3930	138
5540 0675 00	MAGNET	154	195
5540 0695 00	O-RING	170	195
5540 0695 00	O-RING	14	217
5540 0695 00	O-RING	139	194
5540 0696 00	BEARING	93	219
5540 0700 00	AIR CLEANING	1	73

Part no Detaljnr	Description	Ref no	See page Se sida
5540 0722 00	PIN	9	175
5540 0722 00	PIN	9	179
5540 0793 00	RING	104	193
5540 0793 00	RING	57	192
5540 0793 00	RING	1	191
5540 0793 00	RING	105	194
5540 0797 00	SPACER	25	191
5540 0797 00	SPACER	47	192
5540 0798 00	SHAFT	46	192
5540 0798 00	SHAFT	26	191
5540 0820 00	BOLT	72	219
5540 0825 00	SPRING	3	175
5540 0825 00	SPRING	3	179
5540 0826 00	SPOOL	4	179
5540 0826 00	SPOOL	4	175
5540 0828 00	SCREW	14	175
5540 0829 00	VALVE	24	175
5540 0830 00	PLATE	25	175
5540 0839 00	STRAINER	24	32
5540 0882 00	VALVE	6	273
5540 0883 00	RING	73	193
5540 0887 00	RING	20	211
5540 0995 00	HOSE	14	97
5540 0996 00	CLAMP	15	97
5540 1010 00	WASHER	4340	138
5540 1013 00	SET SCREW	4360	138
5540 1014 00	BOLT	3720	138
5540 1016 00	BOLT	4820	139
5540 1085 00	NUT	4	75
5540 1086 00	ELEMENT	7	75

Part no Detaljnr	Description	Ref no	See page Se sida
5540 1089 00	CUP	13	75
5540 1110 00	CAPSCREW	27	69
5540 1125 00	WASHER	9	69
5540 1125 00	WASHER	13	69
5540 1128 00	WASHER	10	15
5540 1137 00	RING	40	212
5540 1137 00	RING	25	211
5540 1137 00	RING	25	199
5540 1137 00	RING	2	199
5540 1141 00	RING	28	69
5540 1164 00	GEAR	9	319
5540 1292 00	HUB	2	209
5540 1309 00	GASKET	5	199
5540 1355 00	HYDRAULIC PUMP	1	314
5540 1692 00	VALVE	1	287
5540 1693 00	SEAL KIT	2	287
5540 1694 00	CARTRIDGE	3	287
5540 1754 00	WELDED HINGE	26	35
5540 2083 00	SCREW, HEX HEAD	37	173
5540 2102 00	CLAMP	6	78
5540 2583 00	COVER	1	277
5540 2661 00	BEARING	2030	141
5540 2662 00	GEAR	2110	141
5540 2663 00	SHIMS SET	2310	141
5540 2664 00	DUST COVER	2440	141
5540 2666 00	COLLAR	2460	141
5540 2667 00	FLANGE	2510	141
5540 2674 00	SPINDLE	3910	138
5540 2676 00	PLANET GEAR	4320	138
5540 2677 00	BEARING	4330	138

Part no Detaljnr	Description	Ref no	See page Se sida
5540 2679 00	GEAR RING	4710	139
5540 2680 00	GEAR	4720	139
5540 2681 00	BEARING	4750	139
5540 2688 00	BEARING	2410	141
5540 2848 00	ROLLER	64	218
5540 2848 00	ROLLER	4	217
5540 2848 00	ROLLER	64	193
5540 2848 00	ROLLER	63	192
5540 3821 00	SHAFT	4020	138
5540 3824 00	BOLT	3610	138
5540 3825 00	BOLT	3620	138
5540 3826 00	BOLT	2210	141
5540 3827 00	CASE	2910	142
5540 3828 00	BOLT	3010	142
5540 3831 00	LOCK PLATE	2040	141
5540 3832 00	LOCK RING	2020	141
5540 3833 00	BEARING	2010	141
5540 3834 00	RETAINER	2220	141
5540 3835 00	KIT	2610	142
5540 3836 00	SEAL	2450	141
5540 3843 00	BOLT	3030	142
5540 3844 00	NUT	3020	142
5540 3892 00	COIL	2	181
5540 4130 00	ADJUSTING NUT	2050	141
5540 4190 00	SEAL	3	319
5540 4555 00	CABLE LUG	4	123
5540 4555 00	CABLE LUG	3	255
5540 4586 00	SCREW	6	239
5540 4587 00	SCREW	7	239
5540 4592 00	CABLE CLAMP	31	239

Part no Detaljnr	Description	Ref no	See page Se sida
5540 4595 00	KIT		239
5540 4596 00	ROLLER		239
5540 4597 00	KIT		239
5540 4633 00	ACCUMULATOR	14	314
5540 4756 00	SPRING	1370	137
5540 4764 00	BEARING	162	195
5540 4764 00	BEARING	146	195
5540 4767 00	CLUTCH ASSY.	18	207
5540 4768 00	BEARING	19	207
5540 4776 00	SHAFT	45	218
5540 4776 00	SHAFT	19	217
5540 4796 00	SPOOL	8	175
5540 4796 00	SPOOL	8	179
5540 4823 00	RELIEF VALVE	6	321
5540 4910 00	CAP	2	323
5540 4911 00	CAP	3	323
5540 4912 00	O-RING	5	323
5540 4913 00	WASHER	5A	323
5540 4914 00	RING	6	323
5540 4915 00	BODY	7	323
5540 5033 00	BEARING	62	192
5540 5033 00	BEARING	65	193
5540 5036 00	SPRING	10	209
5540 5037 00	PISTON RING	11	209
5540 5197 00	FLANGE	56	315
5540 5510 00	LOCK NUT	14	250
5540 5511 00	SCREW	13	250
5540 5602 00	SEPARATOR	29	86
5540 5631 00	BEARING	1	57
5540 5634 00	SCREW, HEX HEAD	4	247

Part no Detaljnr	Description	Ref no	See page Se sida
5540 5642 00	CAPSCREW	11	57
5540 5894 00	BREATHER	410	137
5540 5895 00	PLUG	1010	137
5540 5897 00	PLUG	910	137
5540 5898 00	COVER	1630	137
5540 5901 00	GEAR RING	4730	139
5540 5902 00	PLATE	3960	138
5540 5903 00	BOLT	3970	138
5540 5905 00	NUT	3950	138
5540 5908 00	PLATE	4310	138
5540 5909 00	PLATE	4350	138
5540 5912 00	CARRIER	1910	141
5540 5913 00	BOLT	3650	138
5540 5914 00	NUT	3660	138
5540 5980 00	LOCK	9	250
5540 5993 00	SOCKET	8	250
5540 6087 00	BODY	1	321
5540 6088 00	VALVE	2	321
5540 6090 00	PLUG	11	321
5540 6091 00	O-RING	12	321
5540 6092 00	PLUG	13	321
5540 6093 00	O-RING	14	321
5540 6117 00	ELEMENT	3	95
5540 6118 00	SEAL KIT	0	95
5540 6126 00	VALVE	21	110
5540 6265 00	HOUSING	210	137
5540 6277 00	FITTING	25	339
5540 6324 00	GASKET	10	319
5540 6478 00	SEAL KIT	1	95
5540 6479 00	COLLECTOR	4	95

Part no Detaljnr	Description	Ref no	See page Se sida
5540 6679 00	RING	148	221
5540 6695 00	CAPSCREW	2	215
5540 6696 00	LOCK NUT	15	250
5540 6719 00	GASKET	26	69
5540 6744 00	O-RING	20	57
5540 6900 00	BACK PART	120	220
5540 7019 00	CAP	149	221
5540 7048 00	HOUSING	8	277
5540 7348 00	CHECK VALVE	23	172
5540 7372 00	CONTACT BLOCK	39	251
5540 7438 00	PLATE	121	220
5540 7490 00	BOLT	9	15
5540 7522 00	PLUG	310	137
5540 7522 00	PLUG	4410	138
5540 7522 00	PLUG	1210	137
5540 7523 00	AXLE SHAFT	510	137
5540 7524 00	AXLE SHAFT	520	137
5540 7531 00	O-RING	4830	139
5540 7531 00	O-RING	4610	138
5540 7612 00	COVER	74	219
5540 7613 00	GASKET	75	219
5540 7614 00	WASHER	17	211
5540 7614 00	WASHER	34	212
5540 7807 00	OIL COOLER	35	310
5540 7841 00	GASKET	22	175
5540 7844 00	WASHER	6	211
5540 8095 00	KNOB	2	245
5540 8178 00	CLAMP	11	97
5540 8293 00	ACCEL. PEDAL	1	237
5540 8302 00	LOCK NUT	43	22

Part no Detaljnr	Description	Ref no	See page Se sida
5540 8302 00	LOCK NUT	7	247
5540 8331 00	SPRING	46	304
5540 8347 00	FIRE EXTINGUIS.	1	121
5540 8350 00	COVER	43	218
5540 8367 00	THRUST WASHER	4630	138
5540 8440 00	BUSHING	4	239
5540 8441 00	CABLE	13	239
5540 8442 00	COVER	10	239
5540 8443 00	PLATE	16	239
5540 8444 00	PEDAL		239
5540 8499 00	KIT	37	166
5540 8538 00	PLATE	13	303
5540 8579 00	TRANSFORMER	5	250
5540 8593 00	CONNECTOR	2	255
5540 8594 00	CONNECTOR LOCK	4	255
5540 8596 00	CONNECTOR	53	251
5540 8597 00	CONNECTOR LOCK	55	251
5540 8598 00	CABLE LUG	5	91
5540 8598 00	CABLE LUG	5	259
5540 8625 00	FUEL FILTER	56	87
5540 8710 00	SEAL RING	3730	138
5540 8719 00	CLEVIS	14	55
5540 8783 00	CAPSCREW	4	69
5540 8945 00	FILTER	41	166
5540 9073 00	FILTER HOLDER	2	169
5540 9113 00	SPOOL	36	212
5540 9222 00	CONTROL	4	321
5540 9278 00	CROSS	3940	138
5540 9283 00	HOUSING	710	137
5540 9376 00	GREASE PUMP	1	335

Part no Detaljnr	Description	Ref no	See page Se sida
5540 9389 00	KIT	4210	138
5540 9429 00	PISTON RING	49	218
5540 9454 00	PISTON RING	56	218
5540 9511 00	CABLE TIES	6	91
5540 9566 00	PISTON RING	40	218
5540 9598 00	WASHER	4010	138
5540 9603 00	STUD	7	217
5540 9671 00	PEDAL	1	325
5540 9912 00	PLATE	1610	137
5540 9913 00	STATOR	1620	137
5540 9930 00	COVER	145	221
5540 9942 00	BOX	1	263
5540 9948 00	SEAL WASHER	67	251
5540 9956 00	KIT	12	250
5541 0093 00	FOOT BRAKE	26	314
5541 0241 00	MOUNT	4	66
5541 0272 00	CONNECTOR	2	259
5541 0272 00	CONNECTOR	2	91
5541 0273 00	CONNECTOR LOCK	3	91
5541 0273 00	CONNECTOR LOCK	3	259
5541 0286 00	CONNECTOR	2	123
5541 0288 00	CONNECTOR LOCK	3	123
5541 0324 00	PURIFIER	3	78
5541 0345 00	CONNECTOR LOCK	59	251
5541 0347 00	CONNECTOR	56	251
5541 0350 00	CONNECTOR	58	251
5541 0354 00	CONNECTOR LOCK	57	251
5541 0368 00	BOOT	4	259
5541 0368 00	BOOT	4	91
5541 0369 00	BOOT	5	123

Part no Detaljnr	Description	Ref no	See page Se sida
5541 0429 00	RUBBER DAMPER	47	86
5541 0457 00	SCREW, HEX HEAD	12	69
5541 0462 00	PLUG	12	241
5541 0462 00	PLUG	52	251
5541 0472 00	SHIELD	15	69
5541 0493 00	SCREW, HEX HEAD	10	69
5541 0563 00	BUSBAR	6	250
5541 0600 00	CONTROL LAMP	47	251
5541 0679 00	ABSORBER	63	251
5541 0721 00	GROMMET	17	241
5541 0815 00	CAPSCREW	32	250
5541 0820 00	CAPSCREW	64	251
5541 0825 00	CAPSCREW	30	250
5541 0834 00	SCREW, HEX HEAD	4	241
5541 0838 00	SPRING WASHER	33	251
5541 0840 00	SPRING WASHER	5	241
5541 0860 00	RELAY	10	250
5541 0943 00	SWITCH	2	283
5541 1136 00	COVER	1310	137
5541 1249 00	BELT	5	263
5541 1254 00	SHAFT	87	193
5541 1254 00	SHAFT	122	194
5541 1308 00	PACKING	2	183
5541 1438 00	CAPSCREW	15	271
5541 1439 00	WASHER	16	271
5541 2108 00	SHOULDER SCREW	40	22
5541 2158 00	STUD	4	215
5541 2171 00	FILLER COVER	18	66
5541 2289 00	PISTON RING	107	194
5541 2289 00	PISTON RING	3	191

Part no Detaljnr	Description	Ref no	See page Se sida
5541 2289 00	PISTON RING	55	192
5541 2289 00	PISTON RING	100	193
5541 2329 00	PLATE	1	345
5541 2329 00	PLATE	1	343
5541 2330 00	VALVE	6	343
5541 2332 00	PLATE	2	345
5541 2332 00	PLATE	2	343
5541 2333 00	VALVE	8	345
5541 2334 00	PLATE	3	343
5541 2334 00	PLATE	3	345
5541 2336 00	INDICATOR	10	345
5541 2336 00	INDICATOR	8	343
5541 2415 00	TIE ROD	7	343
5541 2446 00	FITTING	40	340
5541 2447 00	CAP	39	340
5541 2448 00	VALVE	37	340
5541 2450 00	PLUG	17	339
5541 2451 00	PLUG	22	339
5541 2453 00	PLATE	8	339
5541 2454 00	PUMP HOUSING	16	339
5541 2455 00	CAM	12	339
5541 2456 00	ADAPTER	41	340
5541 2457 00	KIT	42	340
5541 2458 00	RESERVOIR	43	340
5541 2459 00	KIT	44	340
5541 2460 00	BEARING	45	340
5541 2461 00	MOTOR SET		339
5541 2462 00	SEAL KIT		339
5541 2464 00	KIT	47	340
5541 2465 00	CIRCUIT BOARD	26	339

Part no Detaljnr	Description	Ref no	See page Se sida
5541 2499 00	COVER	30	339
5541 2570 00	CLAMP	46	165
5541 2578 00	CLAMP	40	310
5541 2981 00	VALVE	4	345
5541 2982 00	VALVE	5	345
5541 2983 00	RING	7	345
5541 2986 00	RING	5	343
5541 3127 00	ACTUATOR	5	121
5541 3174 00	CABLE TIES	51	251
5541 3282 00	WASHER	4	155
5541 3344 00	LOCK NUT	2	271
5541 3359 00	SNAP RING	20	271
5541 3404 00	TOP PART	5	78
5541 3414 00	SEAL KIT	3810	138
5541 3447 00	COOLER	1	91
5541 3593 00	TACHOMETER	18	250
5541 3639 00	PUMP	100	220
5541 3641 00	NUT	30	78
5541 3641 00	NUT	7	161
5541 3641 00	NUT	9	241
5541 3641 00	NUT	33	21
5541 3641 00	NUT	3	172
5541 3641 00	NUT	31	78
5541 3648 00	FAN	2	69
5541 3662 00	SEAL KIT		271
5541 3741 00	CYLINDER COVER	10	271
5541 3742 00	PISTON	6	271
5541 3941 00	CYL.BARREL	8	271
5541 4036 00	O-RING	25	303
5541 4293 00	GEAR	81	219

Part no Detaljnr	Description	Ref no	See page Se sida
5541 4375 00	HYDRAULIC PUMP	1	273
5541 4412 00	HINGE	16	21
5541 4412 00	HINGE	58	11
5541 4490 00	CARRIER	1810	138
5541 4666 00	EXHAUST	34	78
5541 4680 00	CROSS	12	277
5541 4694 00	COOLER	1	93
5541 4695 00	NUT	2	93
5541 4698 00	WASHER	3	93
5541 4699 00	FAN	4	93
5541 4700 00	FAN	5	93
5541 4701 00	SPACER	6	93
5541 4702 00	CAPSCREW	7	93
5541 4703 00	MOTOR	8	93
5541 4704 00	CAPSCREW	9	93
5541 4705 00	WASHER	10	93
5541 4706 00	SUPPORT	2	107
5541 4707 00	TUBE	3	107
5541 4708 00	TUBE	4	107
5541 4709 00	SHROUD	5	107
5541 4710 00	FAN	6	107
5541 4711 00	FLANGE SCREW	7	107
5541 4711 00	FLANGE SCREW	8	107
5541 4712 00	GUARD	9	107
5541 4713 00	SEAL		107
5541 4750 00	CAPSCREW	90	219
5541 4764 00	TRANSMISSION	30	97
5541 4971 00	GROMMET	3	107
5541 4972 00	GROMMET	3	107
5541 5364 00	TUBE	1	103

Part no Detaljnr	Description	Ref no	See page Se sida
5541 5365 00	CROSS	2	103
5541 5366 00	GASKET	3	103
5541 5367 00	CROSS	4	103
5541 5368 00	WASHER	5	103
5541 5369 00	WASHER	6	103
5541 5377 00	CAP	810	137
5541 5378 00	CAP	1510	137
5541 5490 00	BUSHING	21	271
5541 5491 00	BUSHING	22	271
5541 5509 00	LOCK NUT	34	251
5541 5596 00	PISTON ROD	9	271
5541 5698 00	BEARING	4765	139
5541 5727 00	PLATE	50	166
5541 5731 00	PLATE	52	166
5541 5743 00	INSERT	51	166
5541 5936 00	CARTRIDGE	1	185
5541 6097 00	SILENCER	4	78
5541 6102 00	BRACKET	7	250
5541 6107 00	TIRE	1	227
5541 6638 00	HOSE ASSEMBLY	54	118
5541 7067 00	HAND PUMP	30	314
5541 7078 00	LEVER	6	327
5541 7087 00	NUT	6	81
5541 7531 00	CONTROL		191
5541 7604 00	BRAKE UNIT	610	137
5541 7613 00	STUD	4620	138
5541 7614 00	COVER	4810	139
5541 7731 00	HUB	3710	138
5541 9275 00	RECEPTACLE	3	250
5541 9281 00	INDICATOR	26	250

Part no Detaljn	Description	Ref no	See page Se sida
5541 9282 00	INDICATOR	25	250
5541 9283 00	INDICATOR	27	250
5541 9285 00	GAUGE	11	250
5541 9311 00	GASKET	4	250
5541 9492 00	PRESSURE SWITCH	1	123
5541 9503 00	CONNECTOR	1	255
5541 9856 00	CARTRIDGE	24	117
5542 0224 00	KIT	3090	138
5542 0224 00	KIT		141
5542 1111 00	FILTER GAUGE	55	87
5550 0667 00	ACCESS COVER	18	29
5550 0667 00	ACCESS COVER	21	35
5550 2851 00	THREADED ROD	11	245
5553 6763 00	CASTLE NUT	3	155
5553 8109 00	MOUNT	33	148
5553 8252 00	GUARD	31	148
5554 5348 00	LOCK DEVICE	27	21
5554 5348 00	LOCK DEVICE	28	32
5555 2581 00	CHAIN	5	41
5556 0139 00	COVER PLATE	19	29
5556 7224 00	CAP	4	13
5556 9699 00	COVER	6	133
5557 2371 00	WEARING RING	1	183
5557 9156 00	BEARING	12	47
5557 9331 00	PACKING	5	295
5557 9332 00	ROD END	6	295
5557 9836 00	PIN	2	293
5558 2323 00	BAR	13	293
5558 3051 00	COVER	26	47
5558 9017 00	SPACER	7	125

Part no Detaljn	Description	Ref no	See page Se sida
5559 3542 00	SUPPORT	27	47
5559 3684 00	MOUNT	17	172
5559 8586 00	GASKET	2	273
5559 9230 00	WASHER	30	32
5559 9230 00	WASHER	11	335
5559 9230 00	WASHER	29	21
5559 9230 00	WASHER	14	203
5559 9230 00	WASHER	7	263
5559 9230 00	WASHER	67	315
5559 9230 00	WASHER	31	105
5559 9230 00	WASHER	8	110
5559 9231 00	WASHER	20	298
5559 9231 00	WASHER	3	237
5559 9231 00	WASHER	13	172
5559 9231 00	WASHER	36	117
5559 9231 00	WASHER	73	315
5559 9231 00	WASHER	10	203
5559 9231 00	WASHER	8	241
5559 9231 00	WASHER	17	273
5559 9231 00	WASHER	35	22
5559 9231 00	WASHER	5	261
5559 9231 00	WASHER	33	335
5559 9231 00	WASHER	4	125
5559 9231 00	WASHER	12	203
5559 9232 00	WASHER	85	11
5559 9232 00	WASHER	43	299
5559 9232 00	WASHER	9	237
5559 9232 00	WASHER	34	97
5559 9232 00	WASHER	4	41
5559 9232 00	WASHER	11	293

Part no Detaljnr	Description	Ref no	See page Se sida
5559 9232 00	WASHER	72	315
5559 9232 00	WASHER	53	336
5559 9232 00	WASHER	19	35
5559 9232 00	WASHER	5	69
5559 9232 00	WASHER	37	22
5559 9232 00	WASHER	56	166
5559 9232 00	WASHER	38	310
5559 9232 00	WASHER	22	172
5559 9232 00	WASHER	26	273
5559 9232 00	WASHER	4	32
5559 9232 00	WASHER	41	86
5559 9232 00	WASHER	24	21
5559 9232 00	WASHER	39	148
5559 9232 00	WASHER	31	117
5559 9232 00	WASHER	22	29
5559 9232 00	WASHER	5	71
5559 9232 00	WASHER	3	243
5559 9232 00	WASHER	4	245
5559 9232 00	WASHER	6	235
5559 9232 00	WASHER	12	78
5559 9232 00	WASHER	34	32
5559 9233 00	WASHER	5	215
5559 9234 00	WASHER	35	148
5559 9234 00	WASHER	7	245
5559 9234 00	WASHER	19	105
5559 9234 00	WASHER	17	148
5559 9234 00	WASHER	20	21
5559 9234 00	WASHER	30	335
5559 9234 00	WASHER	8	261
5559 9234 00	WASHER	77	315

Part no Detaljnr	Description	Ref no	See page Se sida
5559 9234 00	WASHER	8	269
5559 9234 00	WASHER	87	11
5559 9236 00	WASHER	12	57
5559 9236 00	WASHER	27	148
5559 9236 00	WASHER	8	105
5559 9236 00	WASHER	7	66
5559 9237 00	WASHER	81	11
5559 9237 00	WASHER	12	66
5559 9237 00	WASHER	3	15
5559 9238 00	WASHER	3	225
5559 9239 00	WASHER	4	17
5559 9239 00	WASHER	10	105
5559 9239 00	WASHER	59	47
5559 9239 00	WASHER	11	133
5559 9239 00	WASHER	31	57
5559 9239 00	WASHER	4	187
5559 9239 00	WASHER	9	66
5559 9239 00	WASHER	6	13
5559 9241 00	WASHER	4	145
5559 9241 00	WASHER	14	133
5559 9242 00	WASHER	11	55
5559 9987 00	DRIVELINE	5	148
5561 4110 00	FLANGE	20	35
5561 6328 00	HOSE	17	97
5562 0309 00	LABEL	1	353
5562 9588 00	PIN	3	293
5563 1862 00	MOUNT	45	165
5563 3090 00	LEVER	10	235
5563 3142 00	FLAT KEY	11	235
5563 5240 00	MOUNT	49	165

Part no Detaljnr	Description	Ref no	See page Se sida
5563 6449 00	PLATE	3	133
5564 0889 00	JUNCTION BLOCK	60	315
5564 0889 00	JUNCTION BLOCK	42	166
5564 0934 00	CYLINDER SET		291
5564 0936 00	CYL.BARREL	1	295
5564 0939 00	BARREL	2	295
5564 0941 00	PACKING	4	295
5564 0949 00	BARREL	3	295
5564 1385 00	MOUNT	43	165
5564 7229 00	PIN	7	53
5565 1702 00	ACCUMULATOR	20	172
5565 1703 00	BARREL	5	183
5565 1705 00	PISTON	3	183
5565 1707 00	CAP	7	183
5565 2241 00	GUARD	14	293
5565 2848 00	JUNCTION BLOCK	2	298
5565 4201 00	JUNCTION BLOCK	13	310
5565 4520 00	BLOCK	65	315
5565 7678 00	GUARD	14	148
5570 4133 00	COUPLE	24	69
5570 4134 00	ADAPTER	25	69
5570 5263 00	FITTING	43	315
5570 5608 00	TRANSMISSION	1	189
5570 5608 73	CASE		191
5570 5608 74	TRANSM.SPEC		191
5570 5608 75	TRANSM.SPEC		191
5570 9641 00	HOSE	10	97
5571 0790 00	HOSE	12	97
5571 3299 00	LIFT EAR	12	15
5571 3470 00	RIM	2	227

Part no Detaljnr	Description	Ref no	See page Se sida
5571 3471 00	RIM BASE	1	229
5571 3525 00	INSERT	28	47
5571 3526 00	RETAINER	2	57
5571 3529 00	PIN	5	57
5571 3531 00	SHIM	22	57
5571 3532 00	SHIM	23	57
5571 3533 00	SHIM	24	57
5571 3534 00	SHIM	25	57
5571 3537 00	SHAFT	1	135
5571 4082 00	STOP	25	35
5571 4082 00	STOP	26	21
5571 4500 00	SHIM	26	57
5571 4619 00	BUSHING	6	172
5571 4891 00	SWIVEL		7
5571 4948 00	RETAINER	6	57
5571 4949 00	RETAINER	4	57
5571 5246 00	HOSE	7	97
5571 5542 00	AXLE	1	133
5571 5542 00	AXLE	1	145
5571 6896 00	PIN	3	49
5571 6896 00	PIN	3	59
5571 7188 00	TAILGATE		7
5571 7446 00	CHAIN	15	55
5571 7641 00	MOUNT	5	237
5571 9008 00	MANIFOLD	8	273
5571 9986 00	ROD END	8	245
5572 0397 00	LOCKING PIN	60	47
5572 0554 00	PIN	5	59
5572 0554 00	PIN	5	49
5572 2780 00	BUSHING	5	105

Part no Detaljnr	Description	Ref no	See page Se sida
5572 2781 00	INSERT	27	105
5572 2783 00	LABEL	27	353
5572 2784 00	LABEL	13	353
5572 2786 00	LABEL	18	353
5572 2787 00	LABEL	20	353
5572 2788 00	LABEL	19	353
5572 2789 00	LABEL	6	353
5572 2791 00	LABEL	22	353
5572 2792 00	LABEL	21	353
5572 2793 00	LABEL	11	241
5572 2795 00	LABEL	3	353
5572 2930 00	LABEL	6	243
5572 3035 00	LABEL	16	353
5572 3036 00	LABEL	11	353
5572 3041 00	LABEL	5	353
5572 3041 00	LABEL	7	243
5572 3167 00	LABEL	10	353
5572 3329 00	LABEL	12	353
5572 4000 00	GAUGE	21	250
5572 4002 00	GAUGE	19	250
5572 4003 00	GAUGE	2	257
5572 4004 00	GAUGE	17	250
5572 4005 00	GAUGE	16	250
5572 4007 00	GAUGE	20	250
5572 4008 00	GAUGE	22	250
5572 4009 00	WIRING	60	251
5572 4009 00	WIRING	3	257
5572 4970 00	DUMP BOX	1605	51
5572 5259 00	WASHER	5	66
5572 5271 00	GUARD	32	148

Part no Detaljnr	Description	Ref no	See page Se sida
5572 5294 00	LABEL	21	117
5572 5385 00	MOUNT	4	105
5572 5387 00	MOUNT	3	105
5572 5703 00	LABEL	14	353
5572 8185 00	SPACER RING	14	269
5572 8337 00	MOUNT	2	261
5572 8766 00	LABEL	9	353
5572 8907 00	LABEL	29	250
5572 9426 00	PIN	11	269
5572 9427 00	PIN	12	269
5573 0697 00	MOUNT	5	335
5573 0712 00	BLOCK	2	335
5573 0713 00	BLOCK	3	335
5573 1076 00	LABEL	17	235
5573 2275 00	LABEL	7	353
5573 2275 00	LABEL	50	335
5573 2450 00	PIN	9	55
5573 2468 00	SWITCH	39	118
5573 4655 00	NUT	3	279
5573 5467 00	HOSE	16	97
5573 5569 00	BINDER BOX		233
5573 5570 00	DUMP CONTROL		233
5573 5571 00	THROTTLE CONTR.		233
5573 5574 00	CONTROL		233
5573 5595 00	RADIATOR		63
5573 5599 00	TRANSMISSION		131
5573 5600 00	CONVERTER		131
5573 5766 00	TUBE	1	78
5573 5998 00	HYDRAUL. FILTER	8	35
5573 6003 00	DOOR	24	35

Part no Detaljnr	Description	Ref no	See page Se sida
5573 6004 00	SUCTION PIPE	6	32
5573 6006 00	BRACKET	9	32
5573 6026 00	TUBE	12	165
5573 6028 00	TUBE	14	165
5573 6031 00	CONVERTER	1	215
5573 6038 00	MOUNT	7	69
5573 6041 00	WELDMENT	8	69
5573 6044 00	MOUNT	3	66
5573 6220 00	FITTING	14	298
5573 6221 00	PLATE	41	299
5573 6222 00	PLATE	42	299
5573 6223 00	TUBE	1	97
5573 6224 00	TUBE	2	97
5573 6225 00	TUBE	3	97
5573 6226 00	TUBE	4	97
5573 6228 00	TUBE	6	97
5573 6415 00	CHASSIS	1601	45
5573 6418 00	SWIVEL LOCK		7
5573 6418 61	LOCKING	3002	45
5573 6420 00	MOUNT	33	310
5573 6470 00	WELDMENT	3	21
5573 6474 00	SUPPORT	9	21
5573 6475 00	SUPPORT	10	21
5573 6476 00	SUPPORT	11	21
5573 6477 00	SUPPORT	12	21
5573 6480 00	RADIATOR	1	105
5573 6481 00	TANK	32	97
5573 6487 00	RUBBERMOULDING	28	105
5573 6488 00	RUBBERMOULDING	29	105
5573 6500 00	EAR	5	15

Part no Detaljnr	Description	Ref no	See page Se sida
5573 6510 00	MOUNT	21	78
5573 6512 00	MOUNT	20	78
5573 6520 00	LEVER	1	235
5573 6521 00	FLANGE	8	235
5573 6533 00	CONNECTING ROD	13	235
5573 6541 00	TRANSMISSION	1	187
5573 6542 00	PLATE	2	187
5573 6547 00	EAR	6	15
5573 6548 00	EAR	7	15
5573 6549 00	PLATE	6	237
5573 6551 00	PLATE	7	237
5573 6587 00	LOCK	1	59
5573 6587 00	LOCK	1	49
5573 6649 00	AXLE SUPPORT	37	11
5573 6694 00	MOUNTING PLATE	70	315
5573 6732 00	DRIVE LINE	1	153
5573 6735 00	DRIVE LINE	1	155
5573 6743 00	SPACER	6	148
5573 6746 00	WRAPPER	19	148
5573 6750 00	MOUNT	2	161
5573 6751 00	MOUNT	3	161
5573 6753 00	STRAP	6	161
5573 6769 00	FOOT PLATE	63	11
5573 6780 00	DUMP BOX	1	53
5573 6786 00	CONTROL	1	243
5573 6787 00	ATTACHMENT	1	245
5573 6792 00	LEVER ARM	14	245
5573 6804 00	GUARD	39	86
5573 7009 00	CONTROL	2	279
5573 8092 00	MOUNT	25	78

Part no Detaljnr	Description	Ref no	See page Se sida
5573 8399 00	FIRE EXTINGUIS.		63
5573 8436 00	TUBE	36	166
5573 9713 00	ATTACHMENT	2	66
5574 0335 00	DRIVELINE		131
5574 0338 00	HYDR. SYSTEM		291
5574 0342 00	BRAKE SYSTEM		307
5574 0344 00	HYDR. SYSTEM		307
5574 0382 00	DRIVELINE	4	148
5574 0383 00	DRIVE LINE	1	157
5574 0415 00	PLATE	39	11
5574 0443 00	DRIVELINE	1	148
5574 0444 00	DRIVELINE	1	151
5574 0446 00	COVER	21	148
5574 0447 00	COVER	1	161
5574 0448 00	MOUNT	13	148
5574 0468 00	COVER	6	21
5574 0915 00	WASHER	29	35
5574 0971 00	BRACKET	9	78
5574 1028 00	LABEL	18	235
5574 1048 00	RUBBERMOULDING	33	105
5574 1198 00	CYLINDER ASSY	1	269
5574 1478 00	SPACER	3	69
5574 1479 00	STIFFENER	8	15
5574 2867 00	LUBR. SYSTEM		331
5574 3107 00	AIR INLET		63
5574 3108 00	BRACKET	2	71
5574 3109 00	COVER	5	21
5574 3110 00	PLATE	3	71
5574 3112 00	AIR INLET	8	71
5574 3121 00	COVER	1	21

Part no Detaljnr	Description	Ref no	See page Se sida
5574 3125 00	COVER	22	71
5574 4753 00	CYLINDER SET		267
5574 4754 00	TUBE	2	269
5574 4755 00	TUBE	3	269
5574 4756 00	TUBE	4	269
5574 4757 00	TUBE	5	269
5574 4758 00	MOUNT	10	269
5574 4766 00	PENDULUMHOUSING	2	133
5574 4768 00	TUBE	11	165
5574 4769 00	BRACKET	15	165
5574 4770 00	BRACKET	16	165
5574 4772 00	HYDR. SYSTEM		131
5574 4799 00	TUBE	35	166
5574 4800 00	TUBE	13	165
5574 4802 00	SPACER	38	97
5574 4803 00	FRONT AXLE		131
5574 4973 00	TIE PLATE	11	47
5574 4976 00	TIE PLATE	10	47
5574 4996 00	REAR AXLE		131
5574 4997 00	AIR CLEANING	1	71
5574 5277 00	INLET PORT	14	71
5574 5497 00	CAP	1	41
5574 5717 00	COVER	32	117
5574 5794 00	CAP	23	32
5574 5814 00	FUEL TANK	3102	9
5574 5815 00	HYDR.OIL TANK	3105	9
5574 6160 00	CABLE	28	250
5574 6442 00	PIPE	2	78
5574 6599 00	BAR	7	21
5574 7219 00	HYDR. SYSTEM		131

Part no Detaljnr	Description	Ref no	See page Se sida
5574 7220 00	CONTROL		233
5574 7652 00	HOSE	18	71
5574 7896 00	COVER	8	21
5574 7924 00	BRACKET	4	21
5574 8203 00	BRACKET	1	172
5574 8208 00	ARM	3	245
5574 8351 00	TUBE	27	78
5574 8352 00	GUARD	26	78
5574 8419 00	WELDMENT	19	66
5574 8836 00	SIGN SET		349
5574 9944 00	GAUGE		233
5574 9945 00	FIRE SUPPR.SYST		63
5575 0115 00	LEVEL SENSOR	1	257
5575 0776 00	LABEL	23	353
5575 0777 00	LABEL	24	353
5575 1837 00	CABLE	61	251
5575 4091 00	HOSE	18	97
5575 4880 00	RADIATOR	1	86
5575 5268 00	COOLING SYSTEM		63
5575 5313 00	HOSE	30	69
5575 5392 00	DIESEL ENGINE	1	66
5575 5393 00	DIESEL ENG.SET		63
5575 5802 00	CABLE COMPLETE	18	335
5575 5837 00	FUEL SYSTEM		63
5575 5931 00	TUBE	5	97
5575 7000 60	GRILL	1	15
5575 7001 46	DIESEL ENGINE	1	69
5575 7002 82	GRILL	1102	9
5575 7002 99	HOSE ASSEMBLY	117	311
5575 7003 15	VALVE	1	279

Part no Detaljnr	Description	Ref no	See page Se sida
5575 7003 16	JOYSTICK	3	273
5575 7003 17	HOSE ASSEMBLY	23	250
5575 7003 38	EXHAUST SYSTEM		63
5575 7003 59	HOSE ASSEMBLY	104	89
5575 7003 60	HOSE ASSEMBLY	105	89
5575 7003 62	MOUNT	57	87
5575 7003 69	YOKE	7	155
5575 7003 77	DRIVELINE	3	148
5575 7003 78	DRIVELINE	2	148
5575 7004 28	HOSE ASSEMBLY	119	274
5575 7005 91	STRAINER	3	27
5575 7006 00	HYDR. SYSTEM		267
5575 7007 18	VALVE	1	281
5575 7007 19	STUD	2	281
5575 7007 38	STAY	15	21
5575 7007 77	HOLDER IRON	59	22
5575 7008 09	HOSE ASSEMBLY	101	66
5575 7008 49	PLATE	44	79
5575 7009 93	INSTRUCTIONSIGN	29	353
5575 7009 94	INSTRUCTIONSIGN	30	353
5575 7013 60	HOSE ASSEMBLY	105	166
5580 0009 37	HOSE	30	86
5580 0009 37	HOSE	8	97
5580 0009 93	HOSE	29	69
5580 0010 04	CHAIN	40	335
5580 0012 50	SEAL	48	87
5580 0012 50	SEAL	14	21
5580 0028 29	GAUGE PANEL	1	247
5580 0045 91	HOSE ASSEMBLY	102	310
5580 0046 72	HOSE ASSEMBLY	103	310

Part no Detaljnr	Description	Ref no	See page Se sida
5580 0073 34	O-RING	128	220
5590 0001 03	CHASSIS		7
5590 0001 38	WHEEL COMPL.	1	225
5590 0001 42	SET OF WHEELS		131
5590 0001 45	EXHAUST COVER	23	78
5590 0001 50	EXHAUST COVER	19	78
5590 0001 53	ATTACHM. PLATE	24	78
5590 0001 54	ATTACHM. PLATE	14	66
5590 0001 72	GAUGE PANEL		233
5590 0001 76	DUMP BOX		7
5590 0001 77	POWERFRAME		7
5590 0002 31	CONVERTER	24	217
5590 0002 88	DRIVERS CHAIR	1	261
5590 0003 61	ATTACHMENT	48	98
5590 0023 78	CABLE COMPLETE	38	335
5590 0025 78	ADAPTER	15	110
5590 0025 93	PIPE CONNECTION	13	110
5590 0025 94	MOUNT	3	110
5590 0026 32	COVER	14	335
5590 0026 38	COVER	6	335
9106 1071 00	READ INSTR.BOOK	25	353
9106 1071 01	READ INSTR.BOOK	33	354
9106 1071 03	NO ADMITTANCE	35	354
9106 1071 07	WATER INLET	26	353
9106 1071 12	BATTERY SWITCH	2	353
9106 1071 15	FUEL	4	353
9106 1073 06	HIGH SOUND LEV.	32	353
9106 1073 13	FALLING BOOM	8	353
9106 1073 16	RISK OF CRUSH.	15	353
9106 1073 16	RISK OF CRUSH.	28	353

Part no Detaljnr	Description	Ref no	See page Se sida
9106 1073 31	HAZARDOUS PRES.	34	354
9106 1073 32	HAZARDOUS PRES.	17	353
9125 6871 00	O-RING	39	166